



Sagging or Rubbing Sauna Door Maintenance Guidelines

The most common cause of a sagging sauna door is the frame on the hinge side sagging as well. Remove 1 of the shorter screws in the hinge and replace with a longer 3" (8cm) wood screw to pull the frame back again. The top hinge is normally the most important one. If the door is still rubbing on the frame you can choose to install some wood screws on the opposite side of the hinges. See photos below;



If your sauna door is twisted or crooked loosen the screws from the top and bottom of the door so you can straight the frame and re tighten the screws. It is recommended to remove the door from the frame and do this with the door laying down on a flat surface. We also recommend re-positioning the screws so they do not end up in the same hole pattern as before. Wood glue should be applied. Photo Below.



Dundalk LeisureCraft Inc.

318448 8th Line, Melancthon, Ontario Canada L9V 2K3

Ph: 519-923-9813 | Fax: 866-458-7583 | Web: www.leisurecraft.com