


40" Slate Top Wood Burning Firepit

MODEL # FT-51216

AZPH-YAYI



ATTACH YOUR RECEIPT HERE

Serial Number .	 Purchase	Date	

OWNER'S MANUAL

Item Number: FTB-51216

Product Name: 40 Inch Slate Fire Pit

WARNINGS:


- This fire bowl is intended for outdoor use only. Do not use on wooden decks.
- This fire bowl is intended to burn wood logs only. Do not burn coal, leaves, or other combustible materials in the fire bowl.
- Not for use by children. Keep children and pets away from the fire bowl.
- The fire bowl is hot. Use with caution. Do not touch the hot fire bowl with bare hands.
- Never leave any burning fire bowl unattended, always extinguish the fire completely before leaving the fire bowl.
- Do not use near flammable or combustible objects or materials.
- When the fire bowl is in use, the handle on the mesh screen can reach extreme temperatures that
 can cause serious injury to an unprotected hand. Use a poker or an appropriate heat resistant glove
 or pad when handling.
- Check local fire regulations and municipal by-laws for safe use.

FIRE PIT PARTS LIST

No.	PARTS	Qty
Α	Handle	1
В	Mesh Screen	1
С	Log Grate	1
D	Fire Bowl	1
Е	Slate Top	1
F	Leg	4
G	Support Ring	1
Н	Poker	1

HARDWARE LIST


No.	Hardware	Qty
AA	M6*12 bolt	14
BB	M6 Nut	2




Step By Step Assembly Instructions:

Step 1: Choose a level location for assembly. Remove all parts from packaging, check parts list for missing parts.


Step 2: Attach Leg (F) to Slate Top (E) by using 8pcs M6*12 bolts (AA) Do not fully tighten at first!




Step 3: Attach Support Ring (G) to 4 Legs (F) by using 4pcs M6*12 bolts(AA) tightened, once ring is attached tighten all the bolts.



Step 4: Insert Handle (A) into mid hole of Mesh Screen (B) by using M6*12MM bolts (AA) and M6 Nut (BB) tightened.



Step 5: Place Log Grate(C) and Mesh Screen (B) into the Fire Bowl. Then put the Fire Bowl (D) into the Slate top.



Now your fire pit is ready for use!

