



AM2000 AIR MOVER USER MANUAL



Drawing No. :- TPC403
Issue :- 1
Date :- 01/10/13

IMPORTANT

UNPACKING

Remove the top insert and your EIPL Air Mover from its packing carton, visually inspect for any signs of transit damage. If there are any signs of damage, do not operate your unit. Call your supplier immediately for advice. Do not discard the packing for it will be useful for transporting your unit in the future.

TRANSPORTATION

A cord wrapping facility has been moulded into the plastic fan housing. The power cord should be wrapped around this facility during transit. Do not drop or abuse your Air Mover during transit for risk of damage to both the motor and housing.

INTRODUCTION

EIPL Air Movers are high performance, high efficiency fan systems designed to optimize air movement and minimize operating costs for drying applications. Each model incorporates a double inlet, centrifugal type fan design to provide the high static pressure and airflow required to dry water damaged facilities and equipment. The EIPL Air Mover series was designed to provide you the best performance and serviceability.

- 25 ft. Power Cord with cord grip
- Internal thermal Circuit Breaker
- Aerodynamic, Rotationally Moulded Polythene Housing.
- High Efficient 1/2 HP Motor
- Three Speed Fan Design
- 4 operating Positions (0°, 12°, 45°, & 90°)
- Stack ability in the Vertical Plane during both Storage and Operation.
- Moulded Cord wrap Facility

OPERATING PROCEDURES

Connect the power cord into a grounded electrical outlet and turn the power switch to the ON position. If you have no power or hear any loud or abnormal noises and consult your supplier.

Your EIPL Air Mover is designed to operate in 4 positions to allow drying of floors, walls and ceilings.

Your EIPL Air Mover comes with internal circuit protection for your safety. When working around a wet environment, we also recommend always plugging the unit into a ground fault interrupter to assure the best protection.

For the drying of water damaged facilities, we recommend using an EIPL dehumidifier along with your air mover to provide you with more efficient drying. Your air mover is designed to induce evaporation or water contained within flooded surfaces or materials. Yet, without a mechanism for removing the moisture from the air, drying will not occur. It is recommended that the dehumidifier outlet is close to the air mover intake. This allows for dry air to be distributed by the air mover.

IF YOUR AIRMOVER FAILS TO OPERATE

1. Check that the plug is fully pushed into the socket and is switched on.
2. Check with some other electrical device that the wall socket is "live". If it is not, contact a qualified electrician.
3. Check the circuit breaker on the control panel and reset as required.

Should none of the above remedies work, then disconnect from the mains. Contact your supplier. DO NOT attempt to repair the unit or unscrew the outer casing.

ELECTRICAL CONNECTION

If the appliance is fitted with a plug for which your socket is unsuitable, then it should be cut off and an appropriate plug fitted.

This appliance complies with the suppression requirements of the EEC direction 82/199/EEC as embodied in BS800:1988.

IMPORTANT:- The wires in this mains lead are coloured in accordance with the following code:-

Green	Earth
White	Neutral
Black	Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your own plug, proceed as follows:

The wire which is coloured Green and Yellow must be connected to the terminal in the plug which is marked with the letter E or by the Earth Symbol or coloured Green and Yellow. The wire which is coloured Blue must be connected to the terminal in the plug which is marked with the letter N or coloured Black. The wire which is coloured Brown must be connected to the terminal which is marked with the letter L or coloured Red.

You must dispose of the non rewirable plug once it has been removed from the flexible cord. It is dangerous to attempt to insert the plug into any electrical socket elsewhere in the house. If the flexible cord becomes damaged it must be replaced by an identical cord.

WARNING – THIS APPLIANCE MUST BE EARTHED

TECHNICAL SPECIFICATIONS

AM2000	115V/60Hz/1 Phase
Height	21"
Width	20"
Depth	19"
Weight	34lbs
Horsepower	1/2
Max running current	5A
Fan Speeds	3

- This machine should be serviced by qualified Ebac personnel or other persons having technical competence servicing refrigeration equipment following the instructions in the Ebac service manual.
- Ebac service manuals and spares lists are available upon request by contacting your local Ebac distributor.
- Never operate the unit in a bathroom or swimming pool area
- Do not use the machine if the power cord or case are damaged.
- Do not poke objects into and of the grilles on the machine.
- Do not cover or obstruct the air inlet or outlet.
- This machine complies with the electromagnetic compatibility 1992 regulations.
- This machine has been manufactured in the United Kingdom.