
Vehicle Loading Ramp

AVA101



Note: Gloves are recommended during product installation.



Imported by:


KCT Leisure Glebe Farm, Old London Road, Copdock, Ipswich, Suffolk, IP83JN, United Kingdom



1. FEATURES

Material: Steel - Weight of a ramp: 6kg Ramp unfolded length: 160 cm / ramp folded: 80 cm Maximum load: 200kgs

- 2. HOW TO USE IT
 - a) Mounting



- 1. (x 6pcs 3. x 6pcs
- 2. (x 6pcs 4. O x 4pcs

b) Start

- Make sure no persons or animals are under the ramp or truck bed during the loading process.
- Never load a vehicle while its engine is running. Let the vehicle cool down before loading it.
- Never exceed the maximum weight (see description). Load the vehicle slowly. Do not drop load onto ramp. This may reduce load capacity and possibly lead to personal injury and / or property damage. All loading and unloading must be done on a flat, level, dry surface.

Loading a Motorcycle (3 persons)

- Make sure the ramp is clean of dirt, debris, grease and oil.

1.

- The tongue edge must face down fully and touch the tailgate of the truck.
- Position a person on each side of the motorcycle. Each person should hold either the front handlebar or the front fork, where they can steer/guide the vehicle.
- They should position their other hand toward the rear of the seat or the rear fork. The third person can start the process from the rear, by pushing, then move to the inside of the truck bed to take control of the motorcycle when it enters the truck bed.
- Put motorcycle in neutral.
- As the motorcycle contacts the ramp, make sure the ramp remains straight, and the tongue edge remains in contact with the truck bed. If not, roll back and slowly start over.

3. CARE AND MAINTENANCE

- Always wear protective gloves.
- Warning Risk of property damage or bodily injury.
- Always respect the safety instructions.
- All persons not involved in the loading process must stand clear of the loading ramp.
- Avoid working alone. If an accident happens, an assistant can bring help.
- Keep work area well lighted.
- Dress properly. Do not wear loose clothing or jewelry as they can be caught in moving parts. Protective, electrically non conductive clothes and non skid footwear are recommended when working. Wear restrictive hair covering to contain long hair.
- Use eye and ear protection.
- Keep proper footing and balance at all times.
- Wear security gloves and shoes when handling the ramps.
- Only use the device for its intended purpose.
- Do not exceed the maximum capacity.
- Always be careful. Do not use the ramp if you are tired.
- Check the ramp for stress fractures and breakage before every use. All damaged parts must be replaced by a qualified technician.
- Only use original spare parts to replace parts or accessories.
- Only use spare parts that are meant to be used with this device.
- For your own safety, have the device maintained by a qualified technician.
- All loading and unloading must be done on a flat, level, dry surface. Make sure the flange faces down and the tongue edge fully contacts the tailgate or bed of vehicle.
- This is not a toy, keep away from children.
- Do not exceed maximum weight limit (200kg per ramp).

Please read the instructions carefully and keep for future use.

2.