Weems & Plath[®]

INNOVATION ROOTED IN TRADITION

QUARTZ SHIP'S BELL CLOCK

Two Year (2) Warranty

214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA 410-263-6700 • fax 410-268-8713 E-mail: support@weems-plath.com www.Weems-Plath.com

TO INSERT BATTERY & SET TIME

- 1) Access clock movement. If case has screw-on type bezel, simply unscrew bezel. The movement will lift out. If case has a hinge type of bezel, unscrew latch and open bezel. The back of the movement will be exposed.
- 2) Follow diagram on battery housing and insert one AA Lithium battery making certain battery is not installed backwards.
- 3) To set the time, advance hour and minute hands by turning the knob on the back of the movement counter-clockwise. To reverse, turn clockwise. Note: Do not move hands manually. Bells are turned off when the clock leaves Weems & Plath. Keep them off when setting the time.
- 4) If clock stops due to a dead battery or if the clock is left unattended for long periods of time, remove the battery immediately as it will leak acid causing damage to the movement which will void warranty.*

 *Movement damage caused by battery leakage will void the warranty. We recommend replacing the batteries at the beginning or end of Daylight Savings.

To Operate The Ship's Bells:

Locate the switch (green) with bell symbol on the side of the movement. When viewing the movement from behind, slide the switch to the right to activate the chimes and to the left to silence them. The bell icon is visible when the chimes are turned on. The chiming sequence is regulated automatically within the movement.

TROUBLE SHOOTING

Clock stopped or is not keeping proper time:

- A. Remove battery and inspect battery contact points, remove corrosion if present. Follow diagram on battery housing to make certain battery is installed properly. Install fresh AA Lithium battery. Set time.
- B. Remove battery and return for service**

**When returning for service, package carefully as Weems & Plath® cannot be responsible for damage in transit. Create an account on the Weems & Plath website to complete the Repair Request Form, then print the confirmation email and include it with your instrument when shipping it to:

Send To:

WEEMS & PLATH 214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA

Product Registration:

In order to provide the best service possible, please register your product online at www.Weems-Plath.com. Your registration serves as proof of purchase and activates your warranty.