




Touchscreen Controller User Guide

Pairing

Pairing Massage Chair Via Bluetooth

You must first pair the massage chair with the Touchscreen Controller before you can use it.




Pairing Massage Chair

- ① Turn on the Touchscreen Controller. On the Home Screen tap "Pair Chair".
- ② Select your massage chair and tap to pair.

Status Bar


The icons in the status bar at the top of the screen give information about the Touchscreen Controller.



Home Screen

Home Screen may vary depending on the task you're performing.

swipe
to switch



Menu

Status Bar

The icons in the status bar at the top of the screen give information about the Touchscreen Controller.
Some icons are available for operation.

Battery

This icon shows the battery level or charging status.



Message Chair Status


This icon shows message chair status.

Home Screen


Home Screen may vary depending on the task you're performing.

(Massage chair connection/Recommendations/Running message program controls)

Screen frame is highlighted when task is active.



No Massage Chair Connection
Tap Pair Chair to connect massage chair.




Massage Chair Connected
Recommendations show on display screen.
Tap the program you like to start massage.
Tap Power icon to turn on/off massage chair.

Home Screen

Home Screen may vary depending on the task you're performing.

(Massage chair connection/Recommendations/Running massage program controls)


Screen frame is highlighted when task is active.




Massage Program Running

Home screen shows status of current massage session.

Tap to stop/pause the massage session.



Body Scan



Reset

M e n u

Function Menu

Massage programs/Message chair adjustment/Settings




Auto Massage Programs



Tap the **auto massage program** you like to start, tap the “◀/▶” icon at both sides of the screen to scroll.

Go to Auto Massage Programs



Method 1



Press the Power/sleep button to turn on the Touchscreen Controller (verify that it is connected to the massage chair).

→

There are 3 featured auto massage programs on Home screen.

→

Tap the program you like to start.



Method 2

Press the Power/sleep button to turn on the Touchscreen Controller (verify that it is connected to the massage chair).

→

Swipe left on Home screen to go to Menu screen.

→

Tap the Auto icon on Menu screen to go to Auto screen.

→

You may choose among 12 pre-set Auto wellness massage programs. Tap the “◀/▶” icon at both sides of the screen to scroll.

→

Tap the program you like to start.

M e n u

Function Menu

Massage programs/Message chair adjustment/Settings




Manual Massage



Tap the massage technique and the way you like to start, you can adjust the [manual massage settings](#) during the massage session.

Go to Manual Massage



Press the Power/sleep button to turn on the Touchscreen Controller (verify that it is connected to the massage chair).

→

Swipe left on Home screen to go to Menu screen.

→

Tap the Manual icon on Menu screen to go to Manual screen.

→

You can choose the massage Technique you like, and set the massage Part, Width, 3D Strength and Speed.

About Manual Massage



Techniques Kneading, Tapping, Shiatsu, Sync, Knocking and 3D Shiatsu.
Tap the icon to start.

Part Whole, Partial and Point.

When Point massage is working, Point focus icon will show on the screen.

Tap and hold the icon to adjust the massage focus you desire.

Width Wide, Medium and Narrow.

3D Strength 5 levels and Off (turn off 3D Strength).

Speed 6 levels.

Speed is not adjustable if Shiatsu or 3D Shiatsu massage is selected. (🚫)

M e n u

Function Menu

Massage programs/Message chair adjustment/Settings





Options



This page shows [Airbags](#), [Back Heat](#), [Leg Heat](#) options, you can adjust the Options settings during the massage session.

Go to Options



Press the Power/sleep button to turn on the Touchscreen Controller (verify that it is connected to the massage chair).

→

Swipe left on Home screen to go to Menu screen.

→

Tap the Options icon on Menu screen to go to Options screen.

→

You can choose Airbags, Air Strength, Foot Rollers, Back Heat and Leg Heat.

About Options



Airbags Full, Back, Legs, Shoulders and Hips.

Tap the icon to start.

Air Strength 5 levels and Off (turn off Air Strength).

Foot Rollers 3 levels and Off (turn off Foot Rollers).

This option is not adjustable if Full or Legs Airbags is selected.

Back Heat 3 levels and Off (turn off Back Heat).

Leg Heat 3 levels and Off (turn off Leg Heat).

M e n u

Function Menu

Message programs/Message chair adjustment/Settings




Adjustments



You can adjust Zero Gravity, Message Time, Back Recline/Legs Up-/Down/Extend/Retract in Adjustments.

Go to Adjustments



Press the Power/sleep button to turn on the Touchscreen Controller (verify that it is connected to the massage chair).

→

Swipe left on Home screen to go to Menu screen.

→

Tap the Adjustments icon on Menu screen to go to Adjustments screen.

→

You can adjust

Zero Gravity, Massage Time, Recline, Legs, Knees and Feet.

About Adjustments



Zero Gravity Zero 1, Zero 2, and Off (turn off Zero Gravity).

Tap the icon to start.

Massage Time 10mins, 20mins and 30mins.

Recline Tap and hold the icon to recline/incline the massage chair back.

Legs Tap and hold the icon to lift/lower the massage chair footrest.

Knees Tap and hold the icon to move the upper part of legrest up/down.

Feet Tap and hold the icon to extend/retract the the footrest.


M e n u

Function Menu

Massage programs/Message chair adjustment/Settings



Settings



You can check Connection, Sounds, Screen Brightness, Help, Language, User Guide and About in Settings.

About Settings



Connection



Sounds



Screen Brightness



Help



Language



User Guide



About



Thank you

Have a great message