

PREPARATION

NOTE:

Before beginning assembly of product, make sure all parts are present. Compare parts with parts list. If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 30-60 minute

Recommended to be installed 2.5m (8.2ft) above the ground but not higher than 5m (16.4ft).

Product appearance may vary from image shown.

TOOLS REQUIRED (not included)



WARNING:


THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

CAUTION:


PLEASE MAKE SURE YOUR WALL SWITCH AND POWER AT MAIN CIRCUIT BREAKER BOTH ARE OFF.

IF IN DOUBT ABOUT ELECTRICAL INSTALLATION, CONSULT A LICENSED ELECTRICIAN. CE

13



16



RISK OF SHOCK:

BEFORE BEGINNING INSTALLATION. TURN OFF ELECTRICITY AT THE CIRCUIT BREAKER BOX OR THE MAIN FUSE BOX.

NOTE:

BE SURE TO USE WIRE NUTS/CONNECTORS RATED FOR THE CORRECT GAUGE AND NUMBER OF WIRES USED.

MAKE SURE THERE ARE NO EXPOSED WIRE BUNDLES OUTSIDE THE WIRE NUT/CONNECTOR (IF APPLICABLE).

BE CAREFUL NOT TO DAMAGE OR CUT THE WIRE INSULA-TION (COVERING) DURING INSTALLATION. DO NOT LET THE WIRES TOUCH ANY SHARP EDGES.

WARNING:

TROUBLESHOOTING

Malfunction

ent, the light

LED senses a

does not light up

DO NOT CONNECT THIS LIGHT FIXTURE TO AN UNGROUNDED ELECTRICAL SYSTEM. ATTACH GROUND FIXTURE WIRE TO EITHER GREEN GROUND SCREW ON MOUNTING PLATE OR THE GROUND WIRE IN THE OUTLET BOX.

INSTALLING THIS LIGHT IN AN UNGROUNDED ELECTRICAL SYSTEM MAY CAUSE THE METAL PARTS OF THE LIGHT TO CARRY CURRENT IF ANY WIRES OR WIRE CONNECTIONS ARE DAMAGED OR LOOSE. IN THIS CASE, ANYONE WHO TOUCHES THE LIGHT WILL RECEIVE AN ELECTRIC SHOCK, RESULTING IN INJURY OR DEATH.


14

Cause

. The light is not energized

2. Other surrounding light

sources make the light



FCC ID: 2A3W8BDB55WF-3

FCC Warning:

Œ

Remedv

. Turn off the nearby lights or


sensor head to other directions

Check power-on status

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipm This device complies with part 15 of the FCC Rules. Operation is subject to the following two

conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause



The raised part (RA) of the metal plate must be engaged with the recessed part (RE) of the base, otherwise it cannot be installed.

The 5 heads of the lamp can be adjusted to the angle you want.

CE

LED sensor light did not go out, continued to light upContinuous movement within the sensing rangeCheck the relevant area and retune or override the sensor head if necessaryLED sensor light illuminates during the dayThe shadows around the sensor make it mistakenly think it's night1. Do not cover the sensor head 2. Place the light in a place where the light is bright enough during the dayLED sensor light flashingSurrounded by other unstable light sources shining onto the inductionAvoid being exposed to such light sourcesLED lights turn on unexpectedly1. Wind blows the branches and bushes within the sensing range 2. Sensing cars on the road 3. Sudden temperature change due to climate factors or fans, exhaust from open windows1. Adjust its scope 3. Change irradiation area	misjudge it as daytime 3. During the day, the brightness is in night mode 4. Internal wiring is loose	 Reset Rewiring after power failure
illuminates during the day sensor make it mistakenly think it's night 2. Place the light in a place where the light is bright enough during the day LED sensor light flashing Surrounded by other unstable light sources shining onto the induction Avoid being exposed to such light sources LED lights turn on unexpectedly 1. Wind blows the branches 		retune or override the sensor
flashing light sources shining onto the induction such light sources LED lights turn on unexpectedly 1. Wind blows the branches and bushes within the sensing range 1. Adjust its scope 2. Sensing cars on the road 3. Sudden temperature change due to climate factors or fans, 3. Change irradiation area	sensor make it mistakenly	2. Place the light in a place where the light is bright enough during
unexpectedly and bushes within the sensing range 2. Sensing cars on the road 3. Sudden temperature change due to climate factors or fans,	light sources shining onto the	
	and bushes within the sensing range 2. Sensing cars on the road 3. Sudden temperature change due to climate factors or fans,	2. Adjust its scope
		brightness is in night mode 4. Internal wiring is loose Continuous movement within the sensing range The shadows around the sensor make it mistakenly think it's night Surrounded by other unstable light sources shining onto the induction 1. Wind blows the branches and bushes within the sensing range 2. Sensing cars on the road 3. Sudden temperature change due to climate factors or fans,

17

undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. HK Bright International Lighting Co., Limited Unit 616, 6/F., Kam Teem Industrial Building, 135 Connaught Road West, Sai Wan Hong Kong Manufacturer/Hersteller: MDH LIGHTING LTD Suite 302, 292 Strovolos Avenue, 2048 Stro ovolos Nicosia

Cyprus UK Importer: MDH LIGHTING LTD 69 Aberdeen Avenue, Cambridge CB2 8DL, United Kingdom

Made in China

CE

Support@onforuled.com

