
# **PARTS IDENTIFICATION**










# **IMPORTANT!**

Please read this instruction **Prior** to installation





## **INSTALLATION**



## **BODY INSTALLATION -**

- 1. Flush the pipe work thoroughly prior to installation.
- 2.Leave plastic cover in place and secure the body to the supporting timber noggin ensuring that it is orientated square and vertical
- 3. Connect Hot + Cold water supply and outlet to the concealed valve
- 4. Pressure test for leaks
- 5. Sheet the wall using water resistant board or equivalent. Please refer to diagram above.

## **COVER PLATE INSTALLATION -**

- 1. Once tiling is complete remove the plastic cover from the body sleeve
- 2. Apply silicone to the back of the cover plate (Part 6) and slide over body flange (Part 8) creating a seal from the cover plate to the finished wall .
- 3. Push Handle (Part 3) over Cartridge adaption and tighten grub screw (Part 2) firmly
- 4. Screw Pin Lever (Part 1) into the handle housing and tighten firmly.

**NOTE**- It is the responsibility of the installer to ensure a waterproof seal is achieved between the product and mounting surface. If in doubt about the quality of the seal, remove the product and re-install

## IMPORTANT RECOMMENDATIONS FOR INSTALLATION

Installation should comply to AS/NZS3500.1 2003 or relevant local requirement. Not suitable for gravity feed application.

Hot & cold water inlet pressures should be equal.



#### WATER PRESSURE

Operating static pressure is 150 - 500kpa. If pressure exceeds this, then an approved pressure limiting valve must be installed.



### PRE-FLUSH

Always flush out the pipework before connecting any faucets. Damage caused to the faucet by debris coming through the pipework is not covered under warranty.



#### WATER TEMPERATURE

Maximum hot water temperature is 75 degree.



## **ATTENTION!**

Failure to do so will void the warranty.