

# **Instructions:**

#### PLANT MONITOR - ARDUINO



Instructions version 1b.

## TABLE OF CONTENTS

Warning	2
Introduction	
Using the Plant Monitor	4
Arduino	5
Troubleshooting	9
Support	
MonkMakes	.10

## WARNING

Only the prong of the Plant Monitor below the white line should be allowed to get wet. If the top of the board gets wet, disconnect it from everything, dry it using a paper towel and then leave it the throughly dry out before trying to use it again.

## INTRODUCTION

The MonkMakes Plant Monitor measures soil moisture, temperature and relative humidity. This board is compatible with the BBC micro:bit, Raspberry Pi and most microcontroller boards.

- Superior capacitative sensor (no electrical contact with soil)
- Alligator / crocodile clip rings (for use with BBC micro:bit and Adafruit Clue etc.
- Ready soldered header pins for Arduino and other microcontroller boards.
- Easy to use UART serial interface
- Additional analog output for moisture only
- Built-in RGB LED (switchable)





## USING THE PLANT MONITOR

The plant monitor should be placed as shown below.



The front side of the prong should be as close to the edge of the pot as possible. The sensing all takes place from the far side of the prong.

The electronics should be facing out of the pot and the prong of the Plant Monitor pushed into the dirt as far as the white line (but no deeper).

It's a good idea to attach the wires you are going to use to connect to the Plant Monitor before positioning it in the plant pot.

Once powered up, the plant monitor will immediately start displaying the level of wetness using the builtin LED. Red means dry, green means wet. Before you put the Plant Monitor in the pot, try gripping the prong in your hand and the moisture of your body should be enough to alter the LED's color.

## ARDUINO

Warning: The Plant Monitor is designed to operate at 3.3V, not the 5V that some Arduinos such as the Arduino Uno operate at. So, never power the Plant Monitor with 5V and make sure that none of it's input pins receive more than 3.3V.

To connect a 5V Arduino, such as the Arduino Uno or Leonardo you will need to use a level converter or a (as we have here) a  $1k\Omega$  resistor to limit the current flowing from the 5V Soft Serial transmit pin of the Arduino (pin 11) to the 3.3V RX\_IN pin of the Plant Monitor.

Here's what this looks like, solderless breadboard is used to hold the resistor (in the middle of the breadboard), male to male jumper wires to connect the the Arduino to the breadboard and female to male jumper wires to connect the Plant Monitor to the breadboard. The connections are as follows:

- GND on the Arduino to GND on the Plant Monitor
- 3V on the Arduino to 3V on the Plant Monitor
- Pin 10 on the Arduino to TX\_OUT on the Plant Monitor
- Pin 11 on the Arduino to RX\_IN on the Plant Monitor via a 1kΩ resistor. Note that the resistor is not needed for a 3V Arduino.



Once its all connected, you can install the Arduino library for the PlantMonitor by going to https://github.com/monkmakes/mm\_plant\_monitor and the from the Code menu, select Download ZIP.

Public		
<> Code	17 Pull requests 🕑 Actions 🖽 Projects	🗇 Wiki 🛈 Security 🗠 Insights 🕠
얀 main ▾	Go to file Add file -	Code - About
simonmonk initial	leat 🖸 Clone	An Arduino library for the MonkMakes Plant Monitor
examples/simple	INI HTTPS SSH GitHub CLI	🛱 Readme
.gitignore	ini https://github.com/monkmakes/mm_plant_	□ MIT license
LICENSE	Use Git or checkout with SVN using the web URL.	<ul><li>☆ 0 stars</li><li>⊙ 2 watching</li></ul>
PlantMonitor.cpp	ini (낮) Open with GitHub Desktop	양 0 forks
PlantMonitor.h	ini	
README.md	int Download ZIP	Releases

Now open the Arduino IDE and from the Sketch menu select the option to Add .ZIP Library and navigate to the ZIP file you just downloaded.

🗯 Arduino	File	Edit	Sketch	Tools	Help		
•••		sim	Verify/	Compile		ЖR	Manage Libraries
			Upload		жU		
		Upload Using Programmer			Add .ZIP Library		
simple				compile	d Binary	ζ₩S	Arduino libraries
1 #include "Plan	ntMoni	tor.h"	Show	Sketch F	older	ЖК	Bridge
2 3 PlantMonitor pm = PlantMo 4		Include Library				Esplora	
		Add Fi	e			Ethernet	
5 void setup() ·							Firmata
6 Serial.begin	1(9600	));					GSM
7 }							Keyboard

As well as installing the library, this will also fetch an example program that you will find in the Examples sub-menu of the File menu, under the category Examples from Custom Libraries.

🗯 Arduino	File Edit Ske	tch Too	s Help	👱 🤯 📚 🔺 🛋
simple	New Open Open Recent Sketchbook	#N #O ►	Grove - RTC DS1307 GXEPD ITEADLIB Arduino WeeESP8266-master	
1 #include "Pla 2 3 PlantMonitor 4 5 void setup()	Examples Close Save Save As	► 業W 業S 企業S	Lona Microchip_EEPROM-master	
6 Serial.begi 7 } 8 yoid loop() {	Page Setup Print	分 業 P 業 P	mm_plant_monitor-main MMA8653 MySensors	simple
	<pre>vailable()) {</pre>		NeoPixelBus by Makuna NewliquidCrystal	►

Upload the example called *Simple* to your Arduino and then open the Serial Monitor. Here, you will see a series of readings. You can also turn the Plant Monitor's LED on and off from the Serial Monitor by sending serial commands. Type L in the send area of the Serial Monitor and then press the Send button to turn the LED on, and I (lower-case L) to turn the LED off.

\varTheta 🕘 🔵 /de	ev/cu.usbmodem141201
	Send
werness: ω temp (L): 24.10 numiaity: 27.55	
Vetness: 0 temp (C): 24.18 humidity: 27.32	
Vetness: 0 temp (C): 24.17 humidity: 27.35	
Vetness: 0 temp (C): 24.17 humidity: 27.34	
Vetness: 0 temp (C): 24.17 humidity: 27.34	
Vetness: 0 temp (C): 24.17 humidity: 27.33	
Vetness: 0 temp (C): 24.18 humidity: 27.32	
Vetness: 0 temp (C): 24.15 humidity: 27.29	
Vetness: 0 temp (C): 24.16 humidity: 27.28	
Vetness: 42 temp (C): 24.15 humidity: 27.29	
Vetness: 42 temp (C): 24.14 humidity: 27.27	
Vetness: 48 temp (C): 24.14 humidity: 27.28	
Vetness: 48 temp (C): 24.14 humidity: 27.24	
Wetness: 52 temp (C): 24.12 humidity: 27.28	
🗹 Autoscroll 📃 Show timestamp	No line ending ᅌ 9600 baud ᅌ Clear outpu

Here is the code for this example:

```
#include "PlantMonitor.h"
PlantMonitor pm = PlantMonitor(10, 11); // RX, TX
void setup() {
   Serial.begin(9600);
}
void loop() {
   if (Serial.available()) {
     char cmd = Serial.read();
     if (cmd == 'l') {
        pm.ledOff();
     }
}
```

```
else if (cmd == 'L') {
    pm.ledOn();
    }
    report();
    delay(1000);
}
void report() {
    Serial.print("Wetness: ");
    Serial.print(pm.getWater());
    Serial.print(" temp (C): ");
    Serial.print(" humidity: ");
    Serial.print(" humidity: ");
    Serial.println(pm.getHumidity());
}
```

The library uses another Arduino library called <code>SoftSerial</code> to communicate with the Plant Monitor. This can carry out serial communication on any of the Arduino pins. So, when an instance of <code>PlantMonitor</code> called <code>pm</code> is created, the pins to be used to communicate to the Plant Monitor hardware are specified (in this case, 10 and 11). If you like, you can change 10 and 11 for other pins.

The main loop checks for incoming messages of *L* or *I* from you to turn the LED on or off respectively, using the pm.ledOn or pm.ledOff commands.

Getting readings from the PlantMonitor all takes place in the report function that writes out all the readings to the Arduino IDE's Serial Monitor.

#### TROUBLESHOOTING

**Problem:** When I first connect power to the PlantMonitor, the LED cycles through colors. Is this normal?

Solution: Yes, this is the Plant Monitor doing a self-test as it starts up.

Problem: The LED on the Plant Monitor does not light at all.

**Solution:** Check the power connections to the Plant Monitor. Alligator leads and jumper wires can become faulty. Try changing the leads.

**Problem:** I am connecting using the serial interface, and I get wetness readings, but the humidity and temperature readings are wrong and not changing.

**Solution:** You may have inadvertently powered your Plant Monitor from 5V rather than 3V. This may have destroyed the temperature and humidity sensor.

## SUPPORT

You can find the Product's information page here: https://monkmakes.com/pmon including a datasheet for the product.

If you need further support, please email <a href="mailto:support@monkmakes.com">support@monkmakes.com</a>.

# MonkMakes

As well as this kit, MonkMakes makes all sorts of kits and gadgets to help with your electronics projects. Find out more, as well as where to buy here: <u>https://monkmakes.com</u> you can also follow MonkMakes on Twitter @monkmakes.

