


AUTOMATIC WATCH


When a watch is first purchased or if the second marker (second hand) have stopped moving, it is a good idea to gently wind the mainspring to restart, and put energy on the mainspring. An automatic watch will only wind when the watch is on your wrist and your arm moves. This is also advisable before setting the time on your watch.

To wind an automatic watch - without pulling the crown out, hand wind the mainspring by simply turning the crown clockwise in the "0" position. Wind 15-20 times, and the second marker will start to move naturally after shaking slightly.



This watch MUST be worn for at least 8 (Eight) hours each day to ensure it is fully wound.

AUTOMATIC 3 DISC MARKERS




If the second marker is not moving, it is advisable to wind your watch before setting the time. To learn more, go to "**AUTOMATIC WATCH**" page.

TIME SETTING


1. Pull out the crown to position 2.
2. Turn the crown clockwise to set the hour marker.
3. Then turn the crown to set the minute.
4. Push the crown back in.

TIME READING EXAMPLES


TIME: 12:59



TIME: 1:00



TIME: 5:30



TIME: 2:28

