

READ AND SAVE THESE INSTRUCTIONS!

- ALWAYS place the humidifier in an area that is out of the reach of children.
- Before using the humidifier, extend the cord and inspect for any signs of damage. DO NOT use the product if the cord has been damaged.
- ALWAYS UNPLUG AND EMPTY the humidifier when it is not in operation or while it is being cleaned.
- DO NOT use water bottles greater than 22oz.
- This product is intended for residential use only. DO NOT use outdoors.

Initial Setup:

- 1. Unravel and straighten the cord before use.
- 2. Set the unit on a flat, waterproof surface.
- 3. Remove the top cap from the reservoir cover. Place the reservoir cover back onto the base. (Figure 1)
- 4. Use the bottle cap that came with your humidifier and screw it onto the mouth of the water bottle firmly. (Figure 2)



Figure 1



Figure 2



Figure 3

5. Turn your water bottle upside down and insert into the water reservoir. (Figure 3)

Note: Failure to ensure the water bottle is seated correctly could cause the unit to leak water from the tank

6. Insert the power adapter into the bottom right side of the unit, then plug the adapter into a wall outlet. (Figure 4)

Operation:

Figure 4

- 1. To turn the humidifier ON, press the "MIST" button. This will adjust the mist output to High, Medium, Low and Off. The indicator lights on the control panel will indicate the humidity level selected.
- 2. To turn the humidifier OFF, pressing the "Mist" button until the indicator lights turn off.
- 3. To turn the color changing LED light on, press the "LIGHT" button. Press the button again at the desired light color to set to that color. To turn the LED light off, pressing the "LIGHT" button until the light turn off. (Figure 5)





Figure 5

Maintenance:

- 1. Turn off the humidifier and unplug the power adapter from the wall and the unit.
- 2. Remove the water bottle from the unit and remove the bottle cap.
- 3. Empty the water from the bottle.
- 4. Rinse the bottle cap thoroughly with warm water. Replace the water bottle if necessary.
- Remove the reservoir cover from the humidifier and empty any remaining water.
- 6. Wipe any mineral deposits from the cover and base with a soft cloth.
- 7. Replace the cover onto the base. Align notch on the cover with the groove on the base. The mist exhaust should be 45° to the left of the control panel. (Figure 6)



Figure 6



20307-01 20160730

Troubleshooting:

Problem:

Humidifier is not working.

Solution:

- Make sure the indicator lights for mist output on control panel are not turn off.
- 2. Ensure the power adapter is firmly plugged into the unit.

Problem:

Humidity output and water usage decreased.

Solution:

- 1. Check the "MIST" button to make sure it is set to the desired humidity level and speed.
- 2. Check the water bottle to make sure there are no bubbles when the water bottle is full and running. If there are bubbles, turn the unit OFF until the bubbling stops. When the bubbling has stopped, set the unit to the desired speed.
- 3. Clean any components that have mineral built-up.

Technical Support

If you need any assistance with setup, operation, or parts for your new hunter Humidifier, please call us, our technical support staff is ready to help!

USA:1-888-880-3267

We open 24 hours a day, 7 days a week. You may also reach us online at www.HunterHomeComfort.com. An electronic copy of this user manual can also be obtained online at www.HunterHomeComfort.com.

Limited 1 Year Warranty

Hunter Home Comfort makes the following warranty to the original residential user or consumer purchaser of the ultrasonic humidifer:

If any part of the ultrasonic humidifier fails during the first year from the date of purchase due to a defect in material or workmanship, we will provide a replacement part free of charge.

If no replacement part can be provided, we will replace your Humidifier.

ITINITIATION
IF THE ORIGINAL RESIDENTIAL USER OR CONSUMER
PURCHASER CEASES TO OWN THE ULTRASONIC
HUMIDIFIER, THIS WARRANTY AND ANY IMPLIED
WARRANTY WHICH THEN REMAINS IN EFFECT, INCLUDING
BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF
MERCHANTABILITY OR FITNESS FOR A PARTICULAR
PURPOSE, ARE VOIDED. THIS WARRANTY IS IN LIEU OF ALL
OTHER EXPRESS WARRANTIES. THE DURATION OF ANY
IMPLIED WARRANTY, INCLUDING BUT NOT LIMITED TO ANY
IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS
FOR A PARTICULAR PURPOSE IS EXPRESSLY LIMITED TO THE
PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE.
This warranty is voided if your ultrasonic humidifier is not
purchased and used in the USA.

This warranty excludes and does not cover defects, malfunctions, or failures of the humidifier which were caused by repairs by persons not authorized by us, use of parts, or accessories not authorized by us, mishandling, modifications, or damage to the humidifier while in your possession, or unreasonable use, including failure to provide reasonable and necessary maintenance. This warranty does not cover humidifiers used in commercial applications. There are no express or implied warranties as to commercial purchasers or users.

To obtain servicing, contact the nearest Hunter authorized service center or the Hunter Home Comfort Service Department, 1831-A West Oak Parkway, Marietta, GA30062. You will be responsible for insurance and freight or other transportation to our factory service center. We will return the humidifier freight prepaid to you. The humidifier should be properly packaged to avoid damage in transit since we will not be responsible for any such damage. Proof of purchase is required when requesting warranty service. The purchaser must present the sales receipt or other document that establishes proof of purchase.

IN NO EVENT SHALL HUNTER HOME COMFORT BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE HUMIDIFIER. YOUR SOLE REMEDY WILL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. SOME AMERICAN STATES DO NOT ALLOW:

- LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS:
- THE EXCLUSION OR LIMITATION OF DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES;
- THE EXCLUSION OR INVALIDITY OF EXPRESS OR IMPLIED WARRANTIES IF THE USER CEASES TO OWN THE HUMIDIFIER;
- THE LIMITATION OF THE REMEDIES AND RECOURSES AVAILABLE TO THE PURCHASER; OR THE INVALIDITY OF AN EXPRESS WARRANTY WHEN A PRODUCT IDENTIFIED BY BRAND NAME IS NOT USED (UNLESS SPECIFIC CONDITIONS ARE FULFILLED);

SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.



1831-A West Oak Parkway, Marietta, GA30062 Hunter is a trademark of the Hunter Fan Company and is used under license to Hunter Home Comfort.

20307-01 20160730