

VOYAGER
ELECTRIC SCOOTER

DASH CHARGE
COMMUTER

BC



ITEM NUMBER | SCOT-1060D

USER'S MANUAL

SAFETY PRECAUTIONS

When using your Voyager Dash Charge Commuter Electric Scooter, the following basic safety precautions should always be adhered to:

BEFORE RIDING

1. READ ALL INSTRUCTIONS BEFORE USING YOUR SCOOTER.
2. Your scooter is designed to be used by adults, age 14 and older.
3. Do not ride scooter in temperatures below 30°F.
4. Do not let children use your scooter.
5. Never immerse the scooter in water.
6. Do not leave the scooter in high temperatures.
7. Make sure to wear a helmet and other protective gear when riding your scooter, making sure to comply with the laws of your local municipality.
8. Do not ride your scooter with any loose clothing that can get caught in the wheels.
9. Do not expose your scooter's battery to liquid or moisture. Similarly, do not expose your scooter or its battery to excessive heat or fire.
10. When charging the battery, only use the supplied charging cable included with your scooter.
12. Connect all wires properly, making sure they are not entangled.
13. Do not ride your scooter if you notice any defects or irregularities. Contact the manufacturer or a certified technician immediately for support.

WHILE RIDING

1. When riding your scooter, make sure to always follow all traffic and safety rules based on the laws of your local municipality.
2. Do not ride your scooter while under the influence of any alcohol, medication or other substance which can cause impairment.
3. Do not attempt to do any tricks while riding your scooter. Furthermore, do not ride your scooter over rough terrain, icy roads, or uneven surfaces.
4. Ride carefully. Avoid applying the breaks abruptly.
5. Practice riding in spacious areas at low speeds until you become more experienced and comfortable with higher speeds.
6. Do not allow your scooter to be dragged by cars or bikes. Do not use your scooters on escalators or in crowded areas.
7. Do not use your scooter at night or in areas of low visibility.
8. Always power off your scooter when it is not in use.
9. Never allow more than one person on the scooter at a time.
10. Do not ride your scooter near stairs or bodies of water.

INTRODUCTION

Thank you for purchasing your new Voyager Dash Charge Commuter Electric Scooter and welcome to the Voyager family. We hope that you'll do plenty of exploring on your new scooter. Please enjoy your new scooter responsibly and be sure to read the entire instruction manual before your first use. Have a blast, be safe and Get Moving!


SPECIFICATIONS

- Battery Type: Rechargeable 36v 18650 Lithium Battery
- Motor Power: 300W
- Max Mileage: 13 miles
- Waterproof IP54
- Charger: 100-240V; 50-60Hz
- Charge Time: ~5.5 Hours
- Net Weight: 28 Pounds
- Max Rider Capacity: 265 Pounds
- Recommended For Ages: 14+
- Solid Tire Size: 8 Inches
- Dimensions (l/w/h): Folded 50 inches/14.5 inches/13.5 inches

IN THE BOX

- Voyager Dash Charge Commuter Electric Scooter
- Charging Adapter
- User's Manual with Warranty Information


YOUR SCOOTER



UNFOLDING



Step 1: Open the package and take out the scooter and its parts.



Step 2: Push down on the folding button.



Step 3: Pull the handlebar stem all the way up until it holds securely in place.

CHARGING YOUR SCOOTER

Before riding your scooter, please make sure that the battery is fully charged. In order to charge your scooter's battery, follow the steps below:

Step 1.

Pull the rubber cover off of your scooter's charging port.

Step 2.

Connect one end of the include charging adapter into the charging port on your scooter. Plug the other end into a suitable power outlet in your home.

Step 3.

While your scooter's battery is charging, the LED light on the charging adapter will turn red. Once fully charged, the LED light will turn green.

Step 4.

Unplug the charging adapter once charging is complete, and then put the rubber cover back on the charging port.

NOTE:

Charging takes approximately 4-5 hours to complete. To extend the lifespan of the scooter's battery, make sure to charge it at least once every 20-30 days.

Your scooter's brake light is power by a separate 3V CR1632 button cell lithium battery. This battery can be replaced periodically when your brake light stops powering on.



SCOOTER CONTROLS



THROTTLE: On the right handlebar is the throttle apparatus. Press it down to accelerate.

BRAKING: On the left handlebar is the brake. Press it to stop the scooter. For a sudden stop, while pressing the handlebar brake, also press the rear brake pedal.


CRUISE CONTROL: Ride the e-scooter at a constant speed for more than six seconds to enter cruise mode. Without pressing the throttle button, the scooter will stay at current riding speed. If you press the throttle or brake the scooter will exit cruise mode.

LIGHTS: With your scooter powered on, tap the power button to turn the front headlight on or off.

POWER LEVEL INDICATOR: After the scooter is powered on, if the scooter's battery capacity is over 50%, the LED indicator light will turn blue. If the battery capacity is between 25-50%, the LED indicator will turn blue and blink repeatedly. If the battery capacity is less than 25%, the LED indicator will turn red.


GEARS: By default, the scooter has two gears (10MPH and 15.5MPH). After the scooter is powered on, press the power button twice to switch gears. The buzzer will beep two times if the gear has been switched successfully. The gear can also be switched using the App.

RIDING YOUR SCOOTER



STEP 1: POWERING ON

Press the power button located on the handlebar stem to power on your scooter. The button will illuminate once your scooter is powered on.



STEP 2: PUSHING OFF

Hold the handlebar with both hands and put one foot on the board. Use your other foot to push off.



STEP 1: ACCELERATING

As the scooter accelerates, keep both feet on the deck with one foot in front of the other. The foot that is in front should remain stationary, while the back foot can be used to kick your scooter forward and also to press on the brake pedal.

NOTE: *The color and design of your scooter may vary from the ones displayed in this user's manual.*

ATTACHING YOUR PHONE

Your scooter has a built-in mount for holding your smartphone.



The built-in mount can rotate or tilt forward or backwards, offering you different ways to view your phone's screen.

CHARGING YOUR PHONE

WIRELESS CHARGING:

The surface of your scooter's built-in mount has wireless charging capability. When your scooter is powered on, and a Qi compatible smartphone is placed in the mount, it will charge automatically.

WARNING: If you have a Qi compatible phone and it is not charging when placed in the mount, make sure there is nothing in between the phone and the charging surface.*



**USB PORT FOR
MOBILE CHARGING**


WIRED CHARGING:

If your phone does not have wireless charging capabilities, you can still use your scooter to charge your phone. To do so, power on your scooter, and then plug your phone into your scooter's USB charging port using your phone's charging cable.

***NOTE:** While wireless charging is supported with most phone cases, some thicker cases or cases with metal may not be compatible with wireless charging.

APP INSTALLATION

For a richer riding experience, download the Voyager App, which is available on the Google Play Store and on the iPhone App Store.



USING THE APP

You can use the Voyager app to take videos, plot a course of travel, or check your speed and remaining battery life.



Connect your scooter with your phone via Bluetooth in the settings menu.

You can also change the scooter's lighting settings as well as many other general settings here.



NOTE: Screen shots displayed in this user's guide may appear differently than those currently featured in your app as frequent updates and improvements are being made to the software.

FCC COMPLIANCE

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call (877) 444-0345 in the U.S. or visit our website at www.ridevoyager.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepai red.

VOYAGER
ELECTRIC SCOOTER