

# Weatherproof Digital 'Classic' Maximum/Minimum Thermometer

Robust digital max/min thermometer suitable for indoor or outdoor use.  
Triple display shows maximum, minimum and current temperature simultaneously.

## Product Specification:

**Measurement Range:** -20 to 50°C/°F (switchable)

**Ingress Protection:** IP66

**Accuracy:** +/-1°C

**Display Resolution:** Current temp: 0.1°C/0.1°F

Max/Min temp: 1.0°C/2.0°F

**Battery:** 1pc x AAA (included)

## Instructions:

- Remove tab protecting battery and protective film from LCD before use.
- This thermometer is weatherproof however, where possible, it should be positioned away from direct sunlight, rainfall and draughts to ensure an accurate reading and optimum life of instrument.
- The minimum reading indicates how low the temperature has dropped since last reset.
- The maximum reading indicates how high the temperature has risen since reset.
- To reset the readings, press the CLEAR button.
- To switch Celsius to Fahrenheit, press C/F button.


**Note:** Current temperature LCD reads "LL.L" at -20°C and "HH.H" at 49.9°C.

Allow instrument to acclimatise to working environment for one hour before taking temperature measurements

## To change battery:

Due to the IP rating of this thermometer, care should be taken when removing battery compartment cover. Partially unscrew battery compartment cover then place end of screwdriver under the screw to carefully lever compartment cover out.

Replace cover securely after changing battery.



Please dispose of electrical devices in accordance with local regulation

UK  
CA CE

Rev.2.2021

Measurement for Life.

Brannan

## Digital Max/Min Thermometers - FAQs

### Where is the best place to position my Digital Max/Min thermometer?

- Always position the thermometer out of direct sunlight to ensure accurate readings are displayed and to prolong the life of the product.
- Position the thermometer away from draughts to ensure an accurate reading is obtained.
- Position the thermometer away from direct rainfall to prolong the life of the product.

### Why is my Digital Max/Min thermometer reading higher than the actual temperature?

- This is likely due to the thermometer being positioned in direct sunlight. The sun's radiation causes the thermometer to read higher than the true temperature.
- Please ensure you keep your thermometer in the shade, away from direct sunlight.

### I bought 2 Digital Max Min thermometers but they both give different readings?

- All thermometers have an accuracy tolerance, and therefore there may be slightly different readings between different thermometers.
- For example, the true temperature may be 20.2°C and the thermometer accuracy may be +/-1°C. THERMOMETER 1 may read 19.2°C and THERMOMETER 2 may read 21.2°C. Although the thermometers read 2.0°C apart, they are both still within the accuracy specification.

### The Digital Max/Min thermometer displays a different reading to my old thermometer?

- As above, although the thermometers display different readings, they may both still be within the manufacturer's accuracy specification.
- Different style thermometers also have different response rates. Please allow both thermometers to acclimatise, untouched, for at least 1 hour and then compare the readings.

### The screen on my Digital Max/Min thermometer has died?

- As with all electronic products, if the thermometer is positioned in direct sunlight, the screen will become faint and eventually die.
- The screen will also die if water and/or moisture enters the internals of the thermometer.

### Water has entered my Digital Max/Min thermometer. I thought it was 'Weatherproof'?

- The weatherproof models are weatherproof to IP66, meaning they are protected from high pressure water jets from any direction.
- However, the product will not survive if fully submerged in water.

### How can I remove the battery cover on my Digital Max/Min thermometer?

- To ensure the products are weatherproof, the battery cover includes a waterproof seal. Care needs to be taken to avoid damaging this seal. Partially unscrew the battery cover, then place the end of the screwdriver under the screw to carefully lever the cover out.