

DGTPK

DGTPK: DIGITAL WEIGHT TRANSMITTER/INDICATOR WITH EXTENDED KEYBOARD



Multifunction weight transmitter for table or panel mounting. Ideal as a microcontroller in industrial weighing and dosage systems, making an easier and safer integration of the weighing to any automation system. Fitted with 4 inputs and 6 outputs, programmable. Numerical keyboard for the quick entry of the setpoint and the tare.

MAIN FEATURES

- 20-key numeric/functional waterproof keyboard: quick entry of the setpoints and the tare value.
- Highly efficient red LED display with 6 20-mm digits and 12 LEDs for showing active functions.
- Case for panel mounting. Front panel dimensions: 170x170mm.
- Drill template: 161x162mm.
- Fitted with bracket for use on table or wall mounting. A/D 24-bit sigma-delta conversion, up to 200 conv./sec. autoselect.
- Connectable with up to 16 analogue load cells with 350 Ohm input resistance.
- Up to 1.000.000 displayable divisions with internal resolution up to 3.000.000 points.
- Management of a digitally equalised 4-cell weighing system or management of 4 independent weighing systems.
- Calibration, Set-Up parameters, configurable from keyboard or from PC with DINITOOLS.
- Up to 8 signal linearization points with DINITOOLS (3 from keypad).
- Time/Date
- From 12 Vdc to 24 Vdc power supply.

MAIN CERTIFICATIONS

- EC Type Approval (EN45501)
- OIML R76
- OIML R61 MID

TRANSMITTER / INDICATOR: FUNCTIONS

• THROUGH KEYBOARD:

Zeroing; Semi automatic and presettable tare, print and/or data transmission; ON/Stand-by.

Quick entry of the setpoints and the tare values.

• SELECTABLE:

High Resolution Weighing x 10; Net/Gross or lb/kg conversion; Weighs totalisation; Formulation; Counting; In/Out Truck weighing; Hold e Peak.

• EXTERNAL INPUT:

Simulation of key pressure; Keyboard lock.

• MOSFET OUTPUT:

Set Point Control on the weight, either positive (in loading) or negative (in unloading), or on the pieces (counting mode), with programmable enabling/disabling thresholds, as direct check or upon weight stability.

• SERIAL PORTS:

On all models: Reading of the net, gross, and tare weights; Clearing; Semi automatic and presettable tare; Scale switch; Setting of outputs activation thresholds.

DGTPKV2 and DGTPKANV2 models: Reading of microvolts or ADC converter for all the channels; Message display; Printing; Setting of APW in counting mode; Simulation of key pressure; MODBUS serial protocol.

• THROUGH 16 bit ANALOGUE OUTPUT (DGTPKANV2):

Analogue output proportional to the net or gross weight, either positive (in loading) or negative (in unloading).

MASTER/REPEATER OPTION (MSTSLV code)

• Specific programme for use of the indicator as a universal weight repeater or as a multi-scale repeater (MASTER) in combination with DFW/DGT/MCW.

FUNCTIONING MODES:

- Multi-scale repeater (MASTER):
 function which allows to repeat up to 32 independent scales, with the possibility of managing their functions, or displaying and printing
 the sum of the weighs of all the scales.
- UNIVERSAL weight repeater: function which allows to repeat the weight of any scales, through the configuration of the input string.
- Click to learn more.

I/O SECTION

- 1 RS232/C or RS485 bidirectional port configurable for connection to PC or external units.
- 1 RS232/C bidirectional port configurable for connection to printer.
- PROFIBUS serial interface (DGTPKPBV2 model).
- 6 photomosfet outputs: 150 mA 48 Vac / 150 mA 60 Vdc (NO), with configurable functions.
- 4 optoisolator photocouplers inputs: 12÷24 Vdc, 5 mA min 20 mA max, with configurable functions.
- 16-bit analogue output (DGTPKANV2 model) 4-20mA / 0-5Vdc / 0-10Vdc at choice. Maximum load applicable on the output current: 3500hm. Minimum load applicable on the output voltage: 10k0hm.





DINI ARGEO FRANCE sarl Nogent-sur-Marne info.fr@diniargeo.com DINI ARGEO GMBH Sinsheim - Germany info.de@diniargeo.com

UK Ltd Taunton - United Kingdom info.uk@diniargeo.com

DINI ARGEO

DINI ARGEO WEIGHING INSTRUMENTS Ltd Shanghai - China info.cn@diniargeo.com DINI ARGEO WEIGHBRIDGES Calto (RO) – Italy info@diniargeo.com









HEAD OFFICE

Via Della Fisica, 20 41042 Spezzano di Fiorano Modena - Italy Tel. +39.0536 843418 Fax. +39.0536 843521 info@diniargeo.com

SERVICE ASSISTANCE

Via Dell'Elettronica, 15 41042 Spezzano di Fiorano Modena - Italy Tel. +39.0536 921784 Fax. +39.0536 926654 service@diniargeo.com

1	
-	
1	
i	
į	SALES AND TECHNICAL ASSISTANCE SERVICE
•	•