

## CryoSpa Sport: Basic Controls

- 1. At the front of the CryoSpa Sport, there is a control panel with 3 switches:
- a) An Isolation Switch [RED/YELLOW]
- >> Turn clockwise to Switch power ON the green light flashes
- >> Turn anti-clockwise to Switch power OFF
- b) A Chiller Button [GREEN]
- >> press to switch Chiller ON the green light goes solid
- >> press to switch Chiller OFF the green light flashes
- c) A Jet Pump Button [BLACK]
- >> press to switch Jet Pump (Massage Jets) ON
- >> press to switch Jet Pump OFF

[The Jet Pump should only be switches on when the CryoSpa Sport is in use.]

## Note:

The Jet Pump is on a timer and will switch itself OFF at the end of the Maximum Run Time (time to be agreed). It can be switched on immediately again.

2. At the front of the CryoSpa Sport, below the handrail, are two Air Inlets:

They should be unscrewed approximately 1 bis 1,5 cm which will mix the water with air.





## CryoSpa Sport: Basic Operation

- 1. Check CryoSpa Sport is filled with water to the water level marker [absolute minimum is above the level of the skim weir].
- 2. Check the Chlorine level before use [should be 1ppm] see Daily Maintenance Sheet.
- Switch on Power to Chiller Chiller Button on FRONT of CryoSpa

   Chiller display will light up [If not make sure ON/OFF switch on the Chiller is ON]
   If Chiller and Circulation Pump switch OFF after c10 seconds and the green light on the spa flashes, the flow switch has been activated.
- 4. Check SET Temperature at the Chiller.
- 5. Check water is returning to the CryoSpa Sport from the Chiller.
- 6. **Before** athletes enter the CryoSpa Sport **remove** floating dispenser [if any].
- 7. When the athlete enters the CryoSpa Sport turn ON Jet Pump.

  If the athlete doesn't tolerate the cold turn OFF Jet Pump and it feels less cold.
- 8. When the athlete exits the CryoSpa Sport turn OFF Jet Pump.
- 9. Clean the CryoSpa Sport per Daily Maintenance Sheet after each use.

