

mompush[®]

Designer style.
Unbeatable value.

 mompush_stroller  mompush_stroller

 support@mompush.com

www.mompush.com

mompush[®]

Stroller Manual

P689B



mompush®



Read me first

Before we start, there's a few important things you need to be aware of:

Safety first

The safety of your family is our number one priority. Please take the time to carefully read this manual and all warning notices on page 19-21 before getting started. Incorrect assembly or use can result in serious injury or even death.

⚠️ WARNING

To prevent injury from choking, carefully remove and immediately move out of reach all plastic packaging. Never leave your child unattended with the pram or packaging.

Return Policy

If you decide that the stroller is not the perfect one for you, we offer a Free Return Policy when returned in original condition and packaging (with no signs of usage). Please be mindful of this when unboxing and setting up. Refer to our website for full terms and conditions.

Support

If at any stage you require assistance with set up or use, please refer to our 'After Sales Support' page on our website. There, you'll find instructional videos and FAQ's. Or feel free to email us anytime at:

support@mompush.com

What's in the box

Please check that you have all the correct parts before getting started.



- 1 - Frame & basket
- 2 - Seat & harness covers
- 3 - 2x Rear wheels
- 4 - Napper bar
- 5 - 2x Front swivel wheels
- 6 - Brake bar
- 7 - Canopy
- 8 - Foot cover
- 9 - User manual
- 10 - Cup holder
- 11 - Rain Cover

Contents

- 04 What's in the box checklist
- 06 Step 1: **Setting up your frame**
- 08 Step 2: **Setting up your seat & canopy**
- 10 Using Stroller
- 10 Rear brake
- 10 Front swivel wheels
- 11 Seat recline
- 11 Adjusting the footrest
- 12 Safety harness
- 13 Canopy
- 13 Adjusting the handlebar
- 14 Folding the Stroller
- 15 Free accessories
- 16 Tips for maintaining your pram
- 17 Cleaning
- 18 Warranty
- 19 Safety warnings

Step 1 - Setting up your frame

- 1** To release the frame from the folded position, press the grey button on the right frame release lever, and pull both release levers back towards the handle.



- 2** To open, lift up and swing the lower section into place ensuring you hear it "click" into place.



- 3** Attach the brake bar to the rear of the frame. Push until you see the silver locking pins click into place.



- 4** To attach the rear wheels push each wheel pin into the sides of the brake bar until you hear a "click". Give them a tug to ensure they are attached securely.



- 5** Next, insert each front wheel pin into the centre of the socket ensuring you hear them "click" in. Give each wheel a firm tug to ensure they are secure.

**Now you can
set up the frame!**



Step 2 - Setting up your seat & canopy

- 1** Line up the seat connectors with the frame and press downwards. Listen for the 'click' and ensure it is securely locked in place.



- 2** To recline the seat, lift the seat recline latch located at the canopy end of the frame and tilt the seat forward or back.

Note: The seat can be faced in the forward or rear facing position.



Refer to page 12 for instructions on adjusting your harness.

⚠ WARNING

- Unstable hazardous conditions may exist if package carrying accessories are added onto the product.
- Excessive weight may cause a hazardous unstable condition to exist.
- This stroller seats one passenger with a maximum weight limit of **15kg**.
- Not suitable for a child under 6 months old who cannot sit up unaided.
- Do not allow your child to climb unassisted into the stroller.

⚠ WARNING

- Please ensure that your child correctly wears the fitted and adjusted safety harness at all times with all 5 straps secured.
- Never leave the harness buckled when not fitted to the child in the stroller. The harness can form loops which may cause a strangulation hazard.

- 3** To attach the canopy, first secure it to the frame with the zip starting from the left side (when facing the seat).



- 4** Next attach the plastic canopy connectors onto the sides of the frame (**TIP:** attach from top to bottom). You'll notice a round guide on each side, the connectors should attach over these guides.



- 5** Finally, insert the Napper bar into the Napper bar sockets on the seat frame. Always give the bar a firm tug to ensure its secure.

Note: To remove from one side or both, press the button on the side you want to release, and pull the Napper bar out.



Using Stroller

Correct use:

Any vehicle with moving parts needs to be used and treated with care and given regular maintenance to remain safe and in good condition. Please be gentle, don't overload it, avoid excessive off-road use.

Rear brake:

When stopping, use the brake at all times by pressing down on the bottom of the red brake paddle with your foot until you feel it click into place. To start travelling again press down on the top of the red lever with your foot to disengage the brake and off you go!



Front swivel wheels:

When travelling fast along straight surfaces or across uneven terrain, the front wheels may spin or cause what's commonly known as "wheel shudder".

To lock the front swivel wheels into place, press down on the wheel lock buttons (located on the top of the wheel sockets). To go back to 360° swivel mode, press the buttons again.

To remove the front wheels, press the button on the side of the wheel socket and pull the wheel down.



Rear wheels:

To remove the rear wheels, press the button located on the brake bar and pull the wheel off.



Basket:

The basket has been tested to hold 2kg. Overloading the basket with more weight may cause the basket to break.

Reclining the seat:

The seat can recline to 3 set positions. Fully lift the seat recline latch (located at the top of the canopy) and recline the seat to the desired position.



Adjusting the footrest:

Press both footrest buttons simultaneously and adjust the footrest to the desired position.



Using Stroller

Safety Harness:

Always engage the brake before placing your child in the stroller.

To secure the harness:

- 1 Press the safety buckle release button to separate the shoulder strap, belt and span belt.
- 2 Pull the shoulder strap and belt connection position again to separate the shoulder strap from the jumper strap.
- 3 Put your baby in the middle of the cart seat and pass the left and right shoulder straps through the shoulders, with the chest and belt.
- 4 Then cross the belt through the baby's legs and the left and right shoulder straps and belts, and hear the sound of the safety buckle.
- 5 Shoulder straps, belt length can be adjusted by pulling up and down the day buckle position.



⚠ WARNING

- Always use the harness when your child is in the stroller.
- Always adjust the harness appropriately for your child's size.

- 1 Adjust the shoulder strap depend on your baby's height.



Canopy:

Adjust the canopy as needed to protect your child from the sun and wind. For maximum protection, use the zip to extend the canopy to its maximum length.



Adjusting The Handlebar:

Push the button in the middle of the handlebar and pull or push to your desired height.



Folding the Stroller

Recommended as the safest option:

- 1 Before folding, ensure that the front wheels are unlocked.
- 2 Remove the stroller seat by lifting the release levers on either side.
- 3 Push both frame hub buttons and pull up on bassinet to remove.
- 4 Push down on the handlebar to close it.
- 5 Then you can lift the frame up using the carry bar and the front wheels will close inwards.
- 6 The frame has an automatic lock that ensures that it stays closed while you are carrying or storing the pram. To ensure that it has engaged, always push the front section of the frame closed as far as you can and give it a pull to ensure you cannot release it.



⚠ WARNING

- Always take care when folding the frame and lift the frame from the carry bar.
- Always remove the car capsule, bassinet or seat prior to folding and carry the frame and seat/bassinet separately. This is the safest carry method for your back.

Free Accessories

Foot cover:

- 1 Put the footcover on the footrest and pass the top of the footcover through the bumper and attached the velcro on the top.



2 Attaching the cup holder

1. Slide the cup holder clip on to the frame and rotate it toward the back of the stroller.
2. Then swipe down or up, until it firmly attached to a little hole on the underside of the frame.
3. When the clip snaps securely onto the frame, slide the cup holder into the groove of the clip.



Tips for maintaining your pram.

Excessive wear can reduce the effectiveness and safety of your pram. To keep your stroller in good working condition and ensure that it lasts as long as possible will require regular maintenance and you will need to service your pram every 6 months.

Regular maintenance should include:

Inspecting the locking devices, levers, joints, buttons, brakes, wheels, safety harness and fixtures to ensure they are secure, moving freely and in fully working order.

Preventing rust & mold

After exposure to wet or damp conditions (especially trips to the beach, snow or in the rain), leave the pram fully open in a warm, well ventilated environment to prevent rust and mold. You may need to dry with a soft, lint free cloth. Left damp it will encourage mildew, mold or rust to form, damaging the pram.

Correct Use

The **stroller** has been designed for urban living and weekend adventures which means it's ideal for walking on sealed footpaths, in shopping centres, cafes and down at your local park. Use of the **stroller** off-road or over uneven terrain will clearly place more stress on the frame and wheels and cause it to wear out faster. For this reason we recommend "weekend adventures" and not regular off-road use.

⚠ WARNING POISONOUS, TOXIC SUBSTANCE. USE WITH CARE.

Ensure children are not present when applying silicon lubricant or allowing it to dry. Always spray outside or in a well ventilated area. Ensure you use minimal product and wipe away excess solution before use.

Storage

- Do not leave the pram in direct sunlight for prolonged periods of time to avoid colour fade.
- Do not leave in your car on days of extreme heat or near any heat source or fire.
- Do not store the stroller with heavy items on top of it.
- Store the pram in a dry, well-ventilated and safe place.

Spare Parts

- The brakes and wheels are subject to normal wear and should be replaced if necessary.
- Spare parts are available for purchase on the Spare Parts page of our website: support@mompush.com
If the part you require is not listed please email us for a quote.

Cleaning Instructions

For a comprehensive deep cleaning guide (we recommended you do this every 6 months) please refer to our website.

- Use a soft brush to brush down the pram and remove any dirt or dust making sure you get into all the nooks and crannies (i.e inside the wheel hubs, inside the joints from all folding parts etc). You could also give it a good vacuum.
- At the first sign of rust, remove with steel wool.
- All plastic, fabric and metal parts of the pram may be sponged clean with a soft cloth in warm water and a mild detergent.

- Wipe dry with a soft towel or cloth and allow all parts to dry thoroughly before using.
- The seat liner and bassinet mattress liner are machine washable on a delicate setting (maximum water temperature of 30°C) however hand-washing will keep them looking newer for longer.

Do not

- Do not immerse the seat or canopy in water, sponge clean only.
- Do not clean with abrasive materials or using ammonia, bleach, solvents, caustic or spirit-based cleaners.
- Do not press or iron.
- Do not rub or wring fabric.
- Do not tumble dry.
- Do not dry clean.

⚠ WARNING

- Do not clean your pram with children around.
- Do not dismantle or alter any part of the folding mechanisms, frame, brake axel or wheels for cleaning or any other reason.
- Do not use if any part is broken, torn or missing. Replacement parts are available from our website or by contacting us.

Failing to adhere to these maintenance and cleaning instructions could damage or effect the safety of your pram and may void your warranty.

Warranty Information

Your stroller comes with one year defects warranty to cover against faults in materials and workmanship when your pram is used under normal conditions, according to our user manuals and technical specifications.

The warranty is not valid in the following cases:

- Defects or faults resulting from improper assembly, care or use as outlined in our user manual;
- Defects or faults resulting from an accident, airline or transport damage;
- Normal wear and tear, including scratches to the frame or colour fading of the fabrics;
- Damage to handle/belly bar grips or fabrics (i.e. scuffs or tears) as a result of normal handling and daily use;
- Corrosion, mold or rust due to extreme environmental conditions, including high humidity, salt spray, snow or due to lack of regular maintenance.
- Products that are purchased second hand or from an unauthorised distributor;
- Using a part or accessory that is not compatible with the product and/or not manufactured by mompush.
- If you or a third party has attempted to modify or repair the pram without having received written permission from mompush.
- Claims from anyone other than the original purchaser (i.e. no longer valid if gifted or sold to another individual)
- Damage resulting from extreme heat conditions (i.e. leaving in car on hot days)
- Customer dissatisfaction with the product in terms of fit, weight, functionality, colour or design.

Safety Warnings

Please read and follow the bellow warning notices before using your stroller:

⚠ WARNING

- To avoid injury or death:
- Always apply the brakes whenever the pram/stroller is stationary.
- Do not leave children unattended.
- Secure the child in the stroller harness at all times.
- Do not carry extra children or bags on the pram/stroller.
- Make sure children are clear of any moving parts if you adjust the pram/stroller.
- Avoid serious injury from falling or sliding out. Always use the seat belt.

Seat Specific

- This stroller seats one passenger with a maximum weight limit of 15 kg.
- Not suitable for a child under 6 months old who cannot sit up unaided.
- Do not allow your child to climb unassisted into the stroller.

Safety Harness

- Please ensure that your child correctly wears the fitted and adjusted safety harness at all times with all 5 straps secured.
- Never leave the harness buckled when not fitted to the child in the stroller. The harness can form loops which may cause a strangulation hazard.

Bassinet Specific

- Maximum weight that can be carried in the bassinet is 9kg.
- Do not use the bassinet once the child can sit up unaided.
- Not to be used for overnight or unsupervised sleeping.
- Only use the bassinet in a flat position. Do not recline.
- Do not add additional mattress or padding inside the bassinet.

Safety Warnings Continued

Carrying your stroller

- To avoid finger entrapment, keep your own and your children's fingers clear of any folding parts.
- Do not lift or carry the stroller when occupied by your child.
- Do not lift or carry the stroller when fully assembled. Only lift and carry after folding.
- Always remove the car capsule, bassinet or seat prior to folding and carry the frame and seat/bassinet separately.
- Ensure that the automatic frame lock is engaged before lifting or carrying the stroller.
- Make sure the stroller and all parts are secured when being transported in a vehicle.

General safety

- This is not a toy. Do not allow your child to climb, stand on or play with the stroller.
- Do not use the pram in a manner for which it is not designed.
- Keep children clear of the pram before making any adjustments.
- Not suitable for running, rollerblading or skating.
- Remove your child and fold the stroller/pram when going up or down stairs or escalators.
- Take your child out of the stroller when travelling by bus, tram or train.
- Gentle sloping surfaces may be unstable. On steeper sloping and uneven surfaces, there is a possibility that the pram may tip over and you may need to remove your child.
- Do not use if any part is broken, torn or missing. Replacement parts are available from our website or by contacting us.
- Do not use or leave the pram near open fire or exposed flame.

- Always ensure that the frame and the seat/bassinet/car capsule are correctly engaged before using the product.
- Do not overload the pram with additional children, bags, other items or accessories.
- Bags and other items must not be hung from the handle bar as they may damage the frame or otherwise cause the pram to become unbalanced and tip over.
- Do not allow children to stand on the axle/brake bar between the wheels. This is unsafe and could damage the stroller.

Maximum weight limits:

- Maximum weight for a child in the bassinet is 9kg.
- Maximum weight for a child in the seat is 15 kg.
- Maximum weight for items in the basket is 2kg.
- Maximum weight for items in the cup holder is 0.45 kg.

Supervision

- Never leave your child unattended with the stroller. It should only be used under adult supervision.

Others using your pram

- If the stroller is being used by someone unfamiliar with it (such as grandparents) always explain to them how the stroller works and its safety features.



What next?
Read the Bassinet
Manual carefully.



mompush[®]