Palladian Gazebo

Item Numbers: PC-10053 and PC-30053



Assembly Instructions and Owner's Manual

(Actual canopy top color and panel design may vary - available in taupe and chocolate)



Agora Outdoor Living[™]
Design and Manufacture by
Pacific Currents Inc.

Thank you for choosing a Pacific Currents Product. Please make sure you have carefully read and understood these assembly instructions before you begin.

Pre-Assembly Steps

Prepare the work area:


First, compare the parts in the box with the parts list on the following pages and make sure that none are missing. If you discover any missing parts, please visit www.pacificcurrentsinc.com or call 888-474-2770 . <i>Save your sales receipt</i> as you will need this to obtain service.
Choose and measure the final location where you would like to place the product and ensure that it will fit a $10' \times 10'$ rectangle with $11'$ height clearance. Then, choose an assembly area as close as possible to this final location and large enough to layout and pre-assemble all the parts for this Gazebo.
It is highly recommended that you cover the work surface with a tarp or other fabric to prevent scratches to the finish during assembly.
You will need these additional tools: a ladder and an adjustable wrench.
You may also need these additiontal tools (optional): work gloves, waterproofing spray.


General Notes:

- 1. You will need the help of another person to assemble this product. Please ask a friend or neighbor for assistance!
- 2. Once a unit has been pre-assembled in each step, please set it aside until further instructions.
- 3. For all customers, we **highly** recommend that you **remove your canopy top** in cases of severe inclement weather such as thunderstorms. Unfortunately, damage due to acts of nature are not covered in the warranty.
- 4. You do not need to disassemble the gazebo during winter months. However, to prevent damage to the frame and canvas top due heavy snow loads, remove the canvas top and store it in a dry location until spring.


Parts Identification

(Note: Not drawn to Scale)





Additional Parts (Sold Separately)



Important

For missing or defective parts, Do NOT return to the place of purchase. Call our toll free number below or visit www.pacificcurrents.com. Please have your sales receipt ready when you call.

888-474-2770

Hardware Identification

Bolt Set

[x 8]

Bolt Set

Q [x 8]

Bolt Set

R [x 44]

Bolt Set

S [x 8]

Bolt Set

T [x 40]

2-1/16" (52 mm) Length Bolt









1-1/2" (42 mm) Length Bolt









1-1/4" (32 mm) Length Bolt











2-1/6" (55 mm) Length Bolt











1-3/10" (35 mm) Length Bolt










How to use Hardware

Bolt and Washer Assembly







Bolt and Washer Assembly (Parts L, Q, R)










Assembly Instructions

Assemble the Four Gazebo Corner Legs [x 4]

A [x 4]

B [x 4]


Q (m) (x 8]



6

Assemble the Four Cross Bar Connectors [x 4]


- G [x 4]
- H [x 4]
- E [x 4]
- R () [x 16]



Assemble the Roof Corner Bars [x 4]

- [x 4]
- K [x 4]

- (8 x)



Step 4

Gather the pre-assembled parts

At this point, place all the gazebo legs in an upright position over the final location you have chosen for the gazebo and gather the remaining assembled pieces from steps 2-4.


*Remember, please do not tighten any of the nuts all the way as this will hinder the final assembly.

Attach Gazebo Legs to Cross Bar Connectors



(x 8)


S (mmmm 0 0 0 0 0 0 [x 8]



Attach Canopy Corner Bars (J+K) to Top Connector (D)


D [x 1] J+K [x 4]

R (((x 4)



Attach the center support bars to the canopy frame [x 8]


- O [x 8]




Attach the canopy vents to roof frame

I-L [x 4] I-R [x 4]

R () (x 8) T () (x 16)



NOTE: Your gazebo should now resemble the image below. Please check to make sure all parts are in their respective locations.



If the final location for your gazebo is a soft surface, you may secure it by driving the provided stakes (part F) through holes at the bottom of each gazebo leg panel (parts A and B)

NOTE: Lawn stakes for use only on natural surfaces (grass or dirt) and not meant to permanently secure gazebo to the ground in high winds.

Attach canopy top to frame.


(Optional) Install bug screen and/or sun shade (Sold Separately).



NOTE: Carefully pull the canvas top over the gazebo roof frame and slide the vent bars into each respective vent opening in the canvas.

The fit will be very snug. You may need to reposition the gazebo legs slightly in order to pull the canvas top into position. Use the velcro straps to secure the canvas top to the gazebo frame.

Attach Bug Screen and Sunshade using velcro straps (Sold Separately)



FAQ (Frequently Asked Questions)

Q: Will the gazebo frame ever rust?

A: The powder coated finish of the metal frame prevents rusting so long as the metal itself is not exposed. Exposure of the metal may occur due to accidental scratches or long-term wear and tear. Occasional touch ups to affected areas with weatherproof paint will ensure many years of continued enjoyment from your gazebo.

Q: Can I use grills or barbecues inside the gazebo?

A: No, we do not recommend this. While the canopy top is fabricated using a fire resistant material, our gazebos are not designed to accommodate an open flame. Please refrain from using your grill inside the gazebo.

Q: Will the gazebo move or blow away in strong winds?

A: Several features of our design were considered to allow the gazebo to remain very stable across a range of weather conditions. The four vents in the canopy top help to allow low to medium winds to pass through the covering.

However, if you install the gazebo in an area where strong winds are persistent, it is advisable to take further steps to fasten the gazebo to the ground. If the gazebo is installed over a soft natural surface (grass or dirt), you may drive metal stakes (included) through the holes located at the bottom of the panels and into the ground. If the gazebo is installed over a hard surface (wooden decks or concrete patios) it will be necessary to separately purchase screws or bolts and nuts to affix the frame to your installation surface. Please visit your local Mills Fleet Farm Store for more options.

Q: I like being outdoors, but cannot stay for long because of mosquitoes. Are bug screens available for my gazebo?

A: Yes! Bug screens for all gazebo models are available separately for purchase as an accessory.

Care Instructions:

Canvas Top

The polyester top (Canvas Top) can be machine washed using a small amount of detergent. Do not machine dry or use bleach for the Top. Top may also be spray-rinsed while attached to Gazebo and lightly scrubbed with a soft broom. DO NOT use any hard abrasives to scrub.

The canvas top is not waterproof. However, a waterproofing spray (not included) may be used to prevent rain water infiltration.

The canvas top MUST be removed and stored in a dry location in the event of snow fall. Accumulated snow WILL severely damage your gazebo if the canvas top is not removed.

Gazebo Frame

Any rust on the frame as a result of scratches on the surface can be cleaned with soap and water and wiped down with a soft cloth. DO NOT use any hard abrasives to scrub. Touch-up paint is not available but the colors can be matched at your local Mills Fleet Farm store.

All metal parts may be sprayed with a clear laquer finish to maintain the attractiveness of your gazebo over time and allow you to enjoy your gazebo for as long as possible.

IMPORTANT: Winter storage - If you live in an area that experiences snow in the winter, remove the canvas top and store it in a location that is dry and free of moisture.

1 Year Limited Warranty:

WARRANTY COVERAGE DETAILS

- **A.** Purchaser assumes all risk in the assembly and use of this unit.
- B. Length of Warranty (Blanket Policy): All components carry a one year limited warranty from date of purchase against defects in material and workmanship arising under normal use.
- C. This warranty does NOT cover wear and tear, nor weathering due to climate and other environmental factors, nor does it cover failure resulting from accident, misuse, neglect, mishandling, modification, or damage that is attributed to acts of nature (high winds, rain, snow, etc.).
- **D.** This warranty does not cover incidental or consequential damages resulting from use of product, or losses arising out of any breach of this warranty.
- **E.** This warranty only extends to the original purchaser.

WARRANTY CLAIM PROCEDURES

- A. *** A claim under our warranty must be submitted by the original purchaser to Pacific Currents Inc., via phone, email, website, or fax within 24 hours of the defect occuring and within 12 months of the date of purchase, validated by providing a copy of the original sales receipt, a photograph of the damaged area and a brief description. ***
- **B.** All claims for parts damaged in original packaging must be made **prior** to the partial or complete assembly of the product.
- **C.** Fulfillment of this warranty shall only include direct replacement of damaged parts as described above to be arranged at the discretion of Pacific Currents Inc. If it is not feasible or practical to replace the damaged part directly, Pacific Currents Inc. shall authorize a return of merchandise or replacement between the purchaser and the place of purchase on a case by case basis. **No returns to place of purchace will be accepted without prior authorization.**

Please contact us should you have any questions concerning assembly, care information, warranty coverage, and missing or defective parts.

Customer Service: 888-474-2770

Email: info@pacificcurrentsinc.com

Website: www.pacificcurrentsinc.com

Enjoy your new gazebo and thank you for choosing a Pacific Currents Inc. product!