

Super Pogo 2

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING YOUR Super POGO 2. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

ALWAYS ADHERE TO THE FOLLOWING AGE AND WEIGHT RESTRICTIONS: Super POGO 2: FOR AGES 14 AND UP, 90 TO 200LBS

Satisfaction guaranteed

If any parts are missing, do not return the pogo to the place of purchase. We will rush you any missing parts at no charge. The rubber tip is installed at the factory. Should the tip become lost or damaged, replace it immediately. NEVER use your pogo without the tip properly in place.

Safety information



- Always wear protective gear when operating the pogo stick
- Always operate on a firm surface
- Always check your pogo stick for defects before use
- Wear suitable athletic footwear; do not operate bare foot
- Do not push the pogo stick away from you, keep in an upright position.
- If the rubber tip is lost or damaged, stop using immediately and get a replacement
- Make sure people using the pogo are informed on how to use the pogo before using
- Do not use the pogo stick on wet or uneven surfaces
- Lubricate pogo stick using silicone spray on a regular basis
- Always store the pogo stick under a shelter from the weather

Protective gear: Helmet, shin pads, knee pads, elbow pads and athletic shoes with good grip.

Maintenance



Adjust the handlebars by first loosening all four screws (Turning counter clockwise) at the top of the handlebars, rotate the handlebars to the upright position and then tighten the screws back up again (Turning clockwise). Make sure that the handlebars do not move before operating fully.

Please note: The spring is not adjustable on this model, the spring is deliberately tight and several successive jumps are necessary on first time use. **If** you cannot balance on the pogo stick in order to compress the spring, please seek a spotter. The spotter should stand behind the jumper, his/ her arms over the top of the jumper's holding firmly onto the handlebar, with enough grip to ensure the jumper can actually jump, and to ensure the jumper doesn't fall.

Do not push down on the pogo stick to compress the springs.

For spare parts please visit www.flybar.com or alternatively contact us via email: sales@flybar.com



Right!!!



Wrong!!!



Holding pogo stick upside down, spray tube with silicone spray.