

REFLEX ACTIVE


ACTIVETAG

THANK YOU FOR CHOOSING REFLEX ACTIVE!

We know you want to get straight to the point, but please take a minute to read these instructions, they'll help you get the most from your Reflex Active product.

GETTING STARTED

1. Press and hold the button on the tag for **5 seconds**, the tag will beep and turn on.
2. Open the **Find My app**.
3. Hold the tag close to your device, tap the **items tab**, then tap **add item**.
4. Tap **other supported item**.
5. Tap connect to **MWFD05A**.
6. Type a name for your tag and select an emoji which will be the icon shown within the **Find My app**.
7. Tap **agree** to acknowledge that this item will be linked to your Apple ID.
8. Tap **finish**.




Now, you can attach your tag to any item and see it visible in the Find My app.

ENABLE LOST MODE

If you lose your tag, you can use the Apple Find My app to mark it as lost. You can add a message saying that the item is lost and include your phone number or email address. If someone else finds your item, they can use a supported device to see a website with the Lost Mode message.


1. Open the **Find My app**, tap the **items tab** then tap your item.
2. Under **Lost Mode**, tap **enable** on the **Find My app**.
3. Read the instructions, tap **continue** and enter a phone number or email address.
4. Confirm the information, **customise the lost message**, and tap **activate** to complete the setup.



REMOVING THE TAG FROM THE APP

1. Open the **Find My app**, tap the **items tab**, then tap your item.
2. Tap **remove item** and then tap **remove** to complete the operation.

Note: After removing the device in the app, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state, and the device and app cannot be paired at this time. If you need to pair the device, click the device button once, the device will ring and the light will flash once. At this point, the device enters the pairing state and can be re-paired within the app.



UNKNOWN TAG FOUND

1. If an unknown tag is placed on you or your belongings a notification will appear on your phone.
2. When you open the notification in the Find My app you can see when the item was located on you and the route tracked. From here you can pause or disable the tracking. For more information on how this product works please visit - www.reflex-active.com/pages/support

TAG INSTRUCTIONS

Power on: Long press the button for **five seconds**, the tag will beep, the light will flash five times, and the device will be turned on.

Tag status check: Double-click: the tag button, the tag will beep, and the light will flash three times, indicating that the tag is working. If the tag doesn't beep, the tag is off. Long press the button for **five seconds** to turn it on.

RETURN TO PAIRING STATE: After removing the tag in the app, the tag will beep and the light will flash six times, it will not shut down and will be in pairing mode. If there is no re-pairing within 10 minutes, the tag will leave the pairing state. If you want to pair a device click the tag button once, the tag will beep and the light will flash once. Now the tag enters pairing state and can be paired within the app again.

Power off: When the tag is turned on, press the tag button five times in 2 seconds. The tag will beep, the light will flash three times, the tag will be powered off.

Factory reset: 1. First remove the item from **Find My app** then after the tag is powered on, double-click the tag button. The tag will beep, then long press the tag button for **eight seconds** until the tag beeps and the light flashes three times. 2. Release the button to complete the factory reset. The device can now be paired.

HOW TO REPLACE THE BATTERY (BATTERY PRE INSTALLED)

1. Using the tool provided, place it in the notch on the side to loosen the casing.
2. Replace the battery with a new one. (Positive pole upward).
3. Assemble the tag and long press the button for five seconds to restart it.



BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN.



- If the battery compartment does not close securely, stop using the product immediately and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Dispose of any used batteries immediately.
- Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.

HOW IS MY PRIVACY PROTECTED?

Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way. For more information on how this product works please visit - www.reflex-active.com/pages/support

DISCLAIMER

Reflex Active cannot be held responsible for loss or damage to personal property.

COMPATIBILITY

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.

CARING FOR YOUR PRODUCT

Please follow these simple instructions to keep your tag looking and working great!

- Clean product with a dry cloth.
- Not designed to be submerged in water, should this occur product may malfunction.
- Keep away from steam & dust as these may affect quality of performance.
- Keep away from strong magnetic fields to avoid interference.

GUARANTEE

Your Reflex Active product is guaranteed against any defective construction or parts for 1 year from date of purchase. Please retain your receipt as proof of purchase. Breakages caused by water damage, accident or mishandling are not covered. This guarantee is in addition to your statutory consumer rights. In the unlikely event you need to return your Reflex Active product or you need any other assistance with your product, please contact us and we'll be happy to help.

IMPORTANT INFORMATION

Enjoy your music, but please stay safe & ensure you stay aware of your surroundings at all times. We advise against listening to loud music for long periods of time. Do not use this product whilst driving or in other potentially dangerous situations. This product is not a toy, not for use by children. This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures. Made in China by Peers Hardy UK Ltd. Precision House, Starley Way, Birmingham International Business Park, B37 7GN. EU Address, Peers Hardy UK LTD, C/O Global E-commerce Experts, Rijnlanderweg 766, Unit H, 2132 NM, Hoofddorp, Netherlands.

DISPOSAL OF GOODS

The crossed out wheelee bin symbol is to remind you that waste electrical products, batteries & accumulators should not be disposed of in household waste. If you are unable to reuse or recycle your article it should be disposed of at a civic amenity site or a local authority recycling facility. Do not dispose of your product within household waste. Disposal of the packaging & your product should be done in accordance with local regulations. Batteries are not to be disposed of in municipal waste stream and require separate collection.

EU DECLARATION OF CONFORMITY

The full UK & EU declaration of conformity can be viewed online at the following web page: <https://www.reflex-active.com/pages/audio-docc>

LEGAL NOTICE

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Watch, iPad, iPadOS, macOS, and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

HELP AND CONTACT

If you need any help with your product, then please get in touch, we'll be happy to hear from you! We are available Monday - Friday 9am - 4pm.

✉ Support@Reflex-Active.Com 📞 +44 (0) 121 524 1400



COME JOIN US OVER ON SOCIAL!

REFLEX.ACTIVE

REFLEX.ACTIVE