


CT-106

4 CHANNELS TIMER (100 HRS)

W/ 1/100 SEC. STOPWATCH (10 HRS)

& ALARM CLOCK/CALENDAR



② PRESS START, KEEP ON COUNTING, PRESS STOP, STOP COUNTING.

THEN PRESS **RESET** , BACK TO ZERO.

2. LAP (---). TIME:ist press **SET** TO GET IT.

① PRESS START, 1/100 SEC. COUNT UP. THEN, PRESS **RESET** TO GET THE SECTION LAP TIME.

② PRESS START, BACK TO TOTAL ELAPED TIME. THEN PRESS **RESET** . BACK TO ZERO.

C. ALARM CLOCK: 12 HRS/24 HRS USER SELECTABLE

PRESS **CLK** , DISPLAY "CLOCK" MODE.

5:39 ^{PM} 25

HR MIN SEC.

1. SETTING TIME: CLOCK

① PRESS **SET** , HR5 FLASH, PRESS **△** , ADVANCE TO DESIRED HR.

② THEN PRESS **SET** , MIN 39 FLASH. PRESS **△** , ADVANCE TO NEXT MIN OF STANDARD TIME.

③ THEN PRESS **SET** , SEC FLASH. PRESS **△** , WHEN MIN SAME AS THE STANDARD TIME. SEC. CHANGED TO "00".

④ THEN PRESS **SET** , NO MORE FLASHING. FINISH ADJUSTING THE TIME.

** 12 HRS/24 HRS SELECTABLE:

5:39²⁵ PM

CHANGE

PM




12:39²⁵

2. ALARM SETTING: IN CLOCK MODE

PRESS **CLK** , → 12:00^{PM} AL . IF YOU WANT TO SET


6:30^{PM} AL ALARM

① PRESS **SET** , HR 5 FLASH, PRESS  , ADVANCE TO 6.

6:00^{PM} AL

② PRESS **SET** , MIN 39 FLASH, PRESS  , ADVANCE TO 30.

③ PRESS **SET** , NO MORE FLASHING. DISPLAY 6:30^{PM} AL
. FINISH SETTING ALARM TIME.

④ ALARM ON/OFF: PRESS  , DISPLAY ((•)) 6:30^{PM} ALARM

ON. W/ ALARM SIGNAL



PRESS   ALARM SIGNAL DISAPPEARED. ALARM OFF

D. CALENDAR: PRESS ^{CLDR} **CLK** , DISPLAY **3:1085**

EX. FOR **8:2594** SETTING:

① PRESS **SET** , MON 3 FLASH. PRESS **△** , ADVANCE TO
DESIRED MON 8

② PRESS **SET** , DAY 10 FLASH. PRESS **△** , ADVANCE TO
DESIRED DAY 25

③ PRESS **SET** , YEAR 85 FLASH. **△** , ADVANCT TO
DESIRED YEAR 94

④ PRESS **SET** , NO MORE FLASHING. DISPLAY **8:2594**
. FINISH ADJUSTING.

E. HOURLY CHIME: EVERY HOUR WILL HAVE ALARM 2
SOUND TO REMIND USERS. FOR EX. 6:00^{PM}00 , 7:00^{PM}00...

CHIME SETTING: IN **CALENDAR** MODE

(((•))) mark will appear when the chime function is ON duty.

COUNTING UP FOR EX. COUNT UP TO **T¹ 00:0007** , OVER 7 SEC.
TOTAL TAKE TIME 17 SEC.

STOP ALARM: PRESS ANY KEYS CAN STOP ALARM.

STOP COUNTING: ONLY PRESS **STOP** KEY, CAN STOP COUNTING, OTHERS CAN'T. MEMORY: PRESS STOP KEY AGAIN, DISPLAY

T¹ 00:0007 CHANGE TO **T¹ 00:00 10** PRE-SET TIME.

B. STOPWATCH (1/100 SEC.): RANGE 10 HRS.

① PRESS **STP.W** , DISPLAY 7 DIGIT **STOPW 0:00:0000**
HR MIN SEC 1/100 SEC

② PRESS START, COUNT UP. PRESS STOP, STOP COUNTING TEMPORARILY.

③ PRESS **RESET** , BACK TO ZERO POINT.

④ PRESS START, 1/100 SEC. COUNT UP, THEN, PRESS **RESET**
TO GET THE TOTAL ELAPSED TIME.

1. IF YOU WANT TO START T1, T2, T3, T4 SIMULTANEOUSLY.

YOU JUST FINISH SETTING, THEN PRESS **CLK** ONCE, THEN

PRESS **START STOP**, DISPLAY

T1	T2	T3	T4
5:3925			

 T1 T2 T3 T4 4 SIGNALS

FLASHING AT THE SAME TIME. IT MEANS, T1, T2, T3, T4. 4 CHANNELS ALL START COUNT DOWN SIMULTANEOUSLY. PRESS **STOP**, CAN STOP COUNT DOWN TEMPORARILY. THEN PRESS **START**, COUNT DOWN CONTINUOUSLY PRESS **T1**, OR **T2**, **T3**, **T4**, YOU CAN SEE HOW MUCH TIME IT LEFT OR OVER ELAPSED. THEN PRESS **T1**, PRESS **START** KEY, DISPLAY THE PRE-SET TIME OF T1, T2, T3, T4 SAME.

2. T1, T2, T3, T4 W/ 4 DIFFERENT ALARM SOUND. YOU CAN EASILY DISTINGUISH IT.

3. RECORDING THE OVER ELAPSED TIME & MEMORY (RECALL THE PRE-SET TIME):

IF YOU SET

T1
00:00 10

, START, COUNT DOWN TO

00:0000

, WILL ALARM. THEN COUNT UP AUTOMATICALLY.

RECORDING THE OVER-ELAPSED TIME. PRESS **STOP**, STOP

OPERATIONS:

A. 4 CHANNELS TIMER: T1, T2, T3, T4 CAN START

SIMULTANEOUSLY RANGE: 99HR. 59MIN. 59SEC.


SETTING:


1. SETTING: PRESS T1 (CHANNEL 1), DISPLAY  , EX. FOR
HR MIN SEC







2. THEN PRESS  .  . HR FLASH, PRESS  .

ADVANCE TO DESIRED HR 3

3. PRESS  , MIN FLASH. PRESS  , MIN ADVANCE TO DESIRED

4. PRESS  , SEC FLASH. PRESS  SEC ADVANCE TO DESIRED 10,

5. THEN PRESS  AGAIN, BACK TO 

6. ALSO YOU CAN PRESS  , OR  ,  DIRECTLY INTO
SETTING CHANNEL 2,3,4 THEN NO MORE FLASHING. FINISHING
SETTING.

7. IF YOU SET WRONG TIME, CAN PRESS  , THEN IT BACK TO



8. T2, T3, T4 SETTING, SAME AS T1.

9 RECALL CHANNEL 1,2,3,4. JUST PRESS  ,  ,  , 