Sper Scientific Instruments

870003

Online Conductivity Analyzer

User Manual

Catalog

Technical Specification	•••••	••••••	1
Installation and Wiring			2
Size		2	
Installation		3	
Wiring		3	
Operation Interface			5
Measurement Interface			6
Setting			7
Setting menu		7	
Unit		8	
4-20mA		8	
Communication		9	
Temperature		9	
Simulation1		9	
Simulation2		10	
Relay1		10	
Relay2		10	
Relay3		11	
Storage		11	
Date&Time		11	
Language		12	
Backlight		12	
Factory data reset		12	
Calibration			13
Parameter set		13	
Cell constant		14	
Conductivity Calibra	tion	14	
Standards Calibration	n	. 15	
Factory data reset		15	
History			15
Waveform			16

Appendix 17

Introduction

DDG-2080Pro Industrial Online Electrical Conductivity Analyzer is a brand-new online intelligent analyzing instrument independently developed and manufactured by BOQU Instrument. This Electrical Conductivity analyzer supports matching bipolar electrodes and quadrupole electrode. Complete functions, stable performance, easy operation, low power consumption, safety and reliability are the outstanding advantages of this EC analyzer.

The Electrical Conductivity a can be widely used in industrial application such as thermal power generation, chemical industry, metallurgy, environmental protection, pharmaceutical, biochemical, food and tap water.

Technical Features

- 1) Extremely quickly and precision electrical conductivity sensor.
- 2) It's suitable for harsh application and free-maintenance, save cost.
- 3) Provide two ways of 4-20mA output for EC and temperature.
- 4) Quardrupole EC Sensor provide precision and online measurement.
- 5) With data recording function, user easy to check history data and history curve.

Technical Specification

Specifications	Details		
Name	Online Electrical Conductivity Analyzer		
Shell	ABS plastic		
Power Supply	90V ~ 260V AC 50/60Hz		
Power Consumption	4W		
Output	Two 4-20mA output tunnels,RS485		
Relay	5A/250V AC 5A/30V DC		
Size	144mm×144mm×104mm		
Weight	0.9kg		
Protocol	Modbus RTU		
Range	0 uS/cm ~2000000 uS/cm(0 mS/cm ~2000 mS/cm) 0 g/L ~80 g/L(ppt) 0 mg/L ~130000 mg/L(ppm) 0 MΩ ~20 MΩ -40 °C ~200 °C		
Accuracy	2% ±0.5°C		
Waterproof Level	IP65		
Storage Environment	-40°C~70°C 0%~95%RH(non-condensing)		
Working Environment	-20°C~50°C 0%~95%RH(non-condensing)		

Installation and Wiring

SIZE



Installation





Wiring

Bipolar









Operation Interface

There are 2 modules in the main panel of the electrical conductivity measuring instrument, LED LCD display module and button module.

Users can set and adjust the parameters of the instrument through the 5 buttons on the panel.



Picture 1 Operation Interface

- ① Set/Exit button
- 2 Select/Shift button
- ③ Up button
- ④ Down button
- ⑤ Confirm button
- 6 LED screen

Measurement interface

Enter the main measurement interface after the start-up animation.

When the instrument is working normally, the LED display shows the following content.



Picture 2 Main interface

- ① Measurement value
- 2 Unit
- ③ Temperature
- ④ Real-time date
- ⑤ Real time
- 6 Measurement status
- ⑦ 4-20mA corresponding value of electrical conductivity
- 8 Relay status
- 9 Mode

Setting

Press "Set/Exit Button" to enter the password input interface.



Picture 3 Password

Enter settings:

Enter the password "3700" to enter the setup menu.



Picture 4 Setting Menu

3.1 Unit

In this menu, users can change the measurement method Cond / Salinity / TDS / Resistivity, and at the same time can adjust the offset to make the measurement accurate.



Picture 3.1.2 Unit

3.2 4-20mA

In this menu, users can change the corresponding value of 4-20mA and set the corresponding effective range.

4-20mA					
0 000 mS/cm					
0002 mS/cm					
+000 °C					
+100 °C					

Picture 3.2 4-20mA

3.3 ModbusRTU communication

In this menu, users can change the communication address and rate.



Picture 3.3 ModbusRTU communication

3.4 Temperature

In this menu, users can set the temperature compensiton and manually set the temperature.



Picture 3.4 Temperature

3.5 Simulation

In this menu, users can simulate the 4-20mA current output. The current output can be verified by simulating the measurement of the IO1 (measured value) and IO2 (temperature) ports. The release relay is closed. The relay is simulated and verified.



Picture 3.5.1 Simulation1



Picture 3.5.2 Simulation2

3.6 Relay1

In this menu, users can switch the relay 1 function, set the parameter alarm upper limit value, alarm return difference value, and alarm delay time.

Relay1				
Func.	:	ON		
		▶ OFF		
High	:	10.00 mg/L		
Hyst	:	1.00 mg/L		
Delay	:	030 S		

Picture 3.6 Relay1

3.7 Relay2

In this menu, users can switch the relay 2 function, set the parameter alarm lower limit value, alarm return difference value, and alarm delay time.

Relay2					
Func. :	ON				
	► OFF				
Low :	03.00 mg/L				
Hyst :	1.00 mg/L				
Delay :	030 S				

Picture 3.7 Relay2

3.8 Relay3

In this menu, users can set the relay 3 function, set the cleaning time and cleaning cycle.

Relay3				
Func. :	ON ▶ OFF			
Period:	001.0h			
Clean:	010s			

Picture 3.8 Relay3

3.9 Storage

In this menu, users can set the storage function (default off), clear storage memory and recording interval.



Picture 3.9 Storage

3.10 Date&Time

In this menu, users can change date and time according to different time zone.

Date Y-M-D : 20**1**9-10-01 H:M:S : 12:00:00



3.11 Language

Users can choose English or Chinese according to need.



Picture 3.11 Language

3.12 Backlight

In this menu, users can change the backlight mode of the LCD screen. The backlight can be always on or delayed off (the default is delayed off), the backlight brightness can be changed (brightness level 1-5, brightness increases), and the contrast can be changed.



Picture 3.12 Backlight

3.13 Factory data reset

In this menu, users can restore the current output and relay to the factory parameters.

Factory R	eset
Restore: ▶	Current Relay1 Relay2 Relay3 All

Picture 3.13 Factory data reset

Calibration

Press "ESC" to enter the password input interface.



Picture 5 Password

Enter calibration menu:

Enter the password "3900" to enter the calibration menu.



Picture 6 Calibration menu

4.1 Parameter set

In this menu, users can manually change the parameters of reference temperature and temperature coefficient.



Picture 4.1 Parameter Set

4.2 Cell Constant

In this menu, users change cell constant manually . Press 'Enter' buttom after value changed.



Picture 4.2 Cell Constant

4.3 Conductivity Calibration

In this menu, users can change conductivity by known density solution manually. Press 'Enter' buttom after value changed.

Cond	l Cal
26.26 us/cm	0 000.00 us∕cm
Please Pr	ess Enter

Picture 4.3 Conductivity Calibration

4.4 Standards Calibration

In this menu, users can change conductivity by standard solution. When the value comes stable, press 'Enter' buttom.



Picture 4.4 Standards Calibration

4.5 Factory data reset

In this menu, users can restore the calibration parameters to the factory parameters.



Picture 4.5 Factory data reset

History Data Display

Press "ESC" to enter the password input interface.



Picture 7 Password

Enter History Data Display:

Enter the password "1300" to enter the History Data Display.

Press the up and down keys to switch the display. It can store up to 1000 records and overwrite automatically if reach maximum.

Record	l 1/1000
2020-01-09	12:48:28
6.00 us/cm	
2020-01-09	12:43:28
6.00 us/cm	
2020-01-09	12:38:28
6.00 us/cm	
2020-01-09	12:33:28
6.00 us/cm	

Picture 8 History

Waveform Display

Press "ESC" to enter the password input interface.

PASSWORD
0000

Picture 9 Password

Enter Waveform Display:

Enter the password "1400" to enter the Waveform Display.

Press the up and down keys to switch the display.



Picture 10 Waveform Display

Appendix

Communication protocol

Communication parameters:

Baudrate:4800, 9600, 19200(9600default)

Serial data format: 8N1(8 data bits, No parity, 1 stop bit)

Function code: 03

Device address: Electrical Conductivity analyzer defaults to 2

Register definition:

Register address(Dec)	Definition	R/W	Remarks	
0, 1	Temp	R	×1.0 °C, FP32 AB CD	
2, 3	EC	R	×1.0 us/cm, FP32 AB CD	
8	RTU Address	R/W	Modbus communication address, EC defaults 2.	
9	Baudrate	R/W	4800, 9600, 19200, 9600 as default	
26, 27	TDS	R	FP32 AB CD	
28, 29	MoHM	R	FP32 AB CD	
30, 31	ppt	R	FP32 AB CD	

Examples of communication formats:

Data reading instruction

Addr. + Func. + Register start address + Number of Registers read + CRC check code

(Hex)

e.g. Tx:02 03 00 02 00 02 65 F8

Address	Func.	Register start address	Number of Registers read	CRC check code
02	03	0002	0002	65F8

Data return instruction:

Address + Func. + Data length + Data + CRC check code (Hex)

e.g. Rx:02 03 04 40 0E B8 52 4E CD

Address	Func.	Data length	EC value	CRC check code
02	03	04	400EB852	4ECD

Convert the hexadecimal number 400EB852 to decimal through a floating-point number

converter, resulting in a value of 2.23



Electrode parameter table of Online Electrical Conductivity Analyzer

Туре	ECG-0.01C	ECG-0.1C	ECG-1.0C	ECG-10C	ECG-30C				
CC	0.01	0.1	1.0	10	30				
EC Range	0-20µS/cm	0-200µS/cm	0-2000µS/cm	0-20000µS/cm	30-600mS/cm				
Temp	0.0-100.0°C	0.0-100.0°C	0.0-100.0°C	0.0-100.0°C	0.0-100.0°C				
Range									
Accuracy	2%, ±0.5°C								
Withstand	0.4MPa								
pressure									
Waterproof	IP68/NEMA6P								
Level									