

VITUS

OWNERS MANUAL

VITUS OWNER'S MANUAL FOR MULTI-SPEED BICYCLES

NOTE

This manual is not intended as a comprehensive assembly, use, service, repair or maintenance manual. Please see your dealer for all assembly, service, repairs or maintenance. Your dealer may also be able to refer you to classes, clinics or books on bicycle use, service, repair or maintenance.

IMPORTANT

This manual contains important safety, performance and service information. Read it before you take the first ride on your new bicycle, and keep it for reference. Additional safety, performance and service information for specific components such as pedals, or for accessories such as helmets or lights that you purchase, may also be available from your dealer. Make sure that your dealer has given you all the manufacturers literature that was included with your bicycle or accessories. If you have any questions or do not understand something, take responsibility for your safety and consult with your dealer as a first point of contact.

3 CONTENTS

- 4 General Warning
- 4 Note to parents

5 SECTION 1 - FIRST

- Bike fit
- Safety first
- Mechanical safety check
- First ride

8 SECTION 2 - SAFETY

- The basics
- Riding safety
- Wet weather riding
- Riding at night
- Competition
- Changing components
- Maximum weight

13 SECTION 3 - FIT

- Standover height
- Saddle position
- Handlebar height and angle
- Control position adjustments
- Brake reach

16 SECTION 4 - TECHNICAL

- Initial assembly
- Wheels
- Wheel Quick Release
- Removing and installing Quick Release wheels
- Brakes
- Gears
- Pedals
- Tyres and tubes
- Tightening of fasteners

27 SECTION 5 - SERVICE

- Service intervals
- If your bicycle sustains an impact
- Replacement parts

GENERAL WARNING

Like any sport, cycling involves risk of injury and damage. By choosing to ride a bicycle, you assume the responsibility for that risk, so you need to know - and to practice - the rules of safe and responsible riding and of proper use and maintenance. Proper use and maintenance of your bicycle reduces risk of injury. This manual contains many “warnings” and “cautions” concerning the consequences of failure to maintain or inspect your bicycle and of failure to follow safe cycling practices.

- The combination of the safety alert symbol and the word warning indicates a potentially hazardous situation which, if not avoided, could result in serious injury or death.
- The combination of the safety alert symbol and the word caution indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or is an alert against unsafe practices.
- The word caution used without the safety alert symbol indicates a situation which, if not voided, could result in serious damage to the bicycle or the voiding of your warranty.

Many of the warnings and cautions say “you may lose control and fall”. Because any fall can result in serious injury or even death, we do not always repeat the warning of possible injury or death. Because it is impossible to anticipate every situation or condition which can occur while riding, this manual makes no representation about the safe use of the bicycle under all conditions. There are risks associated with the use of any bicycle which cannot be predicted or avoided, and which are the sole responsibility of the rider.

E-BIKE WARNING

Any manipulation, modification or tuning of e-bike motors will void warranty and carries a severe risk of injury and damage. If the motor is modified, your e-bike may no longer be approved for use on public roads and forest trails.

A SPECIAL NOTE FOR PARENTS

As a parent or guardian, you are responsible for the activities and safety of your child, and that includes making sure that the bicycle is properly fitted to the child; that it is in good repair and safe operating condition; that you and your child have learned and understand the safe operation of the bicycle; and that you and your child have learned, understand and obey not only the applicable local motor vehicle, bicycle and traffic laws, but also the common sense rules of safe and responsible cycling. As a parent, you should read this manual, as well as review its warnings and the bicycle’s functions and operating procedures with your child, before letting your child ride the bicycle.

Warning: *Make sure that your child always wears an approved bicycle helmet when riding; but also make sure that your child understands that a bicycle helmet is for cycling only, and must be removed when not riding. A helmet must not be worn while playing, in play areas, on playground equipment, while climbing trees, or at any time while not riding a bicycle. Failure to follow this warning could result in serious injury or death.*

SECTION 1 - FIRST

Note: We strongly urge you to read this manual in its entirety before your first ride. At the very least, read and make sure that you understand each point in this section, and refer to the cited sections on any issue which you don't completely understand. Please note that not all bicycles have all of the features described in this manual. Ask your dealer to point out the features of your bicycle.

1.A. BIKE FIT

- 1.A.1. Is your bike the right size? To check, see section 3.A. If your bicycle is too large or too small for you, you may lose control and fall. If your new bike is not the right size, ask your dealer to exchange it before you ride it.
- 1.A.2. Is the saddle at the right height? To check, see section 3.B. If you adjust your saddle height, follow the minimum insertion instructions in section 3.B.
- 1.A.3. Are saddle and seatpost securely clamped? A correctly tightened saddle will allow no saddle movement in any direction. See section 3.B.
- 1.A.4. Are the stem and handlebars at the right height for you? If not, see section 3.C.
- 1.A.5. Can you comfortably operate the brakes? If not, you may be able to adjust their angle and reach. See section 3.D and 3.E.
- 1.A.6. Do you fully understand how to operate your new bicycle? If not, before your first ride, have your dealer explain any functions or features which you do not understand.

1.B. SAFETY FIRST

- 1.B.1. Always wear an approved helmet when riding your bike, and follow the helmet manufacturer's instructions for fit, use and care.
- 1.B.2. Do you have all the other required and recommended safety equipment? (See section 2). It's your responsibility to familiarize yourself with the laws of the areas where you ride, and to comply with all applicable laws.
- 1.B.3. Do you know how to correctly operate your wheel quick releases? Check section 4.B.1 To make sure. Riding with an improperly adjusted wheel quick release can cause the wheel to wobble or disengage from the bicycle, and cause serious injury or death.
- 1.B.4. If your bike has toe clips and straps or clipless ("step-in") pedals, make sure you know how they work (see section 4.E). These pedals require special techniques and skills. Follow the pedal manufacturer's instructions for use, adjustment and care.
- 1.B.5. Do you have "toe overlap"? On smaller framed bicycles your toe or toe clip may be able to contact the front wheel when a pedal is all the way forward and the wheel is turned. Read section 4.E. To check whether you have toe overlap.

1.C. MECHANICAL SAFETY CHECK

Routinely check the condition of your bicycle before every ride. Nuts, bolts screws and other fasteners: because manufacturers use a wide variety of fastener sizes and shapes made in a variety of materials, often differing by model and component, it is not possible for this manual to specify correct torque (tightening force) for each specific fastener on your bicycle. We can tell you

the importance of correct torque, but not the specific torque required for each fastener on your bicycle (see section 4.G). To correctly torque a fastener, a torque wrench must be used. A professional bicycle mechanic with a torque wrench should torque the fasteners on your bicycle. If you choose to work on your own bicycle you must get correct tightening torque specifications from the bicycle or component manufacturer or from your dealer. If you need to make an adjustment at home or in the field, we urge you to exercise care, and to have the fasteners you worked on checked by your dealer as soon as possible.

Warning: *Correct tightening force on fasteners – nuts, bolts, screws – on your bicycle is important. Too little force, and the fastener may not hold securely. Too much force, and the fastener can strip threads, stretch, deform or break. Either way, incorrect tightening force can result in component failure, which can cause you to lose control and fall. Make sure nothing is loose. Lift the front wheel off the ground by two or three inches, then let it bounce on the ground.*

1.C.1. TYRES AND WHEELS

Make sure tyres are correctly inflated (see section 4.F.1). Check by putting one hand on the saddle, one on the intersection of the handlebars and stem, then bouncing your weight on the bike while looking at tyre deflection. Compare what you see with how it looks when you know the tyres are correctly inflated; and adjust if necessary. Are both tyres in good condition? Spin each wheel slowly and look for cuts in the tread and sidewall. Replace damaged tyres before riding the bike. Are both wheels true? Spin each wheel and check for brake clearance and side-to-side wobble. If a wheel wobbles side to side even slightly, or rubs against or hits the brake pads, take the bike to a qualified bike shop to have the wheel trued.

Caution: *Wheels must be true for the brakes to work effectively. Wheel truing is a skill which requires special tools and experience. Do not attempt to true a wheel unless you have the knowledge, experience and tools needed to do the job correctly.*

Are both wheel rims clean and undamaged? Make sure the rims are clean and undamaged along the braking surface, and check for excess rim wear. (See section 5. A. 4).

1.C.2. BRAKES

Check the brakes for proper operation (see sections 4.C). Squeeze the brake levers. Are the brake quick releases closed? Are all control cables seated and securely engaged? Do the brake pads contact the wheel rim squarely and make full contact with the rim? Do the brake pads touch the wheel rim within an inch of brake lever movement? Can you apply full braking force at the levers without having them touch the handlebar? If not, your brakes need adjustment. Do not ride the bike until the brakes are properly adjusted by a professional bicycle mechanic.

1.C.3. QUICK RELEASES

Make sure the front wheel, rear wheel and seat post quick releases are properly adjusted and in the locked position. See section 4.B.

1.C.4. HANDLEBAR AND SADDLE ALIGNMENT

Make sure the saddle and handlebar stem are parallel to the bike's centre line and clamped tight enough so that you can't twist them out of alignment. See sections 3.B and 3.C.

1.C.5. HANDLEBAR ENDS

Make sure the handlebar grips are secure and in good condition. If not, have your dealer replace them. Make sure the handlebar ends and aerobar extensions are plugged. If not, have your dealer plug them before you ride. If the handlebars have aerobar extensions, make sure they are clamped tight enough so you can't twist them.

Warning: *Loose or damaged handlebar grips or aerobar extensions can cause you to lose control and fall. Unplugged handlebars or extensions can cut you and cause serious injury in an otherwise minor accident.*

1.C.6. REAR DERAILLEUR HANGER

Make sure the rear derailleur hanger is straight and undamaged. If bent or broken, have your dealer replace it before you ride. (See section 5.B).

1.D. FIRST RIDE

When you buckle on your helmet and go for your first familiarization ride on your new bicycle, be sure to pick a controlled environment, away from cars, other cyclists, obstacles or other hazards. Ride to become familiar with the controls, features and performance of your new bike. Familiarize yourself with the braking action of the bike (see section 4.C).

Test the brakes at slow speed, putting your weight toward the rear and gently applying the brakes, rear brake first.

Sudden or excessive application of the front brake could pitch you over the handlebars. Applying brakes too hard can lock up a wheel, which could cause you to lose control and fall. Skidding is an example of what can happen when a wheel locks up.

If your bicycle has toe clips or clipless pedals, practice getting in and out of the pedals. See paragraph B.4 above and section 4.E.4. Practice shifting the gears (see section 4.D). Remember to never move the shifter while pedalling backward, nor pedal backwards immediately after having moved the shifter. This could jam the chain and cause serious damage to the bicycle. Check out the handling and response of the bike for fit and comfort.

If you have any questions, or if you feel anything about the bike is not as it should be, consult your dealer before your next ride.

SECTION 2 - SAFETY

2. A. THE BASICS

Warning: Many countries require specific safety devices. It is your responsibility to familiarize yourself with the laws of the region where you ride and to comply with all applicable laws, including properly equipping yourself and your bike as the law requires. Observe all local bicycle laws and regulations. Observe regulations about bicycle lighting, reflectors, licensing of bicycles, riding on footpaths, laws regulating bike path and trail use, helmet laws, child carrier laws, and special bicycle traffic laws. It's your responsibility to know and obey the laws.

2.A.1. Always wear a cycling helmet which meets the latest certification standards and is appropriate for the type of riding you do. Always follow the helmet manufacturer's instructions for fit, use and care of your helmet. Most serious bicycle injuries involve head injuries which might have been avoided if the rider had worn an appropriate helmet.

Warning: Failure to wear a helmet when riding may result in serious injury or death.

- 2.A.2. Always do the mechanical safety check (section 1.C) before you get on a bike.
- 2.A.3. Be thoroughly familiar with the controls of your bicycle: Brakes (section 4.C.); Pedals (section 4.E.); Shifting (section 4.D.)
- 2.A.4. Be careful to keep body parts and other objects away from the sharp teeth of chainrings, the moving chain, the turning

pedals and cranks, and the spinning wheels of your bicycle.

2.A.5. Always wear:

- Shoes that will stay on your feet and will grip the pedals. Make sure that shoe laces cannot get into moving parts and never ride barefoot or in sandals.
- Bright, visible clothing that is not so loose that it can be tangled in the bicycle or snagged by objects at the side of the road or trail.
- Protective eyewear, to protect against airborne dirt, dust and bugs - tinted when the sun is bright, clear when it's not.

2.A.6. Don't jump with your bike. Jumping a bike can be fun; but it can put huge and unpredictable stress on the bicycle and its components. Riders who insist on jumping their bikes risk serious damage, to their bicycles as well as to themselves.

2.A.7. Before you attempt to jump or race with your bike, read and understand section 2.E.

2.A.8. Ride at a speed appropriate for current conditions and surroundings. Increased speed means higher risk.

2.B. RIDING SAFETY

2.B.1. You are sharing the road or the path with others - motorists, pedestrians and other cyclists. Respect their rights.

2.B.2. Ride defensively. Always assume that others do not see you

2.B.3. Look ahead, and be ready to avoid:

- Vehicles slowing or turning, entering the road or your lane ahead of you, or coming up behind you.

- Parked car doors opening.
 - Pedestrians stepping out.
 - Children or pets playing near the road.
 - Pot holes, sewer grating, railroad tracks, expansion joints, road or sidewalk construction, debris and other obstructions that could cause you to swerve into traffic, catch your wheel or cause you to have an accident.
 - The many other hazards and distractions which can occur on a bicycle ride.
- 2.B.4. Ride in designated bike lanes, on designated bike paths or as close to the edge of the road as possible, in the direction of traffic flow or as directed by local governing laws.
- 2.B.5. Stop at stop signs and traffic lights; slow down and look both ways at street intersections. Remember that a bicycle always loses in a collision with a motor vehicle, so be prepared to yield even if you have the right of way.
- 2.B.6. Use approved hand signals for turning and stopping.
- 2.B.7. Never ride with headphones. They mask traffic sounds and emergency vehicle sirens, distract you from concentrating on what is going on around you, and their wires can tangle in the moving parts of the bicycle, causing you to lose control.
- 2.B.8. Never carry a passenger, unless it is a small child wearing an approved helmet and secured in a correctly mounted child carrier or a child carrying trailer.
- 2.B.9. Never carry anything which obstructs your vision or your complete control of the bicycle, or which could become
- 2.B.10. Never hitch a ride by holding on to another vehicle.
- 2.B.11. Don't do stunts, wheelies or jumps. If you intend to do stunts, wheelies, jumps or go racing with your bike despite our advice not to, read Section 2.E, Competition, now. Think carefully about your skills before deciding to take the large risks that go with this kind of riding.
- 2.B.12. Don't weave through traffic or make any moves that may surprise people with whom you are sharing the road.
- 2.B.13. Observe and yield the right of way.
- 2.B.14. Never ride your bicycle while under the influence of alcohol or drugs.
- 2.B.15. If possible, avoid riding in bad weather, when visibility is obscured, at dawn, dusk or in the dark, or when extremely tired. Each of these conditions increases the risk of accident.
- 2.B.16. Always carry some form of identification, so that people know who you are in case of an accident; and take along some cash for a candy bar, a cool drink or an emergency phone call.

2.C. WET WEATHER RIDING

Warning: *Wet weather impairs traction, braking and visibility, both for the cyclist and for other vehicles sharing the road. The risk of an accident is dramatically increased in wet conditions.*

Under wet conditions, the stopping power of your brakes (as well as the brakes of other vehicles sharing the road) is dramatically reduced and your tires don't grip nearly as well. This makes it harder to control speed and easier to lose control. To make sure that you can slow down and stop safely in wet conditions, ride

more slowly and apply your brakes earlier and more gradually than you would under normal, dry conditions. See also Section 4.C.

2.D. RIDING AT NIGHT

Riding a bicycle at night is many times more dangerous than riding during the day. A cyclist is very difficult for motorists and pedestrians to see. Therefore, children should never ride at dawn, at dusk or at night. Adults who choose to accept the greatly increased risk of riding at dawn, at dusk or at night need to take extra care both riding and choosing specialist equipment which helps reduce that risk. Consult your dealer about night riding safety equipment.

Warning: Reflectors are not a substitute for required lights. Riding at dawn, at dusk, at night or at other times of poor visibility without an adequate bicycle lighting system is dangerous and may result in serious injury or death.

Bicycle reflectors are designed to pick up and reflect car lights and street lights in a way that may help you to be seen and recognized as a moving cyclist.

Caution: Check reflectors and their mounting brackets regularly to make sure that they are clean, straight, unbroken and securely mounted. Have your dealer replace damaged reflectors and straighten or tighten any that are bent or loose.

Warning: Do not remove the installed front or rear reflectors or reflector brackets from your bicycle. They are an integral part of the bicycle's safety system. Removing the reflectors may reduce your visibility to others using the roadway. Being struck by other vehicles may result in serious injury or death.

If you choose to ride under conditions of poor visibility, check and be sure you comply with all local laws about night riding, and take the following strongly recommended additional precautions:

- Purchase and install battery or generator powered head and tail lights which meet all regulatory requirements and provide adequate visibility.
- Wear light coloured, reflective clothing and accessories, such as a reflective vest, reflective arm and leg bands, reflective stripes on your helmet, flashing lights attached to your body and/or your bicycle. Any reflective device or light source that moves will help you get the attention of approaching motorists, pedestrians and other traffic.
- Make sure your clothing or anything you may be carrying on the bicycle does not obstruct a reflector or light.
- Make sure that your bicycle is equipped with correctly positioned and securely mounted reflectors.

While riding at dawn, at dusk or at night:

- Ride slowly.
- Avoid dark areas and areas of heavy or fast-moving traffic.
- Avoid road hazards.
- If possible, ride on familiar routes.

If riding in traffic:

- Be predictable. Ride so that drivers can see you and predict your movements.

- Be alert. Ride defensively and expect the unexpected.
- If you plan to ride in traffic often, ask your dealer about traffic safety classes or a good book on bicycle traffic safety.

2.E. COMPETITION

By engaging in racing or aggressive riding you voluntarily assume an increased risk of injury or death. Not all bicycles are designed for these types of riding, and those that are may not be suitable for all types of aggressive riding. Check with your dealer or the bicycle's manufacturer about the suitability of your bicycle before engaging in competition. When riding fast downhill, you can reach excessive speeds and therefore face higher risks due to reduced reaction time.

- Have your bicycle and equipment carefully inspected by a qualified mechanic and be sure it is in perfect condition.
- Take your bicycle to your dealer if anything breaks or bends. Do not ride your bicycle when any part is damaged.
- Consult with expert riders and race officials on conditions and equipment advisable at the site where you plan to ride.
- Wear appropriate safety gear. Ultimately, it is your responsibility to have proper equipment and to be familiar with course conditions.

Warning: *Although many catalogues, advertisements and articles about cycling depict riders engaged in various forms of racing, this activity can be extremely dangerous, increases your risk of injury or death, and increases the severity of any injury. Remember that the action depicted is being performed by professionals with many years of training and experience. Know your limits and always wear a helmet and other appropriate safety gear. Even with state-of-the-art*

protective safety gear, you could be seriously injured or killed when riding downhill at speed or in competition.

Caution: *Bicycles and bicycle parts have limitations with regard to strength and integrity, and this type of riding can increase the likelihood of exceeding those limitations.*

2.F. CHANGING COMPONENTS

There are many components and accessories available to enhance the comfort, performance and appearance of your bicycle. However, if you change components or add accessories, you do so at your own risk. The bicycle's manufacturer may not have tested that component or accessory for compatibility, reliability or safety on your bicycle. Before installing any component or accessory, including a different size tyre, make sure that it is compatible with your bicycle by checking with your dealer. Be sure to read, understand and follow the instructions that accompany the products you purchase for your bicycle.

Warning: *Failure to confirm compatibility, properly install, operate and maintain any component or accessory can result in serious injury or death.*

Caution: *Changing the components on your bike may void the warranty. Refer to your warranty, and check with your dealer before changing the components on your bike.*

2.G. MAXIMUM WEIGHT

Vitus frames have been designed and tested to withstand very high loads, and as a result we have not traditionally assigned maximum weight restrictions for our frames. However, your

bicycle is also made up of numerous individual components, all of which have their own unique weight limits. As a result, Vitus recommends that you consult your dealer to ensure that all components selected for use on your bicycle are suitable and safe for your intended use.

SECTION 3 - FIT

Note: Correct fit is an essential element of cycling safety, performance and comfort. To make the adjustments to your bicycle, which result in correct fit for your body and riding conditions, requires experience, skill and special tools. Always have your dealer make the adjustments on your bicycle; or, if you have the experience, skill and tools, have your dealer check your work before riding. The fit suggestions below are based solely on safety concerns. They specify the absolute minimum standards to ride the bike, but by no means do they guarantee optimal performance. Much more elaborate fit requirements are necessary to ensure optimal performance. For the additional performance fitting requirements, please consult with your dealer.

Warning: *If your bicycle does not fit properly, you may lose control and fall. If your new bike doesn't fit, ask your dealer to exchange it before you ride it.*

3.A. STANDOVER HEIGHT

Standover height is the basic element of bike fit. It is the distance from the ground to the top of the bicycle's frame at that point where your crotch is when straddling the bike. To check for correct standover height, straddle the bike while wearing the kind of shoes in which you'll be riding, and bounce vigorously on your heels. If your crotch touches the frame, the bike is too big for you. Don't even ride the bike around the block. A bike which you ride only on paved surfaces and never take offroad should give you a minimum standover height clearance of two inches (5cm). A bike that you'll ride on unpaved surfaces should give you a minimum of three inches (7.5cm) of standover height clearance. And a bike that you'll use off road should give you four inches (10cm) or more

of clearance.

Warning: *If you plan to use your bike for jumping or competition, read Section 2.E again.*

3.B. SADDLE POSITION

Correct saddle adjustment is an important factor in getting the most performance and comfort from your bicycle. If the saddle position is not comfortable for you, see your dealer.

The saddle can be adjusted in three directions:

3.B.1. UP AND DOWN ADJUSTMENT

To check for correct saddle height:

- Sit on the saddle;
- Place one heel on a pedal;
- Rotate the crank until the pedal with your heel on it is in the down position and the crank arm is parallel to the seat tube.

If your leg is not completely straight, your saddle height needs to be adjusted. If your hips must rock for the heel to reach the pedal, the saddle is too high. If your leg is bent at the knee with your heel on the pedal, the saddle is too low.

Once the saddle is at the correct height, make sure that the seatpost does not project from the frame beyond its "Minimum Insertion" mark, which means that the minimum insertion mark should never be visible above the frame once adjusted to your correct position. If the "Minimum Insertion" mark is visible once

your saddle is properly adjusted, contact your dealer to have the seatpost replaced with a longer one.

Warning: *If your seat post projects from the frame beyond the Minimum Insertion or Maximum Extension mark, the seat post may break, which could cause you to lose control and fall.*

Note that some seatposts also have a second insertion mark entitled “Maximum Insertion”. If present on your bicycle, your seatpost should never be lowered into the frame beyond the “Maximum Insertion” point, meaning that this line must always be visible above the frame once the saddle is properly adjusted. If the “Maximum Insertion” mark is no longer visible once your saddle is properly adjusted, contact your dealer to have the seatpost replaced with a shorter one.

Warning: *If your seat post is inserted into the frame beyond the Maximum Insertion mark, the seat post may break, which could cause you to lose control and fall.*

Minimum saddle height is defined as the smallest possible distance between the centre of the bottom bracket and the top of the saddle on a given bicycle. It can be measured along the plane of the seat tube from the top of the saddle to the centre of the crank axle. Several factors can influence the minimum saddle height including thickness of the saddle, design of the seatpost clamp, seatpost length, frame size, and frame design. Vitus does not specify the minimum saddle height on our standard geometry tables due to the variability of this dimension with component changes; instead we recommend consulting your dealer to assist in determining appropriate sizing and in fitting your bicycle to you.

3.B.2. FRONT AND BACK ADJUSTMENT

The saddle can be adjusted forward or back to help you get the optimal position on the bike. Ask your dealer to set the saddle for your optimal riding position and to show you how to make this adjustment.

3.B.3. SADDLE ANGLE ADJUSTMENT

Most people prefer a horizontal saddle; but some riders like the saddle nose angled up or down just a little. Your dealer can adjust saddle angle or teach you how to do it. Small changes in saddle position can have a substantial effect on performance and comfort. To find your best saddle position, make only one adjustment at a time.

Warning: *After any saddle adjustment, be sure that the saddle adjusting mechanism is properly tightened before riding. A loose saddle clamp or seat post binder can cause damage to the seat post, or can cause you to lose control and fall. A correctly tightened saddle adjusting mechanism will allow no saddle movement in any direction. Periodically check to make sure that the saddle adjusting mechanism is properly tightened.*

If, in spite of carefully adjusting the saddle height, tilt and fore-and-aft position, your saddle is still uncomfortable, you may need a different saddle design. Saddles, like people, come in many different shapes, sizes and resilience. Your dealer can help you select a saddle which, when correctly adjusted for your body and riding style, will be comfortable.

Warning: *Some people have claimed that extended riding with a saddle which is incorrectly adjusted or which does not support your*

pelvic area correctly can cause short-term or long-term injury to nerves and blood vessels, or even impotence. If your saddle causes you pain, numbness or other discomfort, listen to your body and stop riding until you see your dealer about saddle adjustment or a different saddle.

3.C. HANDLEBAR HEIGHT AND ANGLE

Your bike is equipped with a “threadless” stem, which clamps on to the outside of the steerer tube. Your dealer may be able to change handlebar height by moving height adjustment spacers from below the stem to above the stem, or vice versa. Otherwise, you’ll have to get a stem of different length or rise. Consult your dealer.

Do not attempt to do this yourself, as it requires special Knowledge.

Warning: *Exceeding the maximum spacer height can result in damage to the fork’s steerer tube, which could cause you to lose control and fall.*

Warning: *On some bicycles, changing the stem or stem height can affect the tension of the front brake cable, locking the front brake or creating excess cable slack which can make the front brake inoperable. If the front brake pads move in towards the wheel rim or out away from the wheel rim when the stem or stem height is changed, the brakes must be correctly adjusted before you ride the bicycle.*

Warning: *The top of the stem where fitted over the fork steerer tube must not extend more than 5mm above the top of the steerer. If the stem is extended beyond this height the stem may break or damage the fork’s steerer tube, which could cause you to lose control and fall.*

Your dealer can also change the angle of the handlebar or aerobar extensions.

Warning: *An insufficiently tightened stem binder bolt, handlebar binder bolt or aerobar extension clamping bolt may compromise steering action, which could cause you to lose control and fall. Place the front wheel of the bicycle between your legs and attempt to twist the handlebar/ stem assembly. If you can twist the stem in relation to the front wheel, turn the handlebars in relation to the stem, or turn the aerobar extensions in relation to the handlebar, the bolts are insufficiently tightened.*

3.D. CONTROL POSITION ADJUSTMENTS

The angle of the brake and shift control levers and their position on the handlebars can be changed. Ask your dealer to make the adjustments for you.

3.E. BRAKE REACH

Many bikes have brake levers which can be adjusted for reach. If you have small hands or find it difficult to squeeze the brake levers, your dealer can either adjust the reach or fit shorter reach brake levers.

Warning: *The shorter the brake lever reach, the more critical it is to have correctly adjusted brakes, so that full braking power can be applied within available brake lever travel. Brake lever travel insufficient to apply full braking power can result in loss of control, which may result in serious injury or death.*

SECTION 4 - TECHNICAL

It's important to your safety, performance and enjoyment to understand how things work on your bicycle. We urge you to ask your dealer how to do the things described in this section before you attempt them yourself, and that you have your dealer check your work before you ride the bike. If you have even the slightest doubt as to whether you understand something in this section of the manual, talk to your dealer.

4.A. INITIAL ASSEMBLY

Vitus bicycles are shipped from the factory to the dealer only partially assembled. Your dealer will complete the assembly of the bicycle, and perform any adjustments required to make it fit you. It is strongly recommended that you allow your dealer to perform the assembly and fitting operations, as it requires specific knowledge of each part, appropriate tools, and understanding of the interactions of various materials. Your bicycle is a high performance machine, much like a racing car, and as such requires skilled maintenance in order to function safely and effectively.

Your dealer will perform the following assembly operations before your bicycle is delivered to you:

- 4.A.1. Fork cut to appropriate length.
- 4.A.2. Headset and stem installed and adjusted.
- 4.A.3. Handlebars clamped into stem.
- 4.A.4. Brake/shift levers installed onto handlebars.

- 4.A.5. Front brake installed on fork.
- 4.A.6. Brake and shifter cables threaded and attached.
- 4.A.7. Brakes and derailleur adjusted.
- 4.A.8. Handlebars wrapped with bar tape and plugged.
- 4.A.9. Seat and seatpost installed.
- 4.A.10. Wheels installed.
- 4.A.11. Pedals (of your choice) installed.

If you choose to perform any assembly operations yourself, ensure that all operations are done in accordance with the specific assembly instructions published by the component manufacturer. These assembly instructions are included in the bike box provided to your dealer. Alternatively, assembly instructions are usually posted on the component manufacturer's websites, or are available from their service departments.

4.B. WHEELS

4.B.1. WHEEL QUICK RELEASE

Warning: *Riding with an improperly adjusted wheel quick release can allow the wheel to wobble or fall off the bicycle, which can cause serious injury or death. Therefore, it is essential that you:*

- *Ask your dealer to help you make sure you know how to install and remove your wheels safely.*
- *Understand and apply the correct technique for clamping your wheel in place with a quick release.*
- *Each time, before you ride the bike, check that the wheel is securely clamped.*

The wheel Quick Release uses a cam action to clamp the bike's wheel in place (see fig. 5). Because of its adjustable nature, it is critical that you understand how it works, how to use it properly, and how much force you need to apply to secure the wheel.

Warning: *The full force of the cam action is needed to clamp the wheel securely. Holding the nut with one hand and turning the lever like a wing nut with the other hand until everything is as tight as you can get it will not clamp the wheel safely in the dropouts.*

4.B.1.A. ADJUSTING THE QUICK RELEASE MECHANISM

The wheel hub is clamped in place by the force of the quick release cam pushing against one dropout and pulling the tension adjusting nut, by way of the skewer, against the other dropout. The amount of clamping force is controlled by the tension adjusting nut. Turning the tension adjusting nut clockwise while keeping the cam lever from rotating increases clamping force; turning it counter-clockwise while keeping the cam lever from rotating reduces clamping force. Less than half a turn of the tension adjusting nut can make the difference between safe clamping force and unsafe clamping force.

4.B.1.B. FRONT WHEEL SECONDARY RETENTION DEVICES

Most bicycles have front forks which utilize a secondary wheel retention device to reduce the risk of the wheel disengaging from the fork if the quick release is incorrectly adjusted. Secondary retention devices are not a substitute for correct quick release adjustment.

Secondary retention devices fall into two basic categories:

- 4.B.1.B.1. The clip-on type is a part which the manufacturer adds to the front wheel hub or front fork.
- 4.B.1.B.2. The integral type is moulded, cast or machined into the outer faces of the front fork dropouts.

Ask your dealer to explain the particular secondary retention device on your bike.

Warning: *Do not remove or disable the secondary retention device. As its name implies, it serves as a back-up for a critical adjustment. If the quick release is not adjusted correctly, the secondary retention device can reduce the risk of the wheel disengaging from the fork. Removing or disabling the secondary retention device may also void the warranty. Secondary retention devices are not a substitute for correct quick release adjustment. Failure to properly adjust the quick release mechanism can cause the wheel to wobble or disengage which could cause you to lose control and fall, resulting in serious injury or death.*

4.B.2. REMOVING AND INSTALLING QUICK RELEASE WHEELS

4.B.2.A. REMOVING A QUICK RELEASE FRONT WHEEL

- 4.B.2.A.1. If your bike has rim brakes, disengage the brake's quick-release mechanism to increase the clearance between the 12 tyre and the brake pads.
- 4.B.2.A.2. Move the wheel's quick-release lever from the locked or CLOSED position to the OPEN position (fig. 6).
- 4.B.2.A.3. Quick release levers should be embossed with the words "OPEN" and "CLOSED" to indicate the current position of the lever.

4.B.2.A.4. If your front fork does not have a secondary retention device go to step (5).

4.B.2.A.5. If your front fork has a clip-on type secondary retention device, disengage it and go to step (5). If your front fork has an integral secondary retention device, loosen the tension adjusting nut enough to allow removing the wheel; then go to the next step.

Raise the front wheel a few inches off the ground and tap the top of the wheel with the palm of your hand to release the wheel from the front fork.

4.B.2.B. INSTALLING A QUICK RELEASE FRONT WHEEL

4.B.2.B.1. Move the quick-release lever so that it curves away from the wheel. This is the OPEN position.

4.B.2.B.2. With the steering fork facing forward, insert the wheel between the fork blades so that the axle seats firmly at the top of the slots which are at the tips of the fork blades - the fork dropouts. The quick-release lever should be on the left side of the bicycle. If your bike has a clip-on type secondary retention device, engage it.

4.B.2.B.3. Holding the quick-release lever in the OPEN position with your right hand, tighten the tension adjusting nut with your left hand until it is finger tight against the fork dropout

4.B.2.B.4. While pushing the wheel firmly to the top of the slots in the fork dropouts, and at the same time centering the wheel rim in the fork, move the quick-release lever upwards and swing it into the CLOSED position. The lever should now be parallel to the fork blade and curved toward the wheel. To apply enough clamping force, you should have to wrap your

fingers around the fork blade for leverage, and the lever should leave a clear imprint in the palm of your hand.

Warning: *Securely clamping the wheel takes considerable force. If you can fully close the quick release without wrapping your fingers around the fork blade for leverage, and the lever does not leave a clear imprint in the palm of your hand, the tension is insufficient. Open the lever; turn the tension adjusting nut clockwise a quarter turn; then try again.*

4.B.2.B.5. If the lever cannot be pushed all the way to a position parallel to the fork blade, return the lever to the OPEN position. Then turn the tension adjusting nut counter clockwise one-quarter turn and try tightening the lever again.

4.B.2.B.6. Re-engage the brake quick-release mechanism to restore correct brake pad-to-rim clearance; spin the wheel to make sure that it is centred in the frame and clears the brake pads; then squeeze the brake lever and make sure that the brakes are operating correctly.

4.B.2.C. REMOVING A QUICK RELEASE REAR WHEEL

4.B.2.C.1. Shift the rear derailleur to high gear (the smallest, outermost rear sprocket).

4.B.2.C.2. If your bike has rim brakes, disengage the brake's quick-release mechanism to increase the clearance between the wheel rim and the brake pads.

4.B.2.C.3. Pull the derailleur body back with your right hand.

4.B.2.C.4. Move the quick-release lever to the OPEN position.

4.B.2.C.5. Lift the rear wheel off the ground a few inches and, with

the derailleur still pulled back, push the wheel forward and down until it comes out of the rear dropouts.

4.B.2.D. INSTALLING A QUICK RELEASE REAR WHEEL

- 4.B.2.D.1. Make sure that the rear derailleur is still in its outermost, high gear, position .
- 4.B.2.D.2. Pull the derailleur body back with your right hand.
- 4.B.2.D.3. Move the quick-release lever to the OPEN position.
The lever should be on the side of the wheel opposite the derailleur and freewheel sprockets.
- 4.B.2.D.4. Put the chain on top of the smallest freewheel sprocket. Then, insert the wheel up and back into the frame dropouts and pull it all the way in to the dropouts.
- 4.B.2.D.5. Tighten the quick-release adjusting nut until it is finger tight against the frame dropout; then swing the lever toward the front of the bike until it is parallel to the frame's chainstay or seatstay and is curved toward the wheel. To apply enough clamping force, you should have to wrap your fingers around a frame tube for leverage, and the lever should leave a clear imprint in the palm of your hand.

Warning: *Securely clamping the wheel takes considerable force. If you can fully close the quick release without wrapping your fingers around the seatstay or chainstay for leverage, and the lever does not leave a clear imprint in the palm of your hand, the tension is insufficient. Open the lever; turn the tension adjusting nut clockwise a quarter turn; then try again. The rear wheel must be secured to the bicycle frame with sufficient force so that it cannot be pulled forward by the chain, even under the greatest pedaling force. If the wheel moves under pedaling force, the tyre can touch the frame, which can cause*

you to lose control and fall.

- 4.B.2.D.6. If the lever cannot be pushed all the way to a position parallel to the chainstay or seatstay tube, return the lever to the OPEN position. Then turn the adjusting nut counter clockwise one-quarter turn and try tightening again.
- 4.B.2.D.7. Push the rear derailleur back into position.
- 4.B.2.D.8. Re-engage the brake quick-release mechanism to restore correct brake pad-to-rim clearance; spin the wheel to make sure that it is centered in the frame and clears the brake pads; then squeeze the brake lever and make sure that the brakes are operating correctly.

4. C. BRAKES

Warning:

1. *Riding with improperly adjusted brakes or worn brake pads is dangerous and can result in serious injury or death.*
2. *Applying brakes too hard or too suddenly can lock up a wheel, which could cause you to lose control and fall. Sudden or excessive application of the front brake may pitch the rider over the handlebars, which may result in serious injury or death.*
3. *See the brake manufacturer's instructions for operation and care of your brakes. If you do not have the manufacturer's instructions, see your dealer or contact the brake manufacturer.*

4.C.1. BRAKE CONTROLS AND FEATURES

It's very important to your safety that you learn and remember which brake lever controls which brake on your bike.

Vitus bicycles will be set up by the dealer initially so that the left

hand brake lever controls the rear brake, and the right hand brake lever controls the front brake (UK specification), or that the right hand brake lever controls the rear brake, and the left hand brake lever controls the front brake (European specification). Make sure that your hands can reach and squeeze the brake levers comfortably. If your hands are too small to operate the levers may be adjustable; or you may need a different brake lever design.

Most brakes have some form of quick-release mechanism to allow the brake pads to clear the tyre when a wheel is removed or reinstalled. When the brake quick release is in the open position, the brakes are inoperative.

Ask your dealer to make sure that you understand the way the brake quick release works on your bike and check each time to make sure both brakes work correctly before you get on the bike.

4.C.2. HOW BRAKES WORK

The braking action of a bicycle is a function of the friction between the brake surfaces - usually the brake pads and the wheel rim or disc. To make sure that you have maximum friction available, keep your wheel rims and brake pads clean and free of dirt, lubricants, waxes or polishes. Brakes are designed to control your speed, not just to stop the bike. Maximum braking force for each wheel occurs at the point just before the wheel "locks up" (stops rotating) and starts to skid. Once the tire skids, you actually lose most of your stopping force and all directional control. You need to practice slowing and stopping smoothly without locking up a wheel. The technique is called progressive brake modulation. Instead of jerking the brake lever to the position where you think you'll generate appropriate braking force, squeeze the lever,

progressively increasing the braking force. If you feel the wheel begin to lock up, release pressure just a little to keep the wheel rotating just short of lockup. It's important to develop a feel for the amount of brake lever pressure required for each wheel at different speeds and on different surfaces. To better understand this, experiment a little by walking your bike and applying different amounts of pressure to each brake lever, until the wheel locks.

When you apply one or both brakes, the bike begins to slow, but your body wants to continue at the speed at which it was going. This causes a transfer of weight to the front wheel (or, under heavy braking, around the front wheel hub, which could send you flying over the handlebars).

A wheel with more weight on it will accept greater brake pressure before lockup; a wheel with less weight will lock up with less brake pressure. So, as you apply brakes and your weight is transferred forward, you need to shift your body toward the rear of the bike, to transfer weight back on to the rear wheel; and at the same time, you need to both decrease rear braking and increase front braking force. This is even more important on descents, because descents shift weight forward.

Two keys to effective speed control and safe stopping are controlling wheel lockup and weight transfer. Practice braking and weight transfer techniques where there is no traffic or other hazards and distractions.

Everything changes when you ride on loose surfaces or in wet weather. Tyre adhesion is reduced, so the wheels have less cornering and braking traction and can lock up with less brake force. Moisture or dirt on the brake pads reduces their ability to grip. The way to maintain control on loose or wet surfaces is to go more slowly to begin with.

4.D. GEARS

Your multi-speed bicycle will have a derailleur drivetrain.

4.D.1. HOW A DERAILLEUR DRIVETRAIN WORKS

The parts of the gear-changing mechanism include:

- A rear cassette or freewheel sprocket cluster
- A rear derailleur
- Usually a front derailleur
- One or two shifters
- One, two or three front sprockets called chainrings
- A drive chain

4.D.1.A. SHIFTING GEARS

There are several different types and styles of shifting controls: levers, twist grips, triggers, combination shift/brake controls and push-buttons. Ask your dealer to explain the type of shifting controls that are on your bike, and to show you how they work. The vocabulary of shifting can be pretty confusing. A downshift is a shift to a “lower” or “slower” gear, one which is easier to pedal. An upshift is a shift to a “higher” or “faster”, harder to pedal gear. What’s confusing is that what’s happening at the front derailleur is the opposite of what’s happening at the rear derailleur (for details, read the instructions on Shifting the Rear Derailleur and Shifting the Front Derailleur below). For example, you can select a gear which will make pedalling easier on a hill (make a downshift) in one of two ways: shift the chain down the gear “steps” to a smaller gear at the front, or up the gear “steps” to a larger gear at the

rear. So, at the rear gear cluster, what is called a downshift looks like an upshift. The way to keep things straight is to remember that shifting the chain in towards the centerline of the bike is for accelerating and climbing and is called a downshift. Moving the chain out or away from the centerline of the bike is for speed and is called an upshift. Whether upshifting or downshifting, the bicycle derailleur system design requires that the drive chain be moving forward and be under at least some tension. A derailleur will shift only if you are pedalling forward.

Warning: *Never move the shifter while pedaling backward, nor Pedal backwards immediately after having moved the shifter. This could jam the chain and cause serious damage to the bicycle.*

4.D.1.B. SHIFTING THE REAR DERAILLEUR

The rear derailleur is controlled by the right shifter. The function of the rear derailleur is to move the drive chain from one gear sprocket to another. The smaller sprockets on the gear cluster produce higher gear ratios. Pedaling in the higher gears requires greater pedaling effort, but takes you a greater distance with each revolution of the pedal cranks. The larger sprockets produce lower gear ratios. Using them requires less pedaling effort, but takes you a shorter distance with each pedal crank revolution. Moving the chain from a smaller sprocket of the gear cluster to a larger sprocket results in a downshift. Moving the chain from a larger sprocket to a smaller sprocket results in an upshift. In order for the derailleur to move the chain from one sprocket to another, the rider must be pedaling forward.

4.D.1.C. SHIFTING THE FRONT DERAILLEUR

The front derailleur, which is controlled by the left shifter, shifts

the chain between the larger and smaller chainrings. Shifting the chain onto a smaller chainring makes pedaling easier (a downshift). Shifting to a larger chainring makes pedaling harder (an upshift).

4.D.1.D. WHICH GEAR SHOULD I BE IN?

The combination of largest rear and smallest front gears is for the steepest hills. The smallest rear and largest front combination is for the greatest speed. It is not necessary to shift gears in sequence. Instead, find the “starting gear” which is right for your level of ability - a gear which is hard enough for quick acceleration but easy enough to let you start from a stop without wobbling - and experiment with upshifting and downshifting to get a feel for the different gear combinations. At first, practice shifting where there are no obstacles, hazards or other traffic, until you’ve built up your confidence.

Learn to anticipate the need to shift, and shift to a lower gear before the hill gets too steep. If you have difficulties with shifting, the problem could be mechanical adjustment. See your dealer for help.

Cross-chain gears should be avoided at all times as these will quickly wear out the chain, and possibly also the derailleurs, chainrings, and sprockets. Cross-chain gears occur when the chain is on both the largest chainring at the front and the largest sprocket at the rear, or alternately both the smallest chainring at the front and the smallest sprocket at the rear. These positions orient the chain at an angle with respect to the centerline of the bicycle, which places greater stress on the drivetrain components. There should be no need to resort to cross-chain gears as equivalent ratios can be found by using other combinations of front and rear gears.

Warning: *Never shift a derailleur onto the largest or the smallest sprocket if the derailleur is not shifting smoothly. The derailleur may be out of adjustment and the chain could jam, causing you to lose control and fall.*

Caution: *Never pedal for long periods in cross-chain gears as these combinations place unnecessary stress on your bicycle’s drivetrain, and may result in premature wearout and decreased performance.*

4.E. PEDALS

Vitus bicycles are not shipped with pedals, which permits the dealer and customer to select and install pedals appropriate for the intended use of the bicycle. Please consult with your dealer to ensure you have been provided all manufacturers’ documentation for the installed pedals, and take responsibility to ensure that you have read and fully understand all documentation before riding any bicycle equipped with unfamiliar pedals.

4.E.1. Toe Overlap is when your toe can touch the front wheel when you turn the handlebars to steer while a pedal is in the forward most position. This is common on small-framed bicycles, and is avoided by keeping the inside pedal up and the outside pedal down when making sharp turns. On any bicycle, this technique will also prevent the inside pedal from striking the ground in a turn.

Warning: *Toe Overlap could cause you to lose control and fall. Ask your dealer to help you determine if the combination of frame size, crank arm length, tyre size, pedal design and shoes you choose to use results in pedal overlap. Note that component changes to your bicycle (cranks, tyres, pedals) can result in a reduction of toe-clearance; consult your dealer about any component changes and use caution when first riding the bicycle following a component change. Whether*

you have overlap or not, you must keep the inside pedal up and the outside pedal down when making sharp turns.

4.E.2. Some bicycles come equipped with pedals that have sharp and potentially dangerous surfaces. These surfaces are designed to add safety by increasing grip between the rider's shoe and the pedal. If your bicycle has this type of high-performance pedal, you must take extra care to avoid serious injury from the pedals' sharp surfaces. Based on your riding style or skill level, you may prefer a less aggressive pedal design, or chose to ride with shin pads. Your dealer can show you a number of options and make suitable recommendations.

4.E.3. Toe clips and straps are a means to keep feet correctly positioned and engaged with the pedals. The toe clip positions the ball of the foot over the pedal spindle, which gives maximum pedaling power. The toe strap, when tightened, keeps the foot engaged throughout the rotation cycle of the pedal. While toe clips and straps give some benefit with any kind of shoe, they work most effectively with cycling shoes designed for use with toe clips. Your dealer can explain how toe clips and straps work. Shoes with deep treaded soles or welts which might make it more difficult for you to remove your foot should not be used with toe clips and straps.

Warning: *Getting into and out of pedals with toe clips and straps requires skill which can only be acquired with practice. Until it becomes a reflex action, the technique requires concentration which can distract your attention and cause you to lose control and fall. Practice the use of toe clips and straps where there are no obstacles, hazards or traffic. Keep the straps loose, and don't tighten them until your technique and confidence in getting in and out of the pedals warrants it. Never ride in traffic with your toe straps tight.*

4.E.4. Clipless pedals (sometimes called "step-in pedals") are another means to keep feet securely in the correct position for maximum pedaling efficiency. They have a plate, called a "cleat," on the sole of the shoe, which clicks into a mating spring-loaded fixture on the pedal. They only engage or disengage with a very specific motion which must be practiced until it becomes instinctive. Clipless pedals require shoes and cleats which are compatible with the make and model pedal being used. Many clipless pedals are designed to allow the rider to adjust the amount of force needed to engage or disengage the foot. Follow the pedal manufacturer's instructions, or ask your dealer to show you how to make this adjustment. Use the easiest setting until engaging and disengaging becomes a reflex action, but always make sure that there is sufficient tension to prevent unintended release of your foot from the pedal.

Warning: *Clipless pedals are intended for use with shoes specifically made to fit them and are designed to firmly keep the foot engaged with the pedal. Using shoes which do not engage the pedals correctly is dangerous.*

Practice is required to learn to engage and disengage the foot safely. Until engaging and disengaging the foot becomes a reflex action, the technique requires concentration which can distract your attention and cause you to lose control and fall. Practice engaging and disengaging clipless pedals in a place where there are no obstacles, hazards or traffic; and be sure to follow the pedal manufacturer's setup and service instructions. If you do not have the manufacturer's instructions, see your dealer or contact the manufacturer for advice.

4.F. TYRES AND TUBES

4.F.1. TYRES

Bicycle tyres are available in many designs and specifications, ranging from general-purpose designs to tyres designed to perform best under very specific weather or terrain conditions. If, once you've gained experience with your new bike, you feel that a different tyre might better suit your riding needs, your dealer can help you select the most appropriate design.

The size, pressure rating, and on some high performance tyres the specific recommended use, are marked on the sidewall of the tyre. The part of this information which is most important to you is tyre pressure.

Warning: *Never inflate a tyre beyond the maximum pressure marked on the tyre's sidewall.*

Exceeding the recommended maximum pressure may blow the tyre off the rim, which could cause damage to the bike and injury to the rider and bystanders.

The best and safest way to inflate a bicycle tyre to the correct pressure is with a bicycle pump which has a built-in pressure gauge.

Warning: *There is a safety risk in using service station air hoses or other air compressors. They are not made for bicycle tyres. They move a large volume of air very rapidly, and will raise the pressure in your tyre very rapidly, which could cause the tube to explode.*

Tyre pressure is given either as maximum pressure or as a pressure range. How a tyre performs under different terrain or

weather conditions depends largely on tyre pressure. Inflating the tyre to near its maximum recommended pressure gives the lowest rolling resistance; but also produces the harshest ride. High pressures work best on smooth, dry pavement.

Very low pressures, at the bottom of the recommended pressure range, give the best performance on smooth, slick terrain such as hard-packed clay, and on deep, loose surfaces such as deep, dry sand. Tyre pressure that is too low for your weight and the riding conditions can cause a puncture of the tube by allowing the tyre to deform sufficiently to pinch the inner tube between the rim and the riding surface.

Caution: *Pencil type automotive tyre gauges can be inaccurate and should not be relied upon for consistent, accurate pressure readings. Instead, use a high quality dial gauge.*

Ask your dealer to recommend the best tyre pressure for the kind of riding you will most often do, and have the dealer inflate your tyres to that pressure. Then, check inflation as described in Section 1.C so you'll know how correctly inflated tyres should look and feel when you don't have access to a gauge. Some tyres may need to be brought up to pressure every week or two. Some special high-performance tyres have unidirectional treads. Their tread pattern is designed to work better in one direction than in the other. The sidewall marking of a unidirectional tyre will have an arrow showing the correct rotation direction. If your bike has unidirectional tyres, be sure that they are mounted to rotate in the correct direction.

4.F.2. TYRE VALVES

There are primarily two kinds of bicycle tube valves: The Schraeder Valve and the Presta Valve. The bicycle pump you use must have

the fitting appropriate to the valve stems on your bicycle.

The Schraeder valve is like the valve on a car tyre. To inflate a Schraeder valve tube, remove the valve cap and clamp the pump fitting onto the end of the valve stem. To let air out of a Schraeder valve, depress the pin in the end of the valve stem with the end of a key or other appropriate object.

The Presta valve has a narrower diameter and is only found on bicycle tyres. To inflate a Presta valve tube using a Presta headed bicycle pump, remove the valve cap; unscrew (counter clockwise) the valve stem lock nut; and push down on the valve stem to free it up. Then push the pump head on to the valve head, and inflate. To inflate a Presta valve with a Schraeder pump fitting, you'll need a Presta adapter (available at your bike shop) which screws on to the valve stem once you've freed up the valve. The adapter fits into the Schraeder pump fitting. Close the valve after inflation. To let air out of a Presta valve, open up the valve stem lock nut and depress the valve stem.

Warning: *Patching a tube is an emergency repair. If you do not apply the patch correctly or apply several patches, the tube can fail, resulting in possible tube failure, which could cause you to lose control and fall. Replace a patched tube as soon as possible.*

4.F.3. CLINCHER AND TUBULAR TYRES

There are primarily two kinds of bicycle tyres: The Clincher tyre and the Tubular tyre. Clincher tyres are shaped like a "U" in cross section, with wire or Kevlar beads on the outer edge of both sides that hook onto the rim and hold the tyre in place on the wheel over the inner tube. Tubular tyres do not have beads – the outer edges of the tyre are sewn together around the inner tube, which is then glued to the rim to hold it in place.

Your Vitus bicycle will be equipped with clincher tyres from the factory, however many riders may wish to purchase a second set of wheels utilising tubular tyres. If you install wheels with tubular tyres on your bicycle, it is very important that you obtain and read all safety information about tubulars from the wheel and tyre manufacturers, in particular the information on the proper technique for gluing the tyres to the rim. Improperly glued tubular tyres can separate from the rim causing a serious crash. It is up to the rider to take responsibility for ensuring their tubular wheels and tyres are safe to use.

Warning: *Improperly installed tubular tyres can separate from the rims during a ride, possibly causing a serious crash that may result in injury or death.*

4.G. TIGHTENING OF FASTENERS

Your Vitus bicycle is equipped with precision components which require precise adjustment and care in order to function properly. Whenever components are changed or adjusted on the bicycle, it is critical for safety and performance reasons that all fasteners be tightened in accordance with the listed values below. It is recommended that you permit your dealer to perform the following adjustments, as they have the proper tools and experience to ensure it is done correctly. Improper adjustments can result in safety hazards – ensure you read all applicable documentation and have the correct tools prior to attempting any adjustments yourself.

Note that prior to assembling and tightening any bolts, all threads must be generously greased with a quality, non-lithium type grease. Torque wrenches with scale appropriate for the particular torque setting are strongly recommended for tightening all threaded fasteners.

Vitus strongly recommends the use of carbon assembly compound/friction paste for all areas of clamping to carbon fibre, such as the seatpost to frame, the stem to fork, and the handlebar to stem joints. Benefits to using this paste include reduced corrosion potential, and a decrease in required clamping force needed to support a given load. The paste should be evenly spread on the carbon surface under the clamped area.

Warning: *Under-tightening or over-tightening fasteners can result in damage to the bicycle that can lead to possible failure, which could cause you to lose control and fall, resulting in injury or death.*

SECTION 5 - SERVICE

Warning: Technological advances have made bicycles and bicycle components more complex, and the pace of innovation is increasing. It is impossible for this manual to provide all the information required to properly repair and/or maintain your bicycle. In order to help minimize the chances of an accident and possible injury, it is critical that you have any repair or maintenance which is not specifically described in this manual performed by your dealer. Equally important is that your individual maintenance requirements will be determined by everything from your riding style to geographic location. Consult your dealer for help in determining your maintenance requirements.

Warning: Many bicycle service and repair tasks require special knowledge and tools. Do not begin any adjustments or service on your bicycle until you have learned from your dealer how to properly complete them. Improper adjustment or service may result in damage to the bicycle or in an accident which can cause serious injury or death.

If you want to learn to do major service and repair work on your bike:

- 5.1. Ask your dealer for copies of the manufacturer's installation and service instructions for the components on your bike, or contact the component manufacturer.
- 5.2. Ask your dealer to recommend a book on bicycle repair.
- 5.3. Ask your dealer about the availability of bicycle repair courses in your area. We recommend that you ask your dealer to check the quality of your work the first time you work on something and before you ride the bike, just to make sure that you did everything correctly. Since that will require the time of a mechanic, there may be a modest charge for this

service.

5. A. SERVICE INTERVALS

Some service and maintenance can and should be performed by the owner, and require no special tools or knowledge beyond what is presented in this manual.

The following are examples of the type of service you should perform yourself. All other service, maintenance and repair should be performed in a properly equipped facility by a qualified bicycle mechanic using the correct tools and procedures specified by the manufacturer.

- 5.A.1. Break-in Period: Your bike will last longer and work better if you break it in before riding it hard. Control cables and wheel spokes may stretch or "seat" when a new bike is first used and may require readjustment by your dealer. Your Mechanical Safety Check (Section 1.C) will help you identify some things that need readjustment.
- 5.A.2. Before every ride: Mechanical Safety Check (Section 1.C)
- 5.A.3. After every long or hard ride: if the bike has been exposed to water or grit; or at least every 100 miles: Clean the bike thoroughly and lightly oil the chain. Wipe off excess oil. Lubrication is a function of climate. Talk to your dealer about the best lubricants and the recommended lubrication frequency for your area.
- 5.A.4. After every long or hard ride or after every 10 to 20 hours of riding:
 - Squeeze the front brake and rock the bike forward and back. Everything feel solid? If you feel a clunk with

each forward or backward movement of the bike, you probably have a loose headset. Have your dealer check it.

- Lift the front wheel off the ground and swing it from side to side. Feel smooth? If you feel any binding or roughness in the steering, you may have a tight headset. Have your dealer check it.
- Inspect both rims for damage. Check the spoke-holes on the rim for any cracks that may have formed due to fatigue. If cracks are found do not ride it – take the wheel to your dealer for replacement. Also inspect the brake surface for wear (relative to other surfaces). If a noticeable amount of wear has occurred do not ride it – take the wheel to your dealer for inspection and possible replacement. Ignoring these signs of wheel wear or damage can lead to failures of the rim.
- Grab one pedal and rock it toward and away from the centre line of the bike; then do the same with the other pedal. Anything feel loose? If so, have your dealer check it.
- Take a look at the brake pads. Starting to look worn or not hitting the wheel rim squarely? Time to have the dealer adjust or replace them.
- Carefully check the control cables and cable housings. Any rust? Kinks? Fraying? If so, have your dealer replace them.
- Squeeze each adjoining pair of spokes on either side of each wheel between your thumb and index finger. Do they all feel about the same? If any feel loose, have your dealer check the wheel for tension and trueness.
- Check to make sure that all parts and accessories are

still secure, and tighten any which are not.

- Check the frame, particularly in the area around all tube joints; the handlebars; the stem; and the seatpost for any deep scratches, cracks or discolouration. These are signs of stress-caused fatigue and indicate that a part is at the end of its useful life and needs to be replaced.

Warning: Like any mechanical device, a bicycle and its components are subject to wear and stress. Different materials and mechanisms wear or fatigue from stress at different rates and have different life cycles. If a component's life cycle is exceeded, the component can suddenly and catastrophically fail, causing serious injury or death to the rider.

Scratches, cracks, fraying and discolouration are signs of stress-caused fatigue and indicate that a part is at the end of its useful life and needs to be replaced. While the materials and workmanship of your bicycle or of individual components may be covered by a warranty for a specified period of time by the manufacturer, this is no guarantee that the product will last the term of the warranty. Product life is often related to the kind of riding you do and to the treatment to which you submit the bicycle. The bicycle's warranty is not meant to suggest that the bicycle cannot be broken or will last forever. It only means that the bicycle is covered subject to the terms of the warranty.

5.A.5. As required: If either brake lever fails the Mechanical Safety Check (Section 1.C), don't ride the bike. Have your dealer check the brake. If the chain won't shift smoothly and quietly from gear to gear, the derailleur is out of adjustment. See your dealer.

5.A.6. Every 25 (hard off-road) to 50 (on-road) hours of riding: Take your bike to your dealer for a complete check-up.

5. B. IF YOUR BICYCLE SUSTAINS AN IMPACT:

- First, check yourself for injuries, and take care of them as best you can. Seek medical help if necessary.
- Next, check your bike for damage on the spot.
- Following any crash, take your bike to your dealer for a thorough check.

Warning: *A crash or other impact can put extraordinary stress on bicycle components, causing them to fatigue prematurely. Components suffering from stress fatigue can fail suddenly and catastrophically, causing loss of control, serious injury or death.*

5. C. REPLACEMENT PARTS:

Over time due to wearout of components or a desire to upgrade, it is likely that one or more components of your bicycle will need to be replaced. Please consult your dealer when choosing replacement parts – it is very important that suitable, genuine parts are selected and properly installed in order to maintain the safety and performance characteristics of your Vitus bicycle.

Warning: *Failure to select and properly install suitable, genuine replacement parts may lead to unforeseen changes in the safety and performance characteristics of your bicycle.*

It is recommended that you use dealer-recommended OEM replacement parts for any components of your bicycle that require replacement. Your Vitus was carefully designed and tested with the components provided, and changes to these parts can result in different performance characteristics.

