

ELECTRIC KETTLE EVA

STAINLESS STEEL WITH COOL TOUCH BODY

CLEARLINE[®]
APPLIANCES

life made smart!



EVA
1.8 LITRES

AUTOMATIC CUT - OFF | SINGLE TOUCH LID LOCKING | ERGONOMICALLY DESIGNED HANDLE |
UNIQUE DESIGN WITH ATTRACTIVE FINISH

IMPORTANT: Read these instructions fully before using this Appliance.
Retain these instructions for future reference.

SAFETY WARNINGS

- Please read these instructions carefully before using the jug kettle for the first time.
- Before you connect the kettle to the mains supply, make sure that the voltage indicated on the rating label, located on the bottom of the product matches the mains voltage in your home. If it does not, contact your dealer and do not use the kettle.
- The kettle will automatically switch off when the water has boiled. You may switch the kettle off before the boiling process is complete by pressing the ON/OFF button.
- After the kettle has switched off automatically (or has been switched off manually) it may need time to cool down. After 15-20 seconds, the kettle may be switched on again.
- If the kettle boils dry, allow 15 minutes to cool down before refilling with cold water. The safety cutout will automatically reset during this time.
- Place and use the kettle on a stable and flat surface.
- Ensure that the kettle is switched off before removing it from its stand.
- Never immerse the kettle or cord in water or any other liquid. Do not allow liquid to penetrate the electrical parts of this kettle.
- Prevent children from pulling on the main cord or knocking the kettle over.
- Before cleaning the kettle disconnect from the power supply and wait until it has cooled down.
- The kettle may be cleaned with a damp cloth.
- Pour away the first lot of water boiled in the kettle.
- Never fill in water more than the maximum acceptable water level.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
- Do not open the lid while water is being boiled.
- If the kettle is overfilled, boiling water may spill out.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning the use of this appliance by a person responsible for their safety.

DESCRIPTION

Model – EVA

Capacity – 1.8 L

Power – 1500 WATTS ~ 230 V



USING THE KETTLE

Switching ON – Plug the power supply cord into the mains.

Filling – To fill kettle, open the lid by pressing the button. Fill to the desired level. Close the lid by pressing it down until it clicks into place.

Switch ON – Press the On/Off switch. The neon indicator will light up.

Switching OFF – The kettle will automatically switch off when the boiling is complete. You can also manually turn off by turning off the main power supply.

Cleaning – Read the instructions in the safety warnings above. Avoid using abrasive cleaning agents.

De-Scaling – The major cause of damage to kettles is lime scale and your kettle will require regular maintenance to ensure that it continues to work properly. Limescale deposits build up over time, blocking important parts of the kettle which in turn make it stop working.

De-scaling can be done by boiling a solution of vinegar/lime-juice in the kettle a couple of times and then cleaning thoroughly.

To clean the outside of the kettle, use a soft and wet cloth.

WARRANTY

Warranty is not valid if:-

- Appliance is not used in accordance with this user manual.
- Defects caused by improper and reckless use.
- Defects caused due to reason beyond control like lightning, acts of god or damage during transportation after purchase.
- Repairs done by unauthorized personnel.
- Product used other than for domestic use.

CLEARLINE CUSTOMER SERVICE

This product carries a Warranty of 12 months from the date of purchase against defects caused by faulty workmanship and materials. The Warranty excludes defects caused by the product not being used in accordance with instructions, misuse, accidental damage and tampering with by unauthorized persons. In the event of any defect arising during Warranty Period, the same should be taken to your nearest dealer or wholesaler. It will then be taken care of as per the discretion of the company's representative. The warranty does not cover damage/defects caused by events beyond control like acts of god, lightning etc.

WARRANTY CARD

Serial No. _____

Bill No. _____

Model No. _____

EVA _____

Customer's Name : _____

Address : _____

Dealer's Name & Stamp

Date of Purchase : _____

Marketed By:

CLEARLINE APPLIANCES LIMITED

177G, Industrial Area, Phase-I, Chandigarh - 160002

Incase of any complaints

please contact: +91 172 4647707, 4626036, 4626027

Whatsapp us at : 98882 27707

or email us at customercare@clearline.co.in or

write to us at the above mentioned address

www.clearline.co.in

