

SANDWICH MAKER & GRILL

CLEARLINE[®]
APPLIANCES

life made smart!



LARGE PLATE
SIZE FOR
4 BREAD SLICES
AT A TIME


INSTRUCTION MANUAL

IMPORTANT: Please read these instructions fully before using the appliance.
Kindly retain these instructions for future reference.

IMPORTANT SAFEGUARDS

- Do not touch hot surfaces.
- Kindly make sure the voltage of the socket complies to that of the product.
- Close supervision is necessary when any appliance is used by or near children.
- Disconnect the power supply before and after using the appliance.
- Please check the power wire, plug and other components before starting the machine.
- If there is any damage to the product, please do not use the product and contact us on our customer care for further clarification and help.
- To protect against risk of electric shock, do not immerse the cord, plug or cooking unit in water or any other liquid.
- Please do not put the product in the microwave.
- The use of accessory attachments not recommended by the manufacturer may result in fire, electrical shock, or risk of injury to persons.
- Do not use outdoors or for commercial purposes.
- Do not place on or near a hot gas or electric burner or heated oven.
- This appliance is not intended to be operated by means of an external timer or separate remote control system.

KNOW YOUR SANDWICH MAKER GRILL



1. Upper Housing
2. Handle
3. Upper Plate
4. Hinge Release Lever
5. Bottom Housing
6. Ready light (Green)
7. Thermostat knob
8. Power light (Red)
9. Oil Tray
10. Bottom Plate

BEFORE FIRST USE

1. Remove all packaging.
2. Clean the Cooking Plates by wiping a sponge or a soft cloth dampened in warm water.
3. Dry with a cloth or paper towel.
4. Do not immerse the unit in water.
5. For best results, lightly coat the cooking plates with a little cooking oil or cooking spray before each use.

Note: When your Grill is heated for the first time, it may emit slight smoke or odour. This is normal with many heating appliances. This does not affect the safety of your product.

HOW TO USE

- Set the Grill Temperature Control to your desired setting.
(You may later adjust it lower or higher according to your preference)
- Close the Grill and plug it into the wall outlet, you will notice that the power indicator turns on which in turn indicates that the Grill has begun preheating.
- It will take approximately 5 minutes to reach baking temperature, the ready light will come on.
- Open the Grill, put the food on the bottom cooking plate.
- Close the Grill. The ready light will go on again.
- Cook for about 3 to 8 minutes as per taste, until the power light turns off or until completion.
- When the food is grilled, use the handle to open the lid. Remove the foods with the help of a plastic spatula/server. Never use metal tongs or a knife as these can cause damage to the non-stick coating of the cooking plates.
- Once you are finished cooking, disconnect the plug from the wall outlet and leave unit open to cool for a while.

USE AS A OPEN GRILL

- Place the Grill on a clean and flat surface where you intend to cook.
- Locate the hinge release lever on the right arm.
- With you left hand on the handle, use your right hand to slide the lever toward you.
Push the handle back until the cover rests flat on the counter. The unit will stay in this position until you lift the handle and cover to return it to the closed position.
- Use the Grill as an open grill to cook burgers, steak, poultry fish and vegetables.
- Cooking on the open grill is the most versatile method of using the Health Grill. In the open position, you have double the surface area for grill.
- You have the option of cooking different types of foods on separates without combining their flavours, or cooking large amounts of the same type of food. The open position also accommodates different cuts of meat with varying thicknesses, allowing you to cook each piece to you liking.



FLAT POSITION

CARE & MAINTENANCE

1. Always unplug the Health Grill and allow it to cool before cleaning.
2. There is no need to disassemble Health Grill for cleaning. Never immerse the Health Grill in water or place in dishwasher.
3. Wipe cooking plates with a soft cloth to remove food residue. For stuck food items, squeeze some warm water mixed with detergent over the food residue then clean with a non abrasive plastic scouring pad or place wet kitchen paper over the grill to moisten the food residue.
4. Do not use anything abrasive that can scratch or damage the non-stick coating.
5. Do not use metal utensils to remove your foods, they can damage the non-stick surface.
6. Wipe the outside of the Health Grill with a damp cloth only. Do not clean the outside with any abrasive scouring pad or steel wool, as this will damage the finish. Do not immerse in water or any other liquid.

CLEARLINE CUSTOMER SERVICE

This product carries a warranty of 12 months from the date of purchase against defects caused by faulty workmanship and materials. The warranty excludes defects caused by the product not being used in accordance with instructions, mis-use, accidental damage and tampering with by un-authorised persons. In the event of any defect arising during warranty period, the same should be taken to your nearest dealer or wholesaler. It will then be taken care of as per the discretion of the company's representative. The warranty does not cover damage/defects caused by the events beyond control like acts of god, lightning, abnormal power supply, voltage fluctuations.

WARRANTY CARD

Serial No.

Bill No.

Model No.

Customer's Name :

SANDWICH MAKER & GRILL

Address :

Date of Purchase :

Dealer's Name & Stamp

Marketed By:

CLEARLINE APPLIANCES LIMITED

177G, Industrial Area, Phase-I, Chandigarh - 160002

Incase of any complaints

please contact: +91 172 4647707, 4626036, 4626027

Whatsapp us at : 98882 27707

or email us at customercare@clearline.co.in or

write to us at the above mentioned address

www.clearline.co.in

CLEARLINE[®]
APPLIANCES

Life made smart!