



Installation, Operation and Maintenance of Indicator Post

Installation

NOTE: Ensure that the Non-rising Stem Gate Valve is in the fully open position before installing the Vertical Indicator Post.

1. Disassemble the Indicator Post

Take off the Locking Wrench. Slide off the Top Section together with the Operating Nut and the square Stem as well as the Crane Coupling and ensure that all other accessories attached from the end of the Body by loosening two Hex Cap screws and Square Nut, slide off the Body from the Standpipe by loosening two Hex Cap Screws and Hex Nut, Loosen the two Hex Cap Screws and Hex Nut, slide off the Standpipe from the Base Flange.

2. Install the Base Flange and Standpipe

Attach the Base Flange together with the Standpipe to the Post Flange of the Non-rising Stem Gate Valve using the four Cap Screws and Hex Nut.

3. Adjust the Grade Line Mark

Pull in and lower the Body over the Standpipe until the Ground Line Mark on the Body is the same height as ground level. Tighten the two Hex Cap Screws and Hex Nut.

4. Adjust the Square Stem

Lower the Stem into Body Standpipe such that the Crane Coupling fits over the Operating nut of the Non-rising Stem Gate Valve Ensure that the Stem engages the Operating Nut a minimum of 2 inches but no more than 4,5 inches. To check for correct engagement, the end of stem should be from 2 to 4, 5 inches below the top of the Body.

5. Adjust the Targets

Remove the Target Carrier Assembly from inside the Body by rotating the Operating Nut counterclockwise. The Open Target and Shut Target are adjusted up or down on the Target Carrier Assembly by pulling the middle section of the Target (Open and Shut) a small distance away from the Target Carrier Assembly and sliding the Target (Open and Shut) up or down as desired. If the Non-Rising Stem Gate Valve is opened left: move the two Open Targets to the very top of the Target Carrier Assembly. Locate the two Shut Targets according to the Non-rising Stem Gate Valve size(stem) turning distance. If the Non-rising Stem Gate Valve is opened right: move the two Shut Targets to the very top of the Target Carrier Assembly. Locate the two Open Targets according to the Non-rising Stem Gate Valve size(stem) turning distance.

6. Final Assembly and Test

Insert the Target Carrier Assembly back into the Top Section by rotating the Operating Nut clockwise, rotate until the Open Target is centered in the window of the window of the Body which corresponds with the Non-rising Stem Gate Valve being in the open position. Lower the Top Section with Target Carrier Assembly onto the Body, assuring that the Stem Engages with the Operating Nut at least 2 inches but not more than 4.5inches. Secure the Top Section to the Body by tightening the Cap Screw and Square Nut Close the Non-rising Stem Gate Valve and make sure that the Shut Target (not shown) is properly centered in the window of the Body and adjust as necessary.



Maintenance

Oil the bearing in the Top Section at least once per year by adding several drops of oil in the hole located on the top of the Operating Nut.