

# HAMMONDSPORT

## USER INSTRUCTIONS


### SPECIFICATIONS

**GANT ID:** G1680

**MOVEMENT ID:** Seiko VR32

**BATTERY:** SR920SW

### DISPLAY



### SETTING THE TIME

1. Pull the crown out to position 2.
2. Turn the crown to set hour and minute hands.
3. When the crown is pushed back to the normal position, the hands begin to run.

### SETTING THE DATE

Pull the crown to position 1 and turn counter-clockwise to adjust the date. If the date is set between 9:00 pm and 0:00 am, the date will not change correctly.

### USING THE CHRONOGRAPH

This chronograph is capable of timing 30 minutes (60 seconds x 30 times).

### MEASURING TIME WITH THE CHRONOGRAPH

1. The chronograph can be started and stopped each time button A is pressed.
2. Pressing button B while the chronograph hands are moving will stop the hands to display a split time while continuing to measure the time. Pressing button B again will release the hands.
3. Pressing button B after stopping the chronograph hands using button A resets the chronograph hands to zero.

### CHRONOGRAPH RESET

(INCL. AFTER REPLACING BATTERY)

This procedure should be performed when the chronograph second hand does not return to zero position after the chronograph has been reset, and including after the battery has been replaced.

1. Pull the crown out to position 2.
2. Press button A to set the chronograph 1/10 second hand to zero position. Press button B to set the chronograph second and minute hand to the zero position.
3. Once the hands have been zeroed, return the crown to the normal position.

\* The chronograph hands can be advanced rapidly by continuously pressing a button.

# GANT

## TIME