


Operational Manual for 3.5 Digit 5 Function



NORMAL TIME DISPLAY shows Hour/Blinking Colon / Minute

MONTH/DATE :

Push S1 button once and the display will change to Month / Date.

Note: The display changes back to NORMAL TIME DISPLAY after approximately 3 seconds.

SECONDS:

Push S1 button once when Date is displayed, or twice if NORMAL TIME is displayed, and display will change to seconds. Push the S1 button again to return to NORMAL TIME.

HOW TO SET:

Although the watch is already running, it may not have the correct time or date for your location. To correct this, follow the instructions listed below. Press S2 button. Each push of the S2 button will change the display through the order shown on the left.

SET MONTH:

Push the S2 button twice. Month will appear on the display. (The Month is shown by its number. January is the number 1, through December, which is 12.) Push the S1 button until the correct month is displayed. Each push of the S1 button will advance the month by one digit.

SET DATE:

Push the S2 button, date will appear on the display. Correct the date by pushing the S1 button.

SET HOUR:

Push the S2 button until Hour / Colon/ A (or P) is displayed. "A" means the watch is set for the morning (AM). "P" means the watch is set for the afternoon (PM). To correct the hour, push the S1 button.

SET MINUTES:

Push the S2 button until Colon/Minutes are displayed. Correct the minutes by pushing the S1 button.

RETURNING TO NORMAL TIME DISPLAY by pushing the S2 button. Push S1 button once to active the watch (colon will flash).

NOTE: If the minutes were changed in the setting mode, the seconds will be reset to 00.