



PRODUCT USAGE AND INSTRUCTIONS

KIDS' FLIP STAINLESS STEEL

INSTRUCTIONS FOR USE:

- All parts are top-rack dishwasher safe. Use a straw brush to clean the fluid passage through the lid. The straw can be removed for cleaning.
- Do not microwave, freeze, or boil.
- Not for use with hot, carbonated, or perishable liquids.
- The lid allows you to control how quickly the mouthpiece moves to the open position. Opening too quickly may cause drops of liquid to flick from the mouthpiece. Open slowly to prevent this from happening.
- Take it easy to avoid flipping them onto yourself or anywhere else.
- When opening the lid, keep fingers away from the underside of the carry loop to avoid pinching them.
- Use the lock to help avoid accidental opening. Hold the carry loop in the closed position while moving the lock.

WARNINGS:

- CHOKING HAZARD – small parts. Not for use by children under 3 years of age.
- In order to minimize bacterial growth, do not use to store warm dairy products or baby food.
- Certain liquids and other contents may build up pressure within the bottle over time, as a result of altitude changes (such as during airplane travel or while ascending mountains), or due to exposure to hot temperatures (such as leaving the bottle in a car on a hot day). Pressurized contents also may cause the spout cover to open rapidly enough to injure fingers positioned under or near the carry loop, can cause liquid to spurt from the mouthpiece upon opening or cause contents to unexpectedly leak or spray out.
- To help relieve built up pressure, loosen the lid by a quarter turn until pressure is released; then retighten the lid before drinking. Be careful as some liquid may drip, spray or leak from full bottles as pressure is released.
- Always open with caution.