SplashDrone 3+	(ADODTANT:
Smart Balance Charger User Manual	1. Charging batteries can be dangerous. Incorrect charging can result in fire, explosion
for firmware v4.0 with STORAGE mode	or the permanent damage of batteries. Always store and charge Lithium batteries at
ior minimule v4.0 with storikide mode	
	2. Ensure you read and understand this manual before using the charger.
	3: Different battery types need to be charged differently. You must ensure that the the settings of the charger match the requirements of your battery.
	4. This manual is for the SwellPro Balance Charger with version 404 firmware. The firmware version appears on the screen of the charger at power up. Updated charger
	in mivare is available at sweilprocom.
	1. Important Precautions
	1. NEVER LEAVE A BATTERY UNATTENDED DURING CHARGING OR DISCHARGING.
	2. Always operate the charger in a suitable environment 5 °C ~ 45 °C. Keep the charger
	away from heat sources, water, flammable gas and corrosive agents. 3. Ensure the charger has sufficient ventilation (recommended >50cm).
	Do not cover the charger or battery during operation. Do not place the battery on top of the charger.
	5. Do not charge non-rechargeable batteries or incompatible batteries.
	anti-flammable and non-conductive surface. Do not charge batteries on a car seat,
If your charger does not have firmware v4.0, please update the charger.	carpet or other similar surfaces. 7. Only charge compatible batteries. Charging incompatible batteries is a fire risk.
instructions and infinitiate is available at swellplotcom/download.html	 8. Do not charge or discharge a battery that has been physically damaged. 9. Do not disconnect the input line during charging. After charging has completed,
	disconnect the battery and then the input line. 10. Keep the charger clean and dry.
September 2019	11. Do not modify or disassemble the charger or batteries.
	13. Do not allow children under the age of 14 to use the charger.
SwellPro Please check www.swellpro.com for the	15. In the event of fire, disconnect the charger and use a dry powder fire extinguisher
www.sweilpro.com latest version of this manual.	to fight the fire. 2
2. Charger Features	3. Connection instructions
2. Charger Features	3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a
2. Charger Features	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely
2. Charger Features	3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger.
2. Charger Features	3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger.
2. Charger Features	3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger.
2. Charger Features	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection
2. Charger Features	3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection
2. Charger Features	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection AC input connection Connect the Balance Port Adapter and Charging cable to the charger.
7 1 2 3 4 1 2 3 4 5 6 8 9 10 1. Charge Mode 6. Balance Interface 2. Decrease 7. LCD Screen 3. Increase 8. AC Input 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating)	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection AC input connection Connect the Balance Port Adapter and Charging cable to the charger.
2. Charger Features 7 7 7 1. Charge Mode 1. Charge Mode 2. Decrease 3. Increase 3. Increase 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 1. USB Interface (for software updating) 2.1 Buttons	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection AC input connection Connect the Balance Port Adapter and Charging cable to the charger.
7 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 1 2 3 4 5 6 Balance Interface 2. Decrease 7. LCD Screen 3. Increase 8. AC Input 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating) 2.1 Buttons 10. USB Interface (for software updating)	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection AC input connection Connect the Balance Port Adapter and Charging cable to the charger.
2. Charger Features	3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection AC input connection Connect the Balance Port Adapter and Charging cable to the charger. Blance Port Adapter Connect the Balance Port Adapter and Charging cable to the charger.
2. Charger Features 7 1. Charge Mode 1. Charge Mode 6. Balance Interface 2. Decrease 7. LCD Screen 3. Increase 8. AC Input 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating) 2.1 Buttons STOP button:	Substrained of the second s
2. Charger Features	Sector 2015 Sec
2. Charger Features 7 1. Charge Mode 1. Charge Mode 2. Decrease 3. Increase 3. Increase 3. Increase 3. Increase 3. Increase 3. Increase 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating) 2.1 Buttons STOP button: - + + - + + STOP button: - Stop the current program - Change MODE	Sector 2015 Sec
2. Charger Features Image: A start of the current program 1. Charge Mode 1. Charge Mode 6. Balance Interface 2. Decrease 7. LCD Screen 3. Increase 8. AC Input 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating) 2.1 Buttons STOP button: - Stop the current program - Change MODE - button: - button:	Sector 2 States of the SplashDrone remote controller battery or S3 Goggle battery
2. Charger Features 1 1 1. Charge Mode 1. Charge Mode 2. Decrease 3. Increase 3. Increase 3. Increase 3. Increase 3. Increase 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating) 2.1 Buttons STOP button: - Stop the current program - Change MODE - button:	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection AC input connection Connect the Balance Port Adapter and Charging cable to the charger. Balance Port Adapter and Charging cable to the charger. Jung and the provided of the splash of the sp
2. Charger Features 1. Charge Mode 6. Balance Interface 2. Decrease 7. LCD Screen 3. Increase 8. AC Input 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating) STOP button: 9. Stop the current program • Change MODE • Decrease selected item value • Dutton: • Decrease selected item value • Decrease selected item value • FORWARD through menu item	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection AC input connection Connect the Balance Port Adapter and Charging cable to the charger. Balance Port Adapter Connect the Balance Port Adapter and Charging cable to the charger. JST cable for the SplashDrone remote controller battery or S3 Goggle battery Use the larger XT60 cable for the SplashDrone 3/3+ drone battery. Only ONE battery can be charged at a time. CHECK THAT THE CHARGING CABLE COLORS MATCH THE COLOR OF THE PORTS
2. Charger Features I Charge Mode 1. Charge Mode 2. Decrease 3. Increase 3. Increase 3. Increase 3. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating) STOP button: 1. Stop the current program Change MODE Image Mode	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. AC input connection AC input connection Connect the Balance Port Adapter and Charging cable to the charger. Balance Port Adapter Use the JST cable for the SplashDrone remote controller battery or S3 Goggle battery Use the larger XT60 cable for the SplashDrone 3/3+ drone battery. Only ONE battery can be charged at a time. CHECK THAT THE CHARGING CABLE COLORS MATCH THE COLOR OF THE PORTS
2. Charger Features I Charge Mode 1. Charge Mode 2. Decrease 3. Increase 3. Increase 3. Increase 3. Increase 3. Increase 4. Start/Confirm 9. DC Input (for connection to a car charging port) 5. Main Output 10. USB Interface (for software updating) 2.1 Buttons Stop button: - Stop the current program - Change MODE - button: - button: - button: - button: - BACK through menu items	 3. Connection instructions 1. The charger can be connected to an AC outlet (100~240V AC) or to a suitable high-current DC source 11~18V such as a car charging port. Normal cigarette lighter adapters do not usually have sufficient current to be safely used for this charger. Imput connection instruction AC input connection instruction Connect the Balance Port Adapter and Charging cable to the charger. Imput connection instruction Connect the Balance Port Adapter and Charging cable to the charger. Imput connection instruction Imput connection instruction



2. When connecting the battery, always check that the positive (red) and negative (black) wires are connected correctly and the connector plugs are connected to the same color ports on the charger.

3. In order to avoid short circuits, connect the charging cable to the charger before connecting the battery. When disconnecting, disconnect the battery before unplugging the cable from the charger.

4. Charging and Maintaining Batteries

- 1. It is best to charge the batteries shortly before use.
- 2. DO NOT store batteries fully charged for more than a few days
- 3. Check the state of charge of stored batteries every 3 months using
- the appropriate STORAGE program.

Connect either a 2S or 4S Lithium battery to the charger using the charge and balance connectors.





For simplicity, the SplashDrone 3/3+ Balance Charger is preloaded with six charge and maintenance programs for SwellPro batteries. Simply plug your battery in and select the correct memory program for the battery type.

Program	Function		BatteryType
[01]	CHARGING		LiHV 4S - SplashDrone 3+ Drone battery
[02]	CHARGING		LiPo 2S - Remote Controller & S3 Goggle battery
[03]	CHARGING		LiPo 4S - Older SplashDrone 3 battery
[04]	STORAGE/REPAIR		LiHV 4S - SplashDrone 3+ Drone battery
[05]	STORAGE/REPAIR		LiPo 2S - Remote Controller & S3 Goggle battery
[06]	STORA	GE/REPAIR	LiPo 4S - Older SplashDrone 3 battery
PROGRAM SE Memory Loa	I. Press the STOP button until the Memory Load menu appears.		
2. Press START to confirm.			
MEMORY LIHV [01] BAL 45 7.0A 3. Program [01] will be displayed.			
- OR	OR + 4. Press the available press availab		DECREASE or INCREASE buttons to scroll through the rograms.
START		5. When the desired charge program is displayed, press the START button to select the program.	
LiHV BAL-CH C= 8000mA	HG 4S h 7.0A	The program parameters will be displayed. In this example, program [01] is displayed.	
START		Press and hold the START button to start the charge program.	
Li4S 0.0A 1	5.8V	The charger will check the connections and then start the program	
<u> </u>			

5. Lithium Battery Storage

▲ Lithium batteries must not be stored for more than a few days fully charged. Storing lithium batteries fully charged reduces their life and their capacity.

The SwellPro Balance Charger includes a convenient STORAGE charge mode. This mode assesses the state of charge of the battery and automatically performs a balanced charge or discharge cycle to achieve the optimum storage state for Lithium batteries.

Batteries stored for an extended period of time without use should be STORAGE charged every 3 months.

Programs [04], [05] and [06] are STORAGE charge cycles for the three standard SplashDrone battery types as per the table on page 6.

6. Battery testing

The Charger can detect the voltage of a single battery, the charger input and output voltage, and the internal and external temperature of the charger. The detected information is used to determine whether the battery is damaged.



6.2 Battery Resistance Measurement	7. Other Charger Functions
PROGRAM SELECT 1. Press STOP until the Battery IR menu appears. Battery IR	The charger can charge other batteries and has other functions which may be of interest to some users.
	Main menu Submenu 1 Submenu 2 Submenu 3 Submenu 4
START 2 Connect the battery to be tested and press "START" The charger	PROCRAM SELECT STARTH LHV CHARGE 45 + + LHV VBALC VIG 45 LHV BALC VIG 45 - + LHV VBALC VIG 45 - + LHV VBALC VIG 45 LHV VBALC VIG 45 - + C=000mAh 7.0x + - 1.0x
will display the internal resistance of the battery.	Important Important <t< td=""></t<>
ternal resistance detection accuracy: $\pm 5 m\Omega$.	De battery fail our contrain a contraint
tteries a)re consumable components. Through use and age, their performance	PROCRAMSELECT STARTH Temp Cuto df Safety timer Eack-light Lipo 4.20V/C User Set ON 60 °C (140 °C) + Safety timer Eack-light Lipo 4.20V/C uar utting DECREASE Chapter timer Each uping time setting Some tingtimes setting Each uping time setting
e performace and age of Lithium batteries can be gauged by measuring the internal	ISTOP FROGRAM SELECT FROGRAM SELECT STARTH
sistance. The lower the internal resistance, the better the discharge performance of e battery.	Battery IR ECCREASE Battery internal resistance information
$D3+$ LiHV drone battery internal resistance reference value: $\leq 15m\Omega$	
SD3+ LiPO remote control battery internal resistance reference value: ≤15mΩ SD3 LiPO drone battery internal resistance reference value: ≤ 11mΩ	battery meter would be a solution
the battery ages and the number of discharge cycles increases the internal	ESTOP1 PROGRAM SELECT PROGRAM SELECT STARI]+ CHARGE 45 7.0A [02] [03] [04] [05] [06]
sistance of the battery will gradually increase and the discharge performance of the	Rad storage ECCREASE Storage settings Storage settings Storage settings
attery will decrease.	PROGRAM SELECT Memory Save transported DECREASEI Standard S 3.0A
nd it is recommended to replace the battery.	
	PROGRAM SELECT Digital Power Digital Power Digital power Power supply identition
9	10
7.1 User settings	7.2 Digital Power
PROGRAM SELECT 1. Select the User Set menu.	In Digital Power mode, the charger can be used directly as a regulated power supply
IserSet	
2. Temp. cut-off Demo. cut-off Dem	Program SELECT Press the "START" button to confirm, the current starts to flash, an Digital Power be output current is set by "," or "," range from 0.1 to 7.4. After
$\frac{1}{4} \frac{1}{4} \frac{1}$	START setting, press the "START" button to confirm, the voltage starts to
3. Press "-" or "+" to select "Safety timer". Press "START" to confirm,	flash, press the "-" or "+" button to set the output voltage. Range from $5\sim 24V$ Press the "START" button to confirm the setting Final
"START" to confirm. The time starts to flash, set by pressing "-" or "+"	press the "START" button for 2 seconds to start outputting the
"-"/"+" , press the "START" button to confirm the setting. (The built-in safety	voltage and current.
prevents the battery from overcharging if the charger cannot detect	
that the battery is fully charged.)	
A. Press "-" or "+" to select "Back-light". Press the "START" button to	
confirm, when 100% starts to flash, use the "-" or "+" button to	
"-"/"+" adjust the screen brightness, and then press the "START" button to confirm the setting.	
5. Press "-" or "+" to select "Battery end volt". Press the "START"	
with "-" or "+", press the "START" button to confirm the selection,	
and 4.20V/C starts to flash. (The default setting is LiPo 4.20V/C and LiPV/is $4.25V/C$ (Where the better under some the other start of the start o	
LIHV IS 4.35V/C. When the battery voltage reaches the set value, it	

voltage may cause battery damage or fire.

8. Error Messages & Troubleshooting

8.1 Error messages

When the charger is used incorrectly or there is a fault, the charger will prompt an error message for the user to view. As shown below:

REVERSE POLARITY	The output port is connected to the wrong terminals.	
CONNECTION BREAK	The battery is not connected to the charger correctly.	
SHORT ERROR	The charger output has been short-circuited.	
INPUT VOL ERR	The input voltage is too low	
BAT TERY CHECK LOW VOLTAGE	The total battery voltage is lower than the user settings, please check the battery type setting.	
BATTERY CHECK HIGH VOLTAGE	The battery voltage is too high, check the battery type setting.	
BATTERY VOLTAGE CELL LOW VOL	The voltage of cells of the battery is too low, check the battery's cells o by one.	ne
BATTERY VOLTAGE CELL HIGH VOL	The voltage of cells of the battery is too high, check the battery's cells one by one.	
BATTERY VOL ERR CELL CONNECT	The battery cells have been incorrectly connected. Check all connections on the balance port.	
TEMP OVER ERR	The charger has overheated. Let it cool down.	
BATTERY CHECK: BALANCE DELTA V	The voltage difference between the cells is too large, the battery may be damaged.	

13

9. Appendix				
9.1 Specifications				
Input	AC input 100-240V DC output 11V-18V			
Output Power	100W			
Battery types	LiPo, LiHV			
Output voltage	7.4-17.4V			
Charging Current	0.1-10A			
Battery Numbers	LiPo-2S, LiPo-4S, LiHV-4S			
Balance Current	400mA/cell			
Discharge current	0.1-2.0A			
Input Protection	Overcurrent			
Output Protection	Overvoltage, undervoltage, short circuit,			
	overheating, short circuit, reverse connection			
Working Temperature	5-45°C			
Size	130*115*61mm			
Weight	380g			

9.2 Warranty & After Sale Service

1. The product is covered by a 12-month warranty.

2. Warranty repairs are free of charge for one year from the date of purchase. If the customer is unable to provide valid proof of purchase, the date will be based on the internal date code of the charger.

3. For repairs after the first 12 months of use, the cost will be charged as appropriate, and the customer shall bear the round-trip shipping costs.

8.2 Troubleshooting Battery Issues

If the voltage of any cell in the battery is lower than 2.5v or the voltage difference between cells is greater than 0.22v, the charger will not charge the battery.

If a charger gives the error message "Balance Delta V", then there is too much voltage difference between individual cells within the battery. This battery condition can sometimes be corrected by the following steps.

2. Select LiPo Battery mode from the main menu. Press START to select this option. 2. Select LiPo CHARGE mode. Press START to select this option.

 Using +/- change the cell count to match the battery you are repairing. For drone batteries, select 4S

For Remote Controller/Goggle batteries, select 2S

Press START and select 2000mAh.
 Press START and select 2.0A

Press START and select 2.0A

6. Press and hold START to start the fast charge program.

7. If the charge takes longer than 2 hours, you may need to repeat the charge process until the battery charger reports the battery is FULL.

LiHV CHARGE 4S C=2000mAh 2.0A

ENSURE THE BATTERY IN NOT LEFT UNATTENDED DURING CHARGING OR REPAIR AND THAT IT DOES NOT GET HOT DURING CHARGING

8. After completing the fast charge, select the appropriate STORAGE/REPAIR program for your battery from the saved programs on page 6.

A

Although the repair may be successful, the battery may have irreversible damage due to over-discharge or age and its performance will be greatly reduced.

If you can't repair the battery through the above steps, the battery must be replaced.

DO NOT attempt to repair batteries that are visibly swollen or are soft and puffed up.

14

Warranty does not cover damage due to neglect or incorrect usage of the charger including:

1. Product damage caused by failure to use a suitable input voltage as required.

2. Damage caused by not following the instructions.

 Any man-made, accidental impact or other force majeure that causes damage to the product.

4. Modification, disassembly or modification of the internal circuit of this product without the approval of the company.

 Water immersion or intrusion, moisture or other foreign matter entering the product and causing damage.

6. Aging, bumps and scratches on the surface of the product.

The user is responsible for any consequences caused by the operation of the charger. SwellPro is not liable for the costs beyond the cost of the product and reserves the right to modify the terms of this warranty which is subject to change without notice.

9.3 Version Information

Version Comments

- 1.0 Pre-release Manual for Smart Balance Charger
- 2.0 New Manual for Smart Balance Charger
- 2.1 Added Charging connection Controller Battery
- 2.3 Updated the Manual
- 2.4 Updated Connection Instructions for the Manual
- 2.5 Updated software upgrade for the manual
- 3.0 Rewrite for new firmware including 6 memory settings

4.1 Release