

JACOB JENSEN 606



1. *Use of the chronograph:*

Press button “A” to start the chronograph.

Press button “A” again to stop it.

By pressing button “B” the chronograph will be reset to zero.

2. *Adjusting the chronograph:*

Pull out the crown completely. Then, simultaneously press buttons “A” and “B” for at least 2 seconds. The seconds counter makes a complete turn, which indicates the chronograph is in the “adjust” mode.

In this mode, press “A” to correct the seconds counter.

Now press button “B” once. The adjust mode switches to the hour counter. Press “A” to adjust the hour counter.

Press “B” again. The adjust mode switches to the minute counter. Press “A” to adjust the minute counter.

If all the hands are at the correct position, push the crown to its normal position.

3. *The various hands and counters:*

Upper left : the minute counter

Upper right : the second hand

Bottom : the hour counter

Middle : the chronograph’s second counter.