


---

# JACOB JENSEN

---



## 1. *Use of the chronograph:*

- Press button “A” to start the chronograph.
- Press button “A” again to stop it.
- By pressing button “B” the chronograph will be reset to zero.

## 2. *Adjusting the chronograph:*

- Pull out the crown completely. Then, simultaneously press buttons “A” and “B” for at least 2 seconds. The seconds counter makes a complete turn, which indicates the chronograph is in the “adjust” mode.
- In this mode, press “A” to correct the seconds counter.
- Now press button “B” once. The adjust mode switches to the hour counter. Press “A” to adjust the hour counter.
- Press “B” again. The adjust mode switches to the minute counter. Press “A” to adjust the minute counter.
- If all the hands are at the correct position, push the crown to its normal position.

## 3. *The various hands and counters:*

- Upper left : the minute counter
- Upper right : the second hand
- Bottom : the hour counter
- Middle : the chronograph’s second counter.

Cal. RONDA 5030 D

---