

# Step-by-Step Guide to Programming Your



# WDM Series Drink Mixers

## MANUAL TIMER PROGRAMMING

# 1

If programming for the first time, display will read R0:00.

If reprogramming, display will read your current customized time.



To set time, press and hold the “-” button for 3 seconds to enter the SET mode (display will blink during SET mode), SX:XX.



# 2

Use “-” & “+” buttons to scroll until you reach desired time. Wait 5 seconds and time will be set.

**NOTE:** To reset time, press and hold the “-” & “+” buttons simultaneously for 3 seconds. This will return you to (R0:00).



## ASSISTED TIMER PROGRAMMING

# 1

If programming for the first time, display will read R0:00. If the timer is already programmed, press and hold the “-” & “+” buttons simultaneously for three seconds. This will return you to (R0:00).



# 2

Mount the cup and actuate. Timer will begin to count up. When your mix has reached its desired consistency, remove the cup.

If additional blend time is needed, remount the cup within 10 seconds to continue the count to your desired blend.



# 3

Press and hold the “+” button for 3 seconds to set the time.



# Step-by-Step Guide to Programming Your



# WDM Series Drink Mixers

## Tips & Tricks

1. Press and hold the “-” or “+” button to quickly scroll through time. Time will increase in 10-second intervals.
2. Press and hold the “-” AND “+” buttons simultaneously to reset time to 0:00 and enter “R” mode.
3. Time can be programmed from 1 second to 9 minutes and 59 seconds.
4. Speeds are selected manually and cannot be programmed. Speeds can be adjusted manually during operation.
5. Pulse speed can be adjusted manually during operation.