

SonicB<sup>™</sup> is registered in Europe as a trademark of iHip Europe Ltd.

Manufactured & Distributed by: iHip Europe Ltd, Chartwell House, 292-294 Hale Lane, London, UK, HA8 8NP





#### Welcome

Thank you for choosing this sonicB product. We are driven by a common pursuit of quality and excellence in daring design and bold products. But most importantly, we're inspired by YOU.

That's why we commit to encouraging you to B – who, what, or where you choose.

B you.

# True Wireless Earphones

with rechargeable carrying case

#### 1 Welcome

.1 What's In The Box

### 2 Your True Wireless Earphones

- 2.1 Getting To Know Your Earphones & Station
- 2.2 Control Features

#### 3 Ouick Start Guide

- 3.1 Charging & Powering ON
- 3.2 Turning ON/OFF 2 Options
- 3.3 Bluetooth Pairing Method 1
- 3.4 Bluetooth Pairing Method 2
- 3.5 Single Earphone Mode

#### 4 Bluetooth Functions

- 5 All Features & Contents
- Specifications
- 7 Troubleshooting & Customer Support
- 8 Care & Maintenance
- 9 Warranty & Legal

### Welcome

1.1 What's In The Box

#### Guide Booklet



#### **True Wireless Earphones**



#### Type-C Cable



Ear Tips



SMALL

#### **Charging Case Station**



### 2 Your True Wireless Earphones


2.1 Getting To Know Your Earphones & Station

#### **A** Ear Tips

Soft silicone perfect hold ear tips.

#### **B** Charging Contacts

Small round metal pieces located on both the LEFT & RIGHT earphones & in the Charging Case Station in the designated earphones notches.





#### 2 Your True Wireless Earphones 2.2 Control Features

#### A Multi-Function Button

- Power on & off
- Pause & play music
- Answer & hand up calls - Reject calls
- Previous & next track
- Increase & decrease volume
- Use of smartphone assistant:
   Google Assistant™ · Siri®

### B Earphones Status Light

Indicates if the earphones are on/off, pairing or charging.


## Charging Case Status Light

This light will flash RED when charging and the RED light will remain on when full charged.

#### ■ Type-C Charging Port

This is the area to plug-in and charge your charging case station and earphones.





WIRELESS EARPHONES - B · WORLDLY
WIRELESS EARPHONES - B · WORLDLY

### 3 Quick Start Guide

3.1 Charging & Powering ON

- Onnect the Type-C cable (only use the provided cable) to a computer USB port or a USB wall charger. Plug the other end of the Type-C cable into the Type-C charging port (D) located on the bottom of the Charging Case Station. While charging the LED indicator light (C) will flash RED. When the battery is fully charged, the RED LED on the Charging Case Station will remain on.
- 2 Open the top of the Charging Case Station and place your earphones in their initialled/designated areas. Once properly in place the LED lights (B) on the earphones will illuminate RED and the LED indicator light (C) on the Charging Case Station will illuminate BLUE. When the earphones are fully charged the LED lights will automatically turn off.



#### NOTE: please refer to the diagram on 2.2

#### 3 **Quick Start Guide** 3.2 Turning ON/OFF - 2 Options

- The first option is when your earphones are turned off, touch and hold the Multi-Function button (A) for 3 seconds to turn ON your earphone. If your earphones are already ON, touch and hold the Multi-Function button (A) for 5 seconds to turn OFF your earphones.
- 2 The second option is when you remove your earphones from the Charging Case Station they will turn ON automatically. When you put them back in the Charging Case Station they will turn OFF automatically and begin to charge if needed.

Note: If the charging case station battery is very low the auto power-off and charge feature will not work. Charge your case until fully charged.





#### 3 Ouick Start Guide

#### 3.3 Bluetooth Pairing - Method 1

- 1 Ensure the earphones are turned off, then touch and hold the Multi-Function button (A) for 3 seconds to turn the earphones ON. The earphones will enter Bluetooth pairing mode automatically and emit a tone as the LED indicator light (B) on one of the earphones will flash BLUE and RED. Make sure your device has Bluetooth enabled.
- Ensure Bluetooth is enabled on your smartphone or music device. Your device will start searching for wireless devices. The earphones will appear as "sonicB worldly earphones" in the list of available Bluetooth devices.
- 3 Select "sonicB worldly earphones" The LED will begin to blink BLUE slowly and the earphones will emit a tone to indicate that is has been successfully paired with your device.







### 3 Quick Start Guide

### 3.4 Bluetooth Pairing - Method 2

- 1 Pick up both earphones from the Charging Case Station to power on. Your earphones will connect to one another after a few seconds and automatically enter pairing mode. One of the earphones will flash RED and BLUE steadily waiting to be paired to a device.
- 2 Ensure Bluetooth is enabled on your smartphone tablet, computer, or music device. The earphones will appear as "sonicB worldly earphones" in the list of available Bluetooth devices
- 3 Select "sonicB worldly earphones" and connect.







NOTE: please refer to the diagram on 2.2

#### 3 Quick Start Guide

3.5 Single Earphone Mode

- Remove either the RIGHT or LEFT earphone from the Charging Case Station or only turn ON one of the earphones.
- 2 After a few seconds the earphone will go into pairing mode (flashing RED& BLUE).
- 3 Open your Bluetooth setting on your device and pair again if needed. The earphone will appear as "sonicB honest earphones" in the list of available Bluetooth devices. Select "sonicB worldly earphones" and connect.







#### 4 Bluetooth Functions

**11** ANSWER & HANG UP CALLS

When there is an incoming call, touch the Multi-Function Button (A) on the RIGHT or LEFT earphone once to answer the call, touch the Multi-Function Button (A) once again to hang up the call.

2 REJECT CALLS

When there is an incoming call, touch and hold the Multi-Function button (A) on the RIGHT or LEFT earphone for 1-2 seconds to reject the call.

3 PAUSE & PLAY MUSIC

When playing music, touch the Multi-Function button (A) on the LEFT or RIGHT earphone once to pause music, touch the button once again to play music.

A NEXT & LAST TRACK

When playing music, double touch the Multi-Function button (A) on the RIGHT earphone to skip to the next track, double touch the Multi-Function button (A) on the LEFT earphone to skip to the previous track.

S VOLUME UP & DOWN

When playing music, triple touch the Multi-Function button (A) on the RIGHT earphone to increase the volume, triple touch the Multi-Function button (A) on the LEFT earphone to decrease the volume

**6** VOICE ASSISTANT

Hold the Multi Function button (A) on either the LEFT or RIGHT earphone for 1-2 seconds until you hear the "beep" prompt to activate Voice Assistant (Google Assistant™ or Siri®) on your smartphone.

#### 5 All Features & Contents



UP TO 25HRS WITH STATION: advanced tech for extended battery life & playtime



ENHANCED AUDIO upgraded acoustics





BUILT-IN MIC: handsfree talking





IN-EAR COMFORT: with comfort-fit for long listening

### Bluetooth<sup>®</sup>

#### WORKSWITHMAJORBRANDS

+ OTHER BLUETOOTH DEVICES









visit us at:

#### CONTENTS:

- True Wireless Earphones
   Charging Case Station
- · Type-C Cable
- · Extra Ear Tips
- $\cdot \, \mathsf{Quick} \, \mathsf{Start} \, \& \, \mathsf{Instruction} \, \mathsf{Guide} \,$

### 6 Specifications

5.0
2.4GHz - 2.48GHz
6mm
10m
40mAh Lithium ion each
300mAh Lithium ion
Up to 5 hours
Up to 25 hours
About 1 hour
About 1.5 hours

NOTE: Working time depends on volume levels.

- Lower volume will prolong your estimated battery life.
- Higher volume will decrease your estimated battery life.

### 7 Troubleshooting & Customer Support

Troubleshooting:	
NO POWER	Recharge your earphones using the included Charging Case Station and Type-C cable.
MUSIC IS NOT PLAYING OVER BLUETOOTH	Make sure your Bluetooth device has A2DP profile. Check if both de- vices are paired and connected over Bluetooth. Restart the earphones to reconnect your Bluetooth device.
BLUETOOTH DEVICE WILL NOT RECONNECT WITH THE EARPHONES	Navigate to your Bluetooth settings menu on your Bluetooth device, tap "sonicB worldly earphones and select "Forget". Now follow the steps to pair your device again.
THE BUTTONS ON THE TRUE WIRELESS EARPHONES ARE NOT WORKING	Turn your True Wireless Earphones off, reconnect after a few seconds.     Make sure that the Bluetooth function is activated on your Bluetooth device.
POOR SOUND RECEPTION / QUALITY OF AUDIO NOT AS GOOD	Make sure your earphones are charged.     Make sure you are within 10m of your Bluetooth device.

### 7 Troubleshooting & Customer Support

Troubleshooting continued:	
ONE EARPHONE IS NOT CONNECTED TO THE OTHER ONE	Power off both earphones by touching the Multi-Function buttor for 5 seconds. Then power both on by holding in the same button for 3 seconds. The earphones will connect automatically.
EARPHONES ARE NOT CHARGING	- Make sure the earphones are properly placed in the Charging Case Station Make sure the Charging Case Station battery is fully charged. Make sure there is no dirt or debris covering the charging conductors within the Charging Case Station or on the earphones.

### **Customer Support Info:**


Any issues or problems please reach us at: support@sonicbaudio.com

WRELESS EARPHONES - B - WORLDLY

WRELESS EARPHONES - B - WORLDLY

#### 8 Care & Maintenance

- DO NOT expose the unit to liquid, moisture, or humidity to avoid damage to the product's internal circuitry.
- DO NOT use abrasive cleaning solvents to clean the unit.
- DO NOT expose the unit to extremely high or low. temperatures as this will shorten the life of the electronic device, destroy the battery, and/or distort certain plastic parts.
- DO NOT dispose of the unit in fire as they may explode or combust
- DO NOT expose the unit to and/or use sharp objects on the earphones as this will cause scratches and damage.
- · DO NOT attempt to disassemble the unit.
- In the event that the unit does not function properly, return it to the store where it was purchased.



### 9 Warranty & Legal

The condition of this warranty and our responsibilities under this warranty are as follows: Supplier's warranty is non-transferable. This warranty is limited to the original purchaser only.

You must be able to prove the date of original purchase of the unit with a dated receipt.

• The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.

The responsibility of supplier's products shall be limited to the repair or replacement of the
product as its sole discretion.
 Specifically exempt from any warranty are limited-life consumable components subject to

normal wear and tear such as batteries, decorates and other accessories.

A supplier will not take any responsibility if the failure of the unit has resulted from accident,

abuse, misuse, or any unauthorized repair, modification or disassemble.

Modification and repair of the unit should be done by authorized and qualified service

personnel, Center or returned to the manufacturer.

This warranty give you specific legal rights, and you may also have other rights which vary

Bluetooth\* is a registered trademark owned by Bluetooth SIG Inc.

Google Assistant™ is a trademark of Google Inc.

Siri® is a trademark of Apple Inc., registered in the U.S. and other countries.

Guidelines for protection of the environment



under local laws

This appliance should not be put into the domestic garbage at the end of its useful life, but must be disposed of at a central point for recycling of electric and electronic domestic appliances.



This symbol on appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

WIRELESS EARPHONES - B · WORLDLY

WIRELESS EARPHONES - B · WORLDLY