
## X-GYM WALL RACK - 1.0 ASSEMBLY GUIDE

**VERSION: XGYM-WR-1.0** 

PART #: 5726501-C





## **WARNING!**

#### Important safety instructions for using Equipment

There is a risk assumed by the individuals who use this type of equipment. To minimize risk, you must follow these precautions:

- READ ALL INSTRUCTIONS AND WARNING LABELS COMPLETELY PRIOR TO ANY USE OR ASSEMBLY. Failure to read and follow the safety instructions and warnings within the Assembly and Maintenance Guide may result in possible serious injury or death. Use this product only for the intended uses described in the Assembly and Maintenance Guide and exercise booklet. DO NOT modify equipment in anyway. Any use other than as intended or modification of product will void any and all product warranties.
- Consult your physician before starting any exercise program. Warm up properly before engaging in resistance training. Stop exercising and consult a physician <a href="immediately">immediately</a> if you experience dizziness, nausea, faintness, chest pain, shortness of breath or any other abnormal symptoms during use of this equipment.
- Certain exercise equipment and/or equipment may not be suitable or appropriate for pregnant women, people with heart conditions, balance impairment or other pre-existing health problems. Persons with disabilities should consult a physician and obtain medical approval prior to using this product and should only use this product under close supervision. Failure to comply with these instructions will void any and all product warranties.
- Carefully inspect equipment before each use. Replace all parts at the first sign of wear or damage. Tighten all loose connections. Do not disassemble, remove any parts or components or otherwise attempt to repair this product. **DO NOT** use product if product appears damaged. **DO NOT** attempt to fix a broken or jammed machine. **Failure to comply with these instructions will void any and all product warranties.**
- Keep body and clothing clear of all moving parts. Do not put anything foreign on or near this product when in use. Wear comfortable clothing which does not impair freedom of movement. Do not wear clothing which is too loose and could get caught in moving parts.
- Make sure all spring pin adjustments are fully engaged after making an adjustment and before using the product.
- Children and pets must not be allowed near this machine. Supervise teenagers. This product is not a toy.
- If unsure of proper use of this product, contact Torque Fitness Customer service at: 763-754-7533 (8:30 am 5:00 pm CST). or www.service@torquefitness.com

#### **Important Safety Instructions for Assembling Equipment**

- Assistance is required. Torque Fitness recommends using more than one person to assemble this equipment.
- This product must be assembled on a flat, level surface to assure its proper function. Locate the unit away from walls or furniture to allow easy access during assembly and use.
- Read each numbered step in Assembly and Maintenance Guide and follow the steps in sequence. Skipping ahead may result in damage to the equipment and may require components to be disassembled.
- Wear proper attire during the assembly process. Do not wear clothing which is too loose or open toed shoes.

#### **Obtaining Service**

- Do not attempt to service the product yourself except for maintenance tasks described in this manual.
- Refer to the Adjustments and Maintenance section at the back of this manual for product operation and service.
- For further information, visit our website at www.torquefitness.com or contact us at www.service@torquefitness.com
- If you call or email customer service, have the model number and serial number(s) available.

## **GENERAL NOTES**

<u>CAUTION:</u> More than one person is required to assemble this unit. Do not attempt to assemble by yourself.

#### **Unpacking the Equipment**

- This product may be packaged and shipped in multiple boxes. Parts from all of the boxes are required for various steps during the assembly process.
- Carefully open each box and arrange all the parts near the area where assembly is to take place.
- <u>CAUTION:</u> Use extreme care when cutting plastic tie wraps and package banding. A wire cutter works best for protecting yourself and the parts.
- <u>CAUTION:</u> Some of the internal boxes may contain upholstery. Do not use a utility knife to open any boxes or the pads may be damaged.
- The hardware is packed in bags. Carefully open each bag and sort them per parts list on the next page.
- Before starting assembly, identify each part and hardware item as listed in the parts list on the next page. If any items are missing, contact Torque Fitness Customer service at: 763-754-7533 (8:30 am - 5:00 pm CST).
   www.service@torquefitness.com
- Note: Some items listed in the parts list may already be pre-installed on the product.

#### **Tools Required**

- Rubber mallet or hammer
- 3/4" wrench
- Ratchet with 3/4" socket
- 3/8" Allen wrench
- Allen wrench set
- Wire snips (to cut plastic tie wraps)
- Scissors or utility knife (to cut hardware bags)
- Step stool or ladder
- Tape measure

#### **Optional Equipment**


- Optional equipment may be available for this product.
- Follow the instructions included with the optional equipment to assemble it to the base product.

#### **Assembly Tips**

- In a continual effort to improve our products, specifications are subject to change.
- A 6" scale is provided at the bottom of every page. To correctly measure the bolts, measure from underneath the bolt head to the end of the bolt as illustrated below.
- Read all notes on each page before beginning that step.
- Some of the items shown in the assembly steps may already be pre-assembled.

#### **Assembly Tips Continued**

- Note: Some items have been hidden for assembly clarity.
- Note: Some pre-assembled parts may need to be temporarily removed in order to complete the step. Follow the instructions or damage to the product could occur.
- Some parts may have extra holes that will not be used. Use only the holes depicted in the instructions.
- Certain parts make reference to the right and left side of the machine. For this product, left and right is determined by facing the product.
- Provide ample space around the product for ease of assembly.
- DO NOT fully tighten any connections until instructed to do so. This will help insure that the alignment of all of the parts will be correct.
- Insert all bolts in the direction indicated in the instructions. Failure to do so may result in clearance issues and will degrade the aesthetics of the product.
- Carefully follow instructions for all pivot points.
   In general, primary rotating parts have connections that should be securely tightened, while secondary connections need to be loosen 1/4 turn.



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	57231PA	PTD ASSY, 7.5' UPRIGHT	2
2	5723501	WLDMT, 1 FT WALL MOUNT ANCHOR	4
3	2007801	WASHER, 1/2 X 1-3/4 X 4.5†	24
4	2005817	BOLT, 1/2-13 X 4-1/2" (114mm) SOCKET HEAD	12
5	2001401	NUT, 1/2-13 LK ST ZN	17
6	5442801	WLDMT, 4' SINGLE CROSS	1
7	2001101	WASHER, FLAT 3/8 SAE ST ZN	16
8	2031101	SCREW, 3/8" LAG X 2.5"L CLEAR ZINC	16
9	5720501	PLATE, HEADER	2
10	5720401	PLATE, WALL MOUNT BACKING	4
11	2001301	WASHER, FLAT 1/2 SAE ST ZN	22
12	2006802	BOLT, 1/2-13 X 3/4" (19mm) SOCKET HEAD W/NP	8
13	54737PA	PTD ASSY, LEFT BAR SUPPORT	1
14	54742PA	PTD ASSY, RIGHT BAR SUPPORT	1

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
15	54745PA	PTD ASSY, LEFT BAR CATCH	1
16	54748PA	PTD ASSY, RIGHT BAR CATCH	1
17	55478PA	PTD ASSY, XDSA LEFT	1
18	55481PA	PTD ASSY, XDSA RIGHT	1
19	55934PA	PTD ASSY, UBPA LEFT	1
20	55935PA	PTD ASSY, UBPA RIGHT	1
21	55782PA	PTD ASSY, BATTLE ROPE ANCHOR	2
22	5521501	ASSY, GROUND ROTATIONAL TRAINER	1
23	5582201	WLDMT, LBPA LEFT	1
24	5582701	WLDMT, LBPA RIGHT	1
25	5621301	ASSY, GROUND ROTATIONAL TRAINER	1
26	2005816	BOLT, 1/2-13 X 4-1/4" (108mm) SOCKET HEAD	5
27	57412PA	PTD ASSY, DOUBLE PLAY	1
28	5745101	WLDMT, DOUBLE PLAY ADAPTER	1

#### **TABLE OF CONTENTS:**

Warnings: Page 2

• General Notes: Page 3

Wall Rack Assembly: Page 5, 6, 7 & 14

Wall anchor mount: Page 8

Wall header/footer mount: Pages 9 -10


Optional wall header plate mount: Pages 11 - 13

Optional Attachments: Pages 15 - 23


Maintenance/notices: Page 24

### **NOTES:**

Assembly steps 1, 2A, 2B & 6 show steps to assemble the 1.0 base system. Additional assembly steps for optional attachments, are shown in subsequent steps and are listed as "optional"




#### STEP 1




## NOTE:

### LOOSELY tighten bolt connections in this step.




#### STEP 2A




#### **NOTE:**

SECURELY tighten all bolt connections in this step and previous steps.





## **STEP 2B (OPTIONAL MULTI GRIP CROSSES)**






**SECURELY** tighten all bolt connections in this step and previous steps.






#### **STEP 3 (WALL ANCHOR MOUNT)**




#### **WARNING:**

THE UPPER AND LOWER WALL MOUNT ANCHORS MUST
BE ANCHORED TO THE WALL USING EIGHT WALL ANCHORS
SUITABLE FOR THAT PARTICULAR WALL CONSTRUCTION.





#### **NOTES:**

The images above show how to attach the rack to the wall using wall anchors. The wall anchors used will depend on the wall construction. **NOTE: All eight anchoring locations must be used**. The pull-out strength of the anchoring hardware used must be equal to or greater than 200 lbs. (91 kg) each.



#### **STEP 4A (HEADER/FOOTER MOUNT)**






#### **NOTES:**


The images above show how to attach a header and footer board to a typical wall with wood studs spaced 16" on center. The anchors used will depend on the wall construction. **NOTE:** All twelve anchoring locations must be used. The pull-out strength of the anchoring hardware used must be equal to or greater than 200 lbs. (91 kg) each.

#### **SECURELY** tighten all bolt connections in this step.




#### WARNING:

THE **HEADER AND FOOTER MUST** BE ANCHORED TO THE WALL USING TWELVE WALL ANCHORS SUITABLE FOR THAT PARTICULAR WALL CONSTRUCTION.




#### **STEP 4B (HEADER/FOOTER MOUNT)**




#### WARNING:

THE RACK MUST BE ANCHORED TO THE HEADER AND FOOTER BOARDS USING ALL EIGHT WALL ANCHORS.





## NOTES:

The images above show how to attach the rack to the header and footer boards from previous step using 3/8" lag bolts. **NOTE: All eight anchoring locations must be used**. The pull-out strength of the anchoring hardware used must be equal to or greater than 200 lbs. (91 kg) each.



#### **STEP 5A (OPTIONAL HEADER PLATE MOUNT)**






#### **NOTES:**


The images above show the anchoring hardware used for attaching the HEADER PLATE MOUNT to a typical wall with wood studs spaced 16" on center. The anchors used will depend on the wall construction. **NOTE:** All sixteen anchoring locations must be used. The pull-out strength of the anchoring bolts used must be equal to or greater than 200 lbs. (91 kg)

## **SECURELY** tighten all bolt connections in this step.




#### **WARNING:**


THE UPPER AND LOWER HEADER PLATE MOUNTS <u>MUST</u> BE ANCHORED TO THE WALL USING 16 WALL ANCHORS SUITABLE FOR THAT PARTICULAR WALL CONSTRUCTION.




## STEP 5B (OPTIONAL HEADER PLATE MOUNT)




## **STEP 5C (OPTIONAL HEADER PLATE MOUNT)**




## NOTES:







## **STEP 7 (OPTIONAL BAR CATCHES)**




## **STEP 8 (OPTIONAL DIP ATTACHMENT)**




# STEP 9A & 9B (OPTIONAL UPPER BAND PEG ATTACHMENT)







## **NOTE:**




## **STEP 10A & 10B (OPTIONAL BATTLE ROPE ANCHOR)**







### **NOTE:**




## STEP 11A & 11B (OPTIONAL GROUND ROTATIONAL TRAINER)







#### **NOTE:**




# STEP 12A & 12B (OPTIONAL LOWER BAND PEG ATTACHMENT)







## **NOTE:**




# STEP 13 (OPTIONAL HORIZONTAL MOUNT GROUND ROTATIONAL TRAINER TO LOWER BAND PEG ATTACHMENT)




## **NOTE:**




# STEP 14 (OPTIONAL BATTLE ROPE ANCHOR TO LOWER BAND PEG ATTACHMENT)



## **NOTE:**




## **STEP 15 (OPTIONAL DOUBLE PLAY ATTACHMENT)**



#### **MAINTENANCE:**

- NUTS/BOLTS: Inspect periodically, tighten and/or adjust as needed.
- **SPRING PINS:** Check that spring pins fully engage the hole when released. Tighten spring pin nuts as needed.
- **FRAME:** Wipe down frame with a damp cloth.



Torque Fitness 11201 Xeon Street NW Ste 101 Coon Rapids, MN USA 55448

www.torquefitness.com or 763-754-7533 (8:30 am – 5:00 CST).

For sales: sales@torquefitness.com For service: service@torquefitness.com

- https://twitter.com/TorqueFitnessHQ
- https://www.instagram.com/torquefitnessusa/
- https://www.youtube.com/c/TorqueFitness/
- f https://www.facebook.com/torquefitness/