

# Assembly Instructions For The Swingbed

## Tools Needed:

Hammer For Light Tapping  
1/2" Wrench  
Screwgun  
#2 Square Drive Bit

## Parts List:

Seat Assembly (1)  
Back Assembly (1)  
Left Arm Assembly (1)  
Right Arm Assembly (1)  
Chains Or Ropes (4)

## Hardware:

1/4" x 4-3/4" Bolts (2)  
1/4" x 2-3/4" Bolts (6)  
1/4" Washers (8)  
5/16" x 4" Eye Bolts (4)  
5/16" Hex Nuts (4)  
1-3/4" Screws (14)  
Allen Wrench (1)

**Step 1** Fasten the back to the seat. Align the predrilled holes on the bottom of the back with the threaded inserts in the back of the seat. Put two 4-3/4" bolts down through the back & turn into the inserts in the seat with the Allen wrench. **NOTE: Do not fully tighten these bolts until Step 2 completed.**

**Step 2** Fasten the arms to the seat and back. Align the holes on the 2x4's on the bottom of the arm with the threaded inserts in the side of the bed. Put a 2-3/4" bolt through the holes in the 2x4's, turn into the inserts, and tighten with the Allen wrench. Now align the hole in the back of the arm with the threaded insert in the side of the back assembly, put another 2-3/4" bolt through & tighten. (**Note: If the holes do not align properly the back assembly can be moved back & forth.**) Now take the 1-3/4" screws and insert in the predrilled holes in the slats on the arm and fasten to the side of the swingbed with the screwgun. (Extra screws are provided). Now attach the other arm & tighten all bolts.

**Step 3** Put a 1/4" washer on a 4" eyebolt & put through the hole above the arm on the back assembly. (The eye of the bolt belongs on the outside). Put another 1/4" washer on the inside & put on a 5/16" hex nut. **NOTE: If your swingbed has chains do not fully tighten these nuts until chains are attached. If it has ropes they can be fully tightened right away.** Now find the predrilled hole in the side of the seat in front of the arm brace. Put another eyebolt in & repeat on other side.

**If your swingbed has chains go to Step 4, if it has ropes skip Step 4 and go to Step 5.**

**Step 4** Attach the chains to the eyebolts. The chains in the front go through the hole in the armrest & attach to the eyebolts below the arms. **NOTE: If you cannot hook the chain onto the eyebolts loosen the nuts on the end of the eyebolts. Turn the eyebolts so the opening is turned down. Now fully tighten the hex nuts with the 1/2" wrench while holding the head of the eyebolt.** Attach the chain to hooks at the ceiling. (You will need to get the hooks unless you ordered our swing hanging kit). The swingbed can be hung from two or four points at the ceiling.

**Step 5** Attach the rope to the swingbed. Take a rope, put the end through the hole in the armrest, & through the eyebolt below the arm. Pull on through the eyebolt & make a knot in the end of the rope. (See photos below). Attach another rope to the eyebolt in the back assembly the same way then repeat on other side. The swingbed is now ready to hang. Hook the rings on hooks at the ceiling or if you purchased comfort springs hook the rings on one end of the springs and hook the other end of the springs to the ceiling. The swingbed can be hung from two points or four points at the ceiling.

**Step 6** You will now need to adjust the ropes until the swingbed is at the desired height. The ropes are all fully adjustable. To lower the swingbed push the bottom loops on the end of the rope further up the rope then hold the top loops with one hand & pull the end of the rope up through the loops. To raise the swingbed pull the rope through the loops in the opposite direction. The ropes attached to the front of the swingbed will need to be adjusted to a different length than the ropes attached to the back. If the swingbed hangs crooked adjust the ropes accordingly until it hangs properly.

**How to make a knot:**

