

双面彩色印刷加折页

展开尺寸：400*160mm
 单页尺寸：80*80mm
 材质：105G双铜

Quick Installation Guide 300M Wireless Repeater

LED Explanation

LED	Status	Indication
POWER	On	Normal power supply
	Off	Abnormal power supply or no power supply.
WIFI	On	WIFI UP
	Blinking	The port is transmitting of receiving data
WAN/LAN	On	Cable accessed.
	Blinking	The port is transmitting of receiving data.
WPS	On	WPS UP.
	Quick Blinking	System set factory default.
Repeater (AP Mode)	On	WPS successful or Relay successful.
	Slow Blinking	WPS failure or relay failure.

Ports and Buttons:

Item	Description
Reset/WPS Button	Press and hold the button more than 5s until the WPS led quick blinking, system set factory default.
Reset/WPS (Repeater)	Press and hold the button for less than 3s to starting WPS uplink.
Reset/WPS (AP/WISP)	Press and hold the button for less than 3s to start allowing clients to connect.
WAN/LAN	Connect PC or Router.

Config WISP Mode

WISP Mode: Connect routers and other devices wirelessly, share the Internet to local wireless and wired networks.

1 Power On

Plug the Repeater into a power outlet next to your router.

2 Set Up

Method 1: Via a Web Browser

1. Connect your computer or smartphone to the Repeater's network: PIX-LINK-2.4G. If you are using a computer, unplug the Ethernet cable if any. The default wireless name can be viewed on the bottom label of the repeater.

Default Access: http://192.168.7.1
 SSID: PIX-LINK-2.4G
 Input: 110V~240V-50/60Hz

2. Launch a web browser, and enter http://192.168.7.1 in the address bar.
 Note: If the login window does not appear, refer to FAQ-1.

3. Follow web instructions to complete the setup.
 a. Click Wizard, select WISP.

b. The system will automatically scan the surrounding wireless networks.

c. After entering the page in WISP mode, the system will automatically scan and display the scanned wireless network in the list. Select the wireless signal you need to connect to. Related information will be displayed at the top of the list. Enter the extended password, and then click Connect to complete the setting.
 Note: The password must be the same as the password of the upper-level SSID. If the upper-level SSID does not require a password, no password is required here.

d. The Repeater LED should turn solid on, indicating successful connection to your router.
 Note: If the LED does not turn solid on, refer to FAQ-2.

e. Connect your devices to the Repeater wirelessly or via an Ethernet cable, then enjoy the internet.

Config Repeater Mode

Repeater Mode: Connect your devices to the Repeater wirelessly or via an Ethernet cable, then enjoy the internet.

1 Power On

Plug the Repeater into a power outlet next to your router.

2 Set Up

Method 1: Via a Web Browser

1. Connect your computer or smartphone to the Repeater's network: PIX-LINK-2.4G. If you are using a computer, unplug the Ethernet cable if any. The default wireless name can be viewed on the bottom label of the repeater.

Default Access: http://192.168.7.1
 SSID: PIX-LINK-2.4G
 Input: 110V~240V-50/60Hz

2. Launch a web browser, and enter http://192.168.7.1 in the address bar.
 Note: If the login window does not appear, refer to FAQ-1.

3. Follow web instructions to complete the setup.
 a. Click Wizard, select Repeater.

b. The system will automatically scan the surrounding wireless networks.

c. Select the SSID of the master router and enter the password. The default Repeater SSID is set to be xxxx-EXT[xxxx indicates The master router's wireless network name]. Then click Connect to complete setup.
 Note: The password is the same as your master router.

d. The Repeater LED should turn solid on, indicating successful connection to your router.
 Note: If the LED does not turn solid on, refer to FAQ-2.

e. Connect your devices to the Repeater wirelessly or via an Ethernet cable, then enjoy the internet.

3 Relocate

1. Plug in the Repeater about halfway between your router and the Wi-Fi dead zone. The location you choose must be within the range of your router.
2. Wait for about 2 minutes until the Signal LED turns solid Green. If it doesn't, relocate the Repeater closer to the router to achieve better signal quality.

Method 2: Via the WPS Button

1. Press the WPS button on your router.
2. Within 2 minutes, press the WPS button on the Repeater for 1 second. The Repeater LED should change from blinking to solid on, indicating successful connection.
 Note: If the Repeater LED does not turn solid on, try again or use Method 1 or 2.

Config AP Mode

AP Mode: Additional wired router realize wireless function: This repeater can connect to uplink router's LAN port by wired connection, convert wired signals to wireless signals, user terminal can connect to this router by wireless connection.

1 Power On

Plug the Repeater into a power outlet next to your router.

2 Set Up

Method 1: Via a Web Browser

1. Connect your computer or smartphone to the Repeater's network: PIX-LINK-2.4G. If you are using a computer, unplug the Ethernet cable if any. The default wireless name can be viewed on the bottom label of the repeater.
2. Launch a web browser, and enter http://192.168.7.1 in the address bar.
 Note: If the login window does not appear, refer to FAQ-1.

3. Follow web instructions to complete the setup.
 a. Click AP Mode.

b. Enter SSID and Password, click apply to complete the settings.

c. Connect the Repeater to the LAN port of your router with an Ethernet cable.

d. Connect your devices to the Repeater wirelessly, then enjoy the internet.

Frequently Asked Questions (FAQ)

1. **Unable to access administration page?** Please make more detailed checks as follows:
 - Computer wired configuration: Ensure your computer gets the address automatically. Ensure your computer is connected to the router's LAN port with the cable, and the network indicators on both sides are lit.
 - Mobile phone or computer wireless configuration: Please make sure that the connected WIFI is the WIFI of this device, and the password is entered correctly.

- Please open your browser and make sure that you have entered the correct IP address or domain name.
- Please refresh your browser or try another browser (such as Firefox or Chrome).
- Please replace the network cable, or replace another computer and try again. Please reset the device factory default and repeat the above steps again if the issue still exists.
2. **After the "Repeater/WISP Mode" configuration of the device is completed, the Repeater light flashes, and the relay signal cannot be connected to the Internet.** The Repeater light of the device flashes to indicate that the Repeater/WISP is not successfully paired, which is usually caused by the following problems:
 - When filling in the wireless router, the password is entered incorrectly. When setting, open the small eye behind the password box to check whether the password is correct.
 - The original signal received by the set repeater is too weak. Please install the mobile device to an area where the Wi-Fi signal is relatively good. (For example, the wireless router is in the living room and the bedroom signal is poor. Then we set it up. The repeater is placed on the socket outside the bedroom, between the bedroom and the living room. Do not use it in the bedroom) This can ensure the network speed of the relay signal and expand the coverage of the Wi-Fi signal.
3. **Under what circumstances can't the relay be successful?**
 - The original wireless router wifi name or password has special symbols;

- The original wireless router wifi name or password has special symbols;
- A small number of telecommunications optical modems (chinanet), mobile optical modems (CMCC-), and Unicom optical modems (unicom) are relayed due to their own limitations or weak signals, which may cause problems such as unsuccessful relaying.
- If the relay is unsuccessful, please select WISP mode
- 4. **The cell phone, tablet or laptop cannot associate to the WIFI network?** Please make more detailed checks as following:
 - Ensure the WIFI function on the mobile device works normally, for example, the WIFI switch is turned on, and the wireless signal can be scanned.
 - Ensure the router is set up correctly.
 - Please make sure that the wireless name selected and the wireless Pass Phrase entered are correct (case sensitive) when establishing the wireless association.
 - Please reset the device factory default and repeat the above steps again if the issue still exists.
- 5. **How to restore the device to the factory default?**
 - Press and hold the button more than 5s System set factory default until the WPS led quick blinking.
 Note: All configurations will be cleared and you need to reconfigure your device after set factory default.