

HEY BUDDY! READY TO TAKE ME OUT FOR A RIDE?







Getting Started Manual



IMPORTANT!
KEEP FOR FUTURE
REFERENCE.

It is very important to read, understand and follow this manual before using your MiniMeis carrier.

Languages index

	English	3
	German	17
	French	34
	Spanish	50
	Italian	67
	Dutch	84

Check out how to use
the manual correctly



The Minimeis Shoulder carrier comply with:
EN13209-1:2022
ASTM F2549 - 14A

Safety manual index

Important safety information	4
Intended use	4
Child safety	5
Activity-related hazards	6
Caregiver safety	7
MiniMeis components	8
Prepare MiniMeis for use	9
Children 6–10 months of age	10
Children 10 months–4 years of age	11
MiniMeis tips & tricks	12
How to fold and store MiniMeis	13
Washing instructions	14
Maintenance	15
Replacement parts	15
Warranty	15

Important safety information

Please read and understand the entire Getting Started manual before using your MiniMeis!

This Getting Started manual contains important information for protecting yourself and others and for preventing potential problems – please read it carefully. Failure to follow these safety instructions and precautions can lead to serious injury or death.

Intended use

The intended use of your MiniMeis G4 carrier is to transport children on your shoulders in a fun, safe, practical and comfortable way. Any other use of the carrier is prohibited and may lead to serious injury or death.

WARNING! To prevent SERIOUS INJURY or DEATH:

- NEVER use the carrier with a child weighing less than 16 lb (7 kg) or more than 40 lb (18kg).
- NEVER use the carrier with a child less than 6 months old or with a child that cannot sit upright unassisted.

WARNING! Child safety

FALL & STRANGULATION HAZARD.
To prevent **SERIOUS INJURY**
from falling or sliding out:

- ALWAYS use child retention system.
- ALWAYS make sure to securely fasten and adjust according to the following instructions.
- NEVER leave child unattended in your MiniMeis carrier.
- NEVER place carrier on counter tops, tables, or other elevated surfaces.
- Take care when bending or leaning forward or sideways. Bend at the knees to keep child upright, as tripping can cause you and the child to fall.
- When in the carrier, your child will be in a position higher than the caregiver. Be aware of door frames, low tree branches, ceiling fans or other potential hazards in your path of travel.

WARNING! Activity-related hazards


- ONLY use your carrier when walking, sitting or standing.
- NOT suitable for use during sports activities or cycling.
- NEVER jog, run, climb, ski, bike, ride horses or use any motorized vehicle while using carrier.
- NEVER use in shower, pool or any other location where water is present.
- NEVER use carrier when your balance or mobility is impaired because of exercise, drowsiness, medical conditions or any other reason.
- KEEP AWAY from fire.
- NEVER use carrier when under the influence of alcohol or drugs.
- NEVER use carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
- Check on your child often. Be aware your child may suffer from the effects of the weather and sun before you do when riding in the carrier. You may need to provide water, sunscreen or a hat.
- Take frequent breaks to help prevent the child from becoming tired or restless in the carrier.

WARNING! Caregiver safety

Your balance may be adversely affected by the movement of the child or your own movement.

- NEVER use carrier with a child weighing more than 40 lb (18 kg).
- ALWAYS be careful when putting on or removing your carrier. Ask for assistance if needed to prevent injury.
- NEVER use your carrier as a means to transport your child in a motor vehicle. Your carrier is not intended for use as a child restraint device in a motor vehicle.
- NEVER wear carrier while driving or riding as a passenger in a motor vehicle.
- NEVER allow your child to sleep in the MiniMeis carrier.
- NEVER leave a child in a carrier that is not being worn.
- NEVER use the MiniMeis carrier if you have shoulder, back or neck problems. If use of the carrier causes discomfort, stop use immediately and consult your doctor.
- NEVER place more than one child in the carrier at a time.
- NEVER wear more than one carrier at a time.

MiniMeis G4 components



Prepare MiniMeis for use

ALWAYS inspect carrier before use. Check for ripped seams, torn straps or fabric and damaged hardware. If any damage is found, or if you are in any doubt, stop using carrier.




1

Remove the side straps holding the MiniMeis in the folded position.



2

Rotate the back support upward. Both sides of the back support should slide into the lower portion of the frame.



3


Make sure both sides of the frame are secure before each use.

IMPORTANT!

Ensure that the child is safely positioned in the carrier according to the instructions on the next pages!


Children 6–10 months of age

If your child needs extra upper body support, use the MiniMeis with the 9-point harness. The child must be able to sit up unaided.



1

Secure your child in the seat by fastening the shoulder strap in the loop between their thighs and the two loops at the back of the frame.



2

Fasten and tighten the waist belt and the leg straps.



3

Place your hands through the straps on each side and grab your child around the waist (as you would normally do to lift it up on to your shoulders).

4


Lift the child up onto your shoulders. Attach the MiniMeis by fastening the straps in front of your shoulders and on each side of the carrier.

IMPORTANT!

Always check that all buckles, snaps, straps and adjustments are secure.

See minimeis.com for more information and a tutorial on the 9-point harness.


Children 10 months–4 years of age



1

Place the MiniMeis on your shoulders. Connect the buckles for the side straps and the chest strap. Tighten the side straps until the MiniMeis fits firmly and adjust chest strap as needed.

Always check that all buckles, snaps, straps and adjustments are secure.



2

Lift the child up in the carrier and place it all the way into the seat. It should not be seated between the carrier and the neck. Child must face forward.

3

Immediately fasten the waist belt around your child and tighten it firmly.

4

Fasten the leg straps around the ankles and secure with buckles.

MiniMeis tips & tricks




CORRECT SITTING POSITION

If you are not able to lift your child fully into the seat on the first try, use the child's legs to push them properly into the seat. Immediately fasten and tighten the waist belt.



ADJUSTMENT FOR WOMEN

If the carrier is still not comfortable over the chest area after adjusting the straps, then release the chest strap. The two side straps **MUST** remain connected and tight.



ADJUSTMENT FOR ALL

Take your time to adjust all straps so the carrier is properly fitted to your body. If the MiniMeis is tilting a bit backwards, loosen the chest strap and tighten the side straps.

See videos on how to achieve the best comfort while wearing the MiniMeis at minimeis.com



9-POINT HARNESS

If your child needs extra upper body support, use the optional 9-point harness. The child must be able to sit up unaided.

How to fold & store MiniMeis



1

Grab the strap marked "FOLD" with one hand.

2

Use your other hand to pull top of the frame. The back support section will slide out of the lower section.

3

Fold the back support section down.




4

To avoid loose straps and to keep the MiniMeis properly folded, attach the side straps over the folded hinges in a cross pattern.

Tip: See video tutorial on how to fold and transport the MiniMeis in our instruction video at minimeis.com

Washing instructions

Improper care will void any and all warranties.



Wipe and clean using wet cloth is OK

Soap based detergents are OK

Do not expose to solvents or other chemicals

Do not use softeners

Do not dry clean

Do not tumble

Do not iron

Do not bleach

Maintenance

For safety; regularly inspect that all parts; components, straps and stitches are intact.

Replacement parts

Only use accessories and replacement parts from authorized dealers or direct from MiniMeis AS.

Warranty

1 year.

MiniMeis AS

Øvre gate 7 N-0551 Oslo Norway

MiniMeis.com contact@minimeis.com