

24 Months Warranty

**Rico®**  
HOME APPLIANCES  
Warranty Card

(As per terms and conditions overleaf)

Please preserve this warranty card the cash memo and ensure that it is duly stamped (with the date stamped) and signed by the dealer. A warranty card or cash memo which is not stamped and signed by the dealer will be treated as invalid. Kindly update your details on our website [www.rico.in](http://www.rico.in).

Name of Customer : \_\_\_\_\_

Address : \_\_\_\_\_

Mobile No.: \_\_\_\_\_ Email: \_\_\_\_\_

Rico Product : \_\_\_\_\_

Product Sr. No.: \_\_\_\_\_ Date Of Purchase : \_\_\_\_\_

Customer's Signature	Dealer's Stamp & Signature

**Rico Appliances Pvt. Ltd.**

8th Floor, Sapphire Bldg, S.V. Road, Khar (W), Mumbai-400052, Maharashtra, India.  
Tel: (91-22) 26002926 Email: [service@rico.in](mailto:service@rico.in) Website: [www.rico.in](http://www.rico.in)

1<sup>ST</sup> INDIA'S  
**Rico®**  
HOME APPLIANCES

LIGHT WEIGHT AUTOMATIC  
ELECTRIC IRON



Instruction Manual with  
Warranty Card

Dear Customer,

Thank you for selecting Rico

Congratulations , you have just brought yourself , one of the finest home product , in the form of Rico Electric Iron. Your Rico Electric Iron has been manufactured for you under the most stringent quality control procedures.

You are assured of the best quality , performance and after sales service. If , however for any reason, you feel something is lacking, we are always there at your service.

If you require any further assistance , please do not hesitate to contact us , for immediate action on your query/ problem ,at

CUSTOMER RELATIONS DEPARTMENT

**Rico Appliances Pvt. Ltd.**

Sapphire Bldg, 8th floor , S.V. Road,  
Khar (W), Mumbai-400 052

Tel. : (91-22) 26002926

Email : service@rico.in

Website : www.rico.in

Thank you once again for buying Rico.

*C. Thakur*

*Chairman,*

**Rico** APPLIANCES PVT. LTD.

#### CONTENTS

Check list / Description	1
General Operating Precautions	2
How to use the Appliance	3
Cleaning Instructions	3
Warranty conditions & service procedure	4,5

Subject to the above - The defective part will be repaired / replaced free of charge for labour or materials, at our discretion & option, provide that:

- The unit is returned at your cost to our Authorized Service Centre along with the stamped and signed Cash Memo and Warranty Card.
- The unit is installed, used and maintained strictly in accordance with the instructions provided.
- The unit is not opened or tampered with by anyone except our Authorized Service Centre or technician.

#### CONSEQUENTIAL DAMAGE

Liability for consequential loss or damages is neither accepted nor is it implied. The warranty extended herein is in lieu of all implied conditions and warranties under the law and is confined to the repair or replacement of defective parts and does not cover any consequential or resulting liability, damage or loss. The warranty in no case shall extend to payment of any monetary consideration whatsoever or the replacement or return of the products as whole, liability for consequential loss or damage is neither accepted nor is implied.

#### 4. SERVICE AND REPAIRS

Please get the product repaired only from our nearest Office, Dealer or Customer service centre.

This warranty is confined to the repair or replacement of defective parts. Any expenses incurred on collecting and returning the product to the customer and/or on the service personnel who will visit the customer, such as to and fro conveyance, incidentals etc., shall be borne by the customer.

Please note that this warranty is issued subject to the jurisdiction of the competent courts in Mumbai INDIA only.

To avoid unnecessary repairs, please study the instruction manual carefully before operation.

## HOME APPLIANCES WARRANTY CARD

### WARRANTY CONDITIONS & SERVICE PROCEDURE

#### Conditions of the Warranty:-

Your Rico product is warranted against manufacturing defects for 24 months from the date of purchase. The product is warranted against manufacturing defects only. This product is designed for domestic use only.

#### This warranty does not apply to

- Normal Wear and tear of parts or surface coating
- Faults which may be due to wrong usage, faulty handling, damage in transit, usage of spurious parts, neglect or accident are not covered by this warranty
- Damages resulting from accidents, mishandling or negligence on the part of the customer and fluctuation in supply voltage.
- Surface Coating, body aesthetics, plastic parts, neon lamps, bakelite parts, rubber/nylon parts, push buttons & bulb.
- Damages resulting due to usage of power supply other than specified 220/230 Volts, AC, 50 Hz. eg: inverters generators etc.
- For humming noise generated due to usage of electronic fan regulators of any make.

Should your Rico product become un-operational during the warranty period, Kindly contact your nearest authorized Rico Dealer / Service Centre. (List is also available on [www.rico.in](http://www.rico.in))

## Technical Specifications


Wattage : 750W / 1000W

Voltage : 230V AC, Single Phase, 50Hz

### Check list / Description



AI04 / 750W



AI07 / 1000W



AI10 / 1000W

- |                                |               |
|--------------------------------|---------------|
| 1. Non-Stick Coated Sole Plate | 4. Mains Cord |
| 2. Knob                        | 5. LED        |
| 3. Handle                      | 6. Back Cover |

## General Operating Precautions

- 1 Check if the voltage indicated on the type plate corresponds to the local mains voltage before you connect the appliance.
- 2 Do not use the appliance if the plug, the cord or the appliance itself is damaged.
- 3 Always connect the unit to a 3 pin, 5 Amp properly earthed power supply socket.
- 4 If the fabric label is missing and you do know the kind of fabric, set the thermostat according to the following guidelines.

Fabric	Temperature
Nylon	70°C to 90°C
Rayon	100°C to 120°C
Silk	130°C to 150°C
Wool	160°C to 180°C
Cotton / Linen	190°C to 210°C

- 5 Never leave the iron unattended when it is connected to the mains.
- 6 Never immerse the iron in water.
- 7 Infirm persons should not allowed to use the appliance with out supervision. Keep the appliance out of the reach of children.
- 8 The sole plate of the iron can become extremely hot and may cause burns if touched. Do not allow the cord to come into contact with the sole plate when it is hot.
- 9 Before changing the setting of the thermostat from one position to another, allow a small time gap. This will help to protect the life of the thermostat.
- 10 First check the labels on the fabric to be ironed. Always follow the ironing instructions given on the labels.
- 11 Do not iron on uneven surfaces like buttons, hooks etc. as it will spoil the sole plate.
- 12 Switch off and remove the plug from the socket when not in use.
- 13 Make sure the plug is removed from the power socket while cleaning the appliance or carrying out any maintenance, assembling or disassembling of parts.
- 14 If you require an extension board, please make sure it is correctly wired and rated for use with this appliance.
- 15 Always store the iron standing on the heel rest to avoid scratching the sole plate.
- 16 Do not attempt to replace the power cord or any other part yourself, because special tools and skill are required for repairs. Please bring the iron to the nearest Rico authorized service centre for repairs.

## Before first use

### Dry Ironing

1. Remove any sticker or protective foil from the sole plate.
2. Let the iron heat up to maximum temperature and pass the iron over a piece of damp cloth for several minutes to remove any residue from the sole plate. The iron may give off some smoke when you use it for the first time, this is normal.
3. Pilot light glows indicating that the iron is switched on.
4. Pilot light goes off when required temperature is reached.
5. The iron is now ready for use.
6. When you finish ironing, turn the temperature dial in anticlockwise direction to 'min' and then switch off the Mains.
7. Disconnect the iron from the electric supply socket when it is not in use.
8. When the iron gets cooled completely, store it vertically in a safe place.

### Operation

- 1 Turn the dial to the desired temperature (as given in the chart)
- 2 Plug in the Iron. The automatic LED light will glow.
- 3 Wait till the automatic LED light goes off and comes on again. This indicates that the correct temperature has been reached.
- 4 Start ironing.
- 5 The lamp will glow off and on from time to time during ironing. This has no effect on the ironing efficiency. So simply continue.
- 6 If by chance you need to set the thermostat lower, after ironing at a higher temperature, please wait till the LED light goes off and comes on again to avoid scorching / burning the material.
- 7 After you have finished ironing, place the iron on its heel rest.
- 8 Set the temperature dial to 'min.'
- 9 Remove the plug on the from the socket.
- 10 Allow the iron to cool down (about 30 minutes)
- 11 You can now wind up the mains cord.

### Cleaning the Iron

1. Disconnect the iron from the electric supply socket.
2. Use a damp cloth or non-scratching cleaner to remove any deposits on the sole plate.
3. Never use sharp or rough object to remove the deposits on the sole plate.
4. Never use any abrasive, vinegar or descaling agents to clean the iron.

### Safety protective cut out

In the unlikely even of the thermostat failing, the protection circuit built in the iron will activate and switch the unit 'OFF' to prevent overheating of iron. The iron should then be taken to an authorized Rico Service Centre