

# **NAVODILA ZA UPORABO**

---

**INSTRUCTIONS FOR USE**

**2022**

[www.glowen.si](http://www.glowen.si)

**KAZALO VSEBINE - Slovenščina**

Stran 1 - Stran 8

**TABLE OF CONTENTS - English**

Stran 9 - Stran 17

<b>01</b>	<b>Pomembne informacije</b>	.....	<b>Stran 1</b>
<b>02</b>	<b>Splošna navodila</b>	.....	<b>Stran 2</b>
	Pred prvo uporabo		
	Predpečenje		
<b>03</b>	<b>Kaj je v škatli?</b>	.....	<b>Stran 3</b>
<b>04</b>	<b>Katero gorivo uporabiti?</b>	.....	<b>Stran 4</b>
<b>05</b>	<b>Kurjenje z lesom</b>	.....	<b>Stran 4</b>
<b>06</b>	<b>Navodila za nego</b>	.....	<b>Stran 4</b>
	Kje naj peč shranim?		
	Kako očistim peč?		
	Kako očistim plošče za peko?		
	Kako ugasnem Glowen Raptor?		
<b>07</b>	<b>Odpravljanje težav</b>	.....	<b>Stran 5</b>
	Na peči opažam spremembo barve		
	V kurišcu imam preveč pepela		
	Temperatura v peči je previšoka		
	Temperatura v peči je prenizka		
	Plošča za pečenje je počila		
<b>08</b>	<b>Varna uporaba</b>	.....	<b>Stran 7</b>
<b>09</b>	<b>Garancija</b>	.....	<b>Stran 8</b>
<b>10</b>	<b>Dimenzijske podatki</b>	.....	<b>Stran 18</b>

## 01



## POMEMBNE INFORMACIJE

Vaša varnost je najpomembnejša, zato skrbno preberite priložena navodila in jih shranite za poznejšo uporabo.



Glowen raptor je zasnovan za zunanjouporabo, zato ga ne uporabljajte v notranjih prostorih.



Peči nikoli ne uporabljajte brez nadzora.



Ne uporabljajte peči ob močnem vetru.



Med uporabo vedno uporabljajte ognevarne rokavice.



Rok in drugih udov ne potiskajte v notranjost peči.



Med uporabo se zunanjosti peči ne dotikajte.



Strogo prepovedano pihanje v peč.



Poskbite, da se otroci in živali med uporabo peči ne zadržujejo v bližini.

## SPLOŠNA NAVODILA



### PRED PRVO UPORABO

Preden se lotite kulinaričnega ustvarjanja z novo Glowne Raptor pečjo skrbno preberite navodila za uporabo, da se seznanite z lastnostmi peči in jih shranite za poznejša morebitna vprašanja.



## PREDPEČENJE

Pred prvo uporabo zakurite peč in jo na najvišji temperaturi kurite najmanj 45 min. Postopek imenujemo predpečenje. Po kurjenju pustite, da se peč ohladi in obrišite notranjost s suho krpo. Ta postopek dezinfekcije bo sežgal olja in premaze, ki so ostali od proizvodnega procesa. V tem koraku se iz peči močneje pokadi, ker je potrebno, da se barvni nanosi popolnoma zapečejo na peč. Sedaj je peč pripravljena za pečenje hrane.

Prvi korak k okusni hrani, je visoko kakovostno gorivo. Uporabljajte samo bukova suha drva. Pri kurjenju na plin pa vedno preverite plinske povezave, rezervoar, cevi in regulator, da preprečite morebitno uhajanje plina.

Peč postavite na dovolj trdno podlago, da drži peč in vaše potrebne sestavine. Priporočamo kovinske in kamnite površine, vsekakor pa odsvetujemo uporabo steklenih in plastičnih.

Če želite zamenjati vrsto goriva (iz drva na plin ali obratno), je bistvenega pomena ohladitev peči pred menjavo gorilnika.

Če potrebujete nižjo temperaturo ali samo malo počitka, temperaturo v peči preprosto znižate tako, da v notranjost ne dodajate goriva ali z regulatorjem samo zmanjšate dovod plina.

Čiščenje in premikanje peči je priporočeno, ko se le ta ohladi (približno 2 uri po koncu kurjenja). Shranjevanje hladne peči je nujno v suhem in zračnem prostoru. Za ohladitev peči nikoli ne uporabljajte vode.

# 03

## KAJ JE V ŠKATLI?

### 1. Peč

V celoti izolirana glavna komora zadržuje vso potrebno toplobo. Integrirane nedrseče noge poskrbijo, da peč stoji trdno in varno.


### 2. Plošča za peko

Plošča za peko zadržuje vso potrebno toplobo.

### 3. Kurišče

Odstranljivo kurišče lahko po uporabi odstranimo in očistimo.

1.



2.



3.



## KATERO GORIVO UPORABITI?

Peč GLOWEN RAPTOR je zasnovana za uporabo s trdimi gorivi, kot je les, lahko pa jo z dodatkom plinskega gorilnika, uporabljate tudi na plin. Izberite si gorivo, ki vam bolj odgovarja. Peč se segreva super hitro in zadržuje toploto. Kroženje zraka je enako kot v pravih, zidanih krušnih pečeh. Najvišja temperatura je na vrhu komore, najmanjša pri vstopu zraka v peč. Kurite počasi in sproti opazujte ter po potrebi izmerite temperaturo. Preden se lotite novega pečenja, s krtačo očistite morebitne ostanke pepela.

## KURJENJE Z LESOM

Prasketanje lesa v ognju ustvarja posebno izkušnjo, dim pa hrani doda aroma. Priporočamo pečenje s popolnoma suhim bukovim lesom. Za agresivnejše gorenje uporabljajte manjše kose lesa, za počasnejše gorenje, večje. Če kurite dlje časa, pepel odstranite v kovinsko vedro, napolnjeno z vodo.

Nikakor ne uporabljajte obdelanega ali barvanega lesa. Les z visokim deležem smole, kot sta smreka in bor lahko hrani dodata neželene aromе.

## NAVODILA ZA NEGO

### Kje naj peč shranim?

Priporočamo, da GLOWEN RAPTOR ob neuporabi shranjujete v suhem in zaprtem prostoru, da peč zaščitite pred različnimi vremenskimi vplivi.

### Kako očistim peč?

Vedno počakajte, da se peč popolnoma ohladi, šele nato se lotite čiščenja. Po potrebi notranjost čistite s suho krpo. Zunanje površine lahko obrisete z vlažno krpo in popolnoma osušite, preden peč pospravite.

### Kako očistim ploščo za peko?

Ploščo za peko očistite s kurjenjem Gloven Raptor pečjo pri najvišjih temperaturah. Če morate odstraniti težje ostanke hrane, uporabite krtačo.

# 07

## ODPRAVLJANJE TEŽAV

Pice in jedi na osnovi testa pecite neposredno na plošči, ostale jedi v litoželeznih ponvah.

### Kako ugasnem Glownen Raptor?

Pustite, da trdo gorivo znotraj izgori in počakajte, da se ohladi. Hlajenje je odvisno tudi od temperature okolice. Odvečen pepel odvržete v kovinsko posodo, napolnjeno z vodo. Pri ohlajanju peči ne uporabljajte vode.

Pri plinskih gorilnih samo ugasnete plin.

Popolnoma normalno je, da različna goriva proizvajajo različen dim. Na prvem predpečenju se bo s peči pokadilo nekoliko drugače zaradi dodatnega zapečenja barve na površino. Po predpečenju bo med uporabo gorelo z minimalnim dimom. Če v peči ne gori, gre za uporabo neprimernega goriva (na primer mokra drva). Les za kurjenje vedno shranjujte na toplem in suhem okolju, saj močno absorbira vlago. Mokra drva ne bodo izgorevala čisto in učinkovito, želene temperature pa ne boste dosegli. Preverite tudi dimnik, da imate prosto pot zraka na prosto.

### Na peči opažam spremembo barve

Glownen Raptor je izdelana iz visokokakovostnega barvanega nerjavečega jekla. Na jeklu lahko po ponavljajočih ogrevalnih ciklih opazite nekaj barvnih sprememb, patine, vendar ti ne vplivajo na kakovost peči. Ne pozabite shranjevati peči v suhem in zaprtem prostoru.

### V kurišču imam preveč pepela

Pepek je naravni ostanek pri gorenju naravnih goriv. Odvečno količino pepela, ki se nabere v kurišču lahko odstranimo z loparjem v kovinsko posodo napolnjeno z vodo. Pri odstranjevanju pepela uporabljamo ognjevarne rokavice, da preprečimo morebitne poškodbe in opekline.

### Temperatura v peči je previsoka

Korigiranje z gorivom je najlažji način za hlajenje peči. Če je v peči prevroče, enostavno ne dodajte goriva ali plamen zmanjšate na regulatorju plina in počakate, da se ohladi do primerne temperature.

### Temperatura v peči je prenizka

Glowen Raptor se segreva približno 15 min nadrva in nekoliko dlje na plin, odvisno od načina kurjenja in spremnosti kurjača. Če je temperatura prenizka preprosto dodajte drva ali povečate plamen na regulatorju plina.

Opomba: Če je bila vaša peč izpostavljena dežu ali ekstremnemu mrazu lahko segrevanje traja dlje.

### Plošča za pečenje je počila

Plošče so izdelane iz naravnega materiala in počijo, kadar so bile prehitro izpostavljene previsoki temperaturi. Predpečenje naj bo zmerno. Plošče so potrošni material in garancija za njih ne velja.



Če imate vprašanja ali komentarje, nam pišite na [info@glowen.si](mailto:info@glowen.si)

# 08

## VARNA UPORABA

- Glown Raptor se sme uporabljati samo zunaj ali v dobro prezračevanem prostoru.
- Ne uporabljajte peči v šotoru.
- Ne uporabljajte Glown Raptor na zaprtih balkonih.
- Glown Raptor ni primeren za uporabo v vozilih ali prtljažnikih vozila.
- Peč postavite na ravno, negorljivo površino brez ostankov gorljivih materialov.
- Gorilnikov ne poskušajte uporabljati z drugimi pečmi. To pomeni razveljavitev garancije.
- Za kurjenje Glown Raptor peči ne uporabljajte gorilnikov, ki niso last Glown Raptorja ali neodobrenih gorilnih drugih proizvajalcev.
- Med uporabo gorilnikov ne odstranjujte.
- Pred uporabo se prepričajte, da je gorilnik varno in pravilno nameščen.
- Ne uporabljajte obdelanega, pobaranega ali svežega lesa.
- V bližini Glown Raptor ne shranujte gorljivih materialov.
- Med uporabo ne skušajte v peč vstavljati vnetljivih tekočin.
- Pri uporabi Glown Raptor peči vedno uporabljajte toplotno odporne rokavice.

## GARANCIJA

### Kaj zajema garancija?

Garancija se nanaša na Glownen Raptor peč.

Omenjena garancija ni prenosljiva in velja samo za prvotnega kupca. Za uveljavljanje garancije je potreben original račun.

Glow seven d.o.o. jamči, da izdelki (v nadaljevanju izdelek) ne bodo imeli pomanjkljivosti v izdelavi in materialih.

Garancija velja 2 leti od datuma nakupa.

Če Glow seven d.o.o. ugotovi nepravilnosti, izdelek ali rezervni del brezplačno menja. Zagotavljamo vzdrževanje in zagotavljanje nadomestnih delov za izdelek v zakonsko določenem roku (18. točka Zakona VP).

### Česa garancija ne vključuje?

Garancija ne velja v primerih, če kupec ni ravnal v skladu s priloženimi navodili.

Garancija ne krije škode ali okvare, ki bi izvirala iz običajne obrabe izdelka, zlorabe, malomarnosti, nepravilnega vzdrževanja, nesreče ali razbarvanja izdelka.

Garancija ne krije poškodb izdelka zaradi uporabe v druge namene, kot je izdelek predvidoma izdelan. Prav tako ne krije, če je izdelek posegala nepooblaščena in nestrokovna oseba.

Garancija ne krije poškodb na izdelkih kupljenih na neodobrenih prodajnih mestih, vključno s tretjimi osebami in trgovci na Bolhi, Amazonu, E-bayu.

Garancija ne velja za glinene plošče.

### Garancijski zahteveki

Vse garancijske zahteve je potrebno predložiti neposredno na Glow seven d.o.o. in sicer na glowenpizza@gmail.com z zadevo garancijski zahtevek v času trajanja garancije z original računom in pojasnilom napake na izdelku. Nepopolna vračila ne bodo sprejeta.

Ko Glow seven d.o.o. prejme vašo zahtevo za uveljavljanje garancije jo potrdi ali ovrže (običajno 7-10 delovnih dni). Po potrditvi reklamacije, boste lahko poškodovan izdelek vrnili na stroške podjetja s priporočeno pošto. Odgovorni ste za carino in davke, ki ob tem nastanejo. Glow seven d.o.o. ne odgovarja za izdelke izgubljene med transportom.

## TABLE OF CONTENTS

<b>01</b>	<b>Important information</b>	.....	Page 10
<b>02</b>	<b>General instructions</b>	.....	Page 11
	Before first use		
	Pre-baking		
<b>03</b>	<b>What's in the box?</b>	.....	Page 12
<b>04</b>	<b>Which fuel to use?</b>	.....	Page 13
<b>05</b>	<b>Firing with wood</b>	.....	Page 13
<b>06</b>	<b>Care instructions</b>	.....	Page 13
	Where should i store the oven?		
	How do i clean the oven?		
	How do i clean the cooking stones?		
	How do i turn off the glown raptor?		
<b>07</b>	<b>Troubleshooting</b>	.....	Page 14
	I notice a change in colour on the oven		
	I have too much ash in the fireplace		
	The oven temperature is too high		
	The oven temperature is too low		
	The cooking stone cracked		
<b>08</b>	<b>Safe use</b>	.....	Page 16
<b>09</b>	<b>Warranty</b>	.....	Page 17
<b>10</b>	<b>Oven dimensions</b>	.....	Page 18

**IMPORTANT**

Your safety is most important, therefore read the attached instructions carefully and save them for later use.



Glowen raptor is designed for outdoor use, therefore do not use it indoor.



Never use the oven without supervision.



Do not use the oven in strong wind.



Always use heat-resistant gloves when using the oven.



Do not put hands and other limbs inside the oven.



Do not touch the exterior of the oven when using it.



Blowing into the oven is strictly forbidden.



Keep children and animals away from the oven while using it.

# 02

## GENERAL INSTRUCTIONS



### BEFORE FIRST USE

Before starting with your culinary creations with the new GLOWEN Raptor oven, carefully read the instructions for use to familiarize yourself with the features of the oven and save them for any questions you may have later.



## PRE-BAKING

Before the first use, fire up the oven and let it heating up at the highest temperature for at least 45 minutes. The process is called pre-baking. After that, allow the oven to cool down and wipe the inside with a dry cloth. This disinfection process will burn oils and coatings left over from the manufacturing process. In this step, it smokes harder from the oven, since it is necessary for the paint coatings to burn completely onto the oven. Now the oven is ready for cooking food.

The first step to delicious food is high quality fuel. Use only dry beech wood. However, when burning gas, always check the gas connections, tank, pipes and regulator to prevent any gas leaks.

Place the oven on a solid enough base to hold the oven and the necessary ingredients. We recommend metal and stone surfaces, but we definitely do not recommend the use of glass and plastic. If you want to change the type of fuel (from wood to gas or vice versa), it is essential to cool the oven before changing the burner.

If you need a lower temperature or just a little rest, you can simply lower the temperature in the oven by not adding fuel to the interior or just reducing the gas supply with the regulator.

It is recommended to clean and move the oven when it has cooled down (approximately 2 hours after the end of firing). It is essential to store the cold oven in a dry and airy place. Never use water to cool the oven.

## WHAT'S IN THE BOX?

### 1. Oven

The fully insulated main chamber retains all the necessary heat. Integrated non-slip feet ensure that the oven stands firmly and safely.


### 2. Cooking stone

Clay stone that retains the necessary heat.

### 3. Fireplace

The removable fireplace can be removed and cleaned after use.


### 1.



### 2.



### 3.



# 04 & 05 & 06

## WHICH FUEL TO USE?

GLOWEN RAPTOR is designed for use with solid fuels such as wood, but also gas can be used with the addition of a gas burner. Choose the fuel that suits you best. The oven heats up super-fast and retains heat. The air circulation is the same as in real, masonry wood-burning ovens. The highest temperature is at the top of the chamber, the lowest where air enters the oven. Burn slowly and observe, and measure the temperature if necessary. Before you start cooking again, clean any ash residue with a brush.

## FIRING WITH WOOD

The crackling of wood in a fire creates a special experience, and the smoke adds flavour to the dish. We recommend cooking with completely dry beech wood. For smaller aggressive burning, use smaller pieces of wood, for slower burning, larger ones. If burning for a long time, remove the ash to a metal bucket filled with water.

Never use treated or painted wood. Wood with a high proportion of resin, such as spruce and pine, can add unwanted flavours to dishes.

## CARE INSTRUCTIONS

### Where should I store the oven?

We recommend that you store the GLOWEN RAPTOR in a dry and closed place when not in use to protect the oven from various weather conditions.

### How do I clean the oven?

Always wait for the oven to cool completely before cleaning. If necessary, clean the inside with a dry cloth. The outer surfaces can be wiped with a damp cloth and dried completely before storing the oven.

## TROUBLESHOOTING

### How do I clean the cooking stone?

Clean the cooking stone by firing the Gloven Raptor oven at the highest temperatures. If you need to remove heavier food debris, use a brush. Make pizzas and dough-based dishes directly on the stone, other dishes in cast iron pans.

### How do I turn off the Gloven Raptor?

Allow the solid fuel inside the oven to completely burn off and wait for it to cool. Cooling also depends on the ambient temperature. Discard excess ash in a metal container filled with water. Do not use water to cool the oven.

With gas burners, you just turn off the gas.

It is perfectly normal for different fuels to produce different smoke. On the first pre-baking, the oven will smoke slightly differently due to the additional baking of the paint on the surface. After pre-baking, it will burn with minimal smoke during use. If the oven does not burn, the used fuel is unsuitable (for example, wet wood). Always store firewood in a warm and dry environment, as it strongly absorbs moisture. Wet firewood will not burn in a clean and efficient way, and you will not reach the desired temperature. Also make sure that the chimney has free airflow.

### I notice a change in colour on the oven

Gloven Raptor is made of high quality painted stainless steel. You can notice some colour changes - patina - on the steel after repeated heating cycles, but these do not affect the quality of the oven. Remember to store the oven in a dry and closed place.

### I have too much ash in the fireplace

Ash is a natural residue in the burning of natural fuels. Excess ash that accumulates in the firebox can be removed with the peel in a metal container filled with water. When removing ash, use heat-resistant gloves to prevent possible injuries and burns.

# 07

## The oven temperature is too high

Correcting with fuel is the easiest way to cool the furnace. If it is too hot in the oven, simply do not add any more fuel (wood) or reduce the flame with the gas regulator and wait for it to cool to a suitable temperature.

## The cooking stone cracked

The cooking stones are made of natural material and crack when exposed to a too high temperature too quickly. Pre-baking should be moderate. The stones are consumables and are not covered by the warranty.

## The oven temperature is too low

The Clowen Raptor needs to be heated for about 15 minutes on wood and a little longer on gas, depending on the firing method and the skills of the fireman. If the temperature is too low simply add fuel or increase the flame with the gas regulator.

**Note:** If your oven has been exposed to rain or extreme cold, heating may take longer.



If you have any questions  
or comments, email us at  
[info@glowen.si](mailto:info@glowen.si)

## SAFE USE

- Glown Raptor should only be used outdoors or in a well-ventilated area.
- Do not use the oven in a tent.
- Do not use the Glown Raptor on enclosed balconies.
- Glown Raptor is not suitable for use in vehicles or trunks.
- Place the oven on a flat, non-combustible surface with no residual combustible materials.
- Do not try to use the burners with other ovens. This will void the warranty.
- Do not use burners that are not part of the Glown Raptor or unapproved third-party burners in the Glown Raptor ovens.
- Do not remove burners during use.
- Before use, make sure that the burner is securely and correctly installed.
- Do not use treated, painted or fresh wood.
- Do not store flammable materials near the Glown Raptor.
- Do not attempt to add flammable liquids into the oven during use.
- Always use heat-resistant gloves when using the Glown Raptor oven.

# 09

## WARRANTY

### What does the warranty cover?

The warranty applies to the Glowen Raptor oven.

This warranty is not transferable and only applies to the original purchaser. An original invoice is required to enforce the warranty.

Glow seven d.o.o. guarantees that the products (hereinafter the product) will not have defects in workmanship and materials.

The warranty is valid for 2 years from the date of purchase. If Glow seven d.o.o finds irregularities, the product or spare part will be replaced free of charge.

We ensure maintenance and provision of spare parts for the product within the statutory period (Article 18 of the Slovenian Consumer Protection Act).

### What does the warranty not cover?

The warranty does not apply in cases where the customer has not complied with the enclosed instructions.

The warranty does not cover damage or defects resulting from normal wear and tear of the product, misuse, negligence, improper maintenance, accident or discolouration of the product. The warranty does not cover damage to the product due to use for purposes other than intended. It also does not apply if the product has been tampered with by an unauthorized or unprofessional person.


The warranty does not cover damage to products purchased at unauthorized points of sale, including third parties and retailers from Bolha, Amazon, E-bay websites.

The warranty does not apply to clay stones.


### Warranty Claims

All warranty claims must be submitted directly to Glow seven d.o.o, namely to [info@glowen.si](mailto:info@glowen.si) with the subject "Warranty claim during the warranty period" with the original invoice attached and an explanation of the defect on the product. Incomplete returns will not be accepted. When Glow seven d.o.o. receives your warranty claim, it confirms or rebuts it (usually 7-10 business days). After confirming the complaint, you will be able to return the damaged product at the expense of the company by registered mail. You are responsible for the customs duties and taxes that arise. Glow seven d.o.o. is not responsible for products lost during transport.

DIMENZIJE PEČI / OVEN DIMENSIONS



Pogled spredaj / Front view



Pogled desna stran / Right side view

**ZAPISKI / NOTES**

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



## OSTANITE Z NAMI

Radi pogledamo, kaj ustvarjate v naših pečeh, zato lahko nas lahko prosto označite pri objavljanju svojih fotografij z #glowen #glowenoven

Spremljajte nas na naših omrežjih

& glowenoven



Če imate vprašanja ali komentarje, nam pišite na [info@glowen.si](mailto:info@glowen.si)

## STAY WITH US

We love to see what you create in our ovens, therefore feel free to tag us when posting your photos with #glowen #glowenoven

Follow us on our social networks

& glowenoven



If you have any questions or comments, email us at [info@glowen.si](mailto:info@glowen.si)