

Operation Instructions

Before use please carefully read the following instructions

- 1: After purchasing, it should be charged for at least 4 hours before use. It takes approximately 4-5 hours to fully charge.
- 2: When using this product for the first time, please use the USB charging cable provided with the product to fully charge the battery. This product can be charged using a computer USB interface, as well as a power adapter with a USB interface, with a charging parameter of 5V/1A.
- 3: Do not use a fast charger for charging to avoid overcharging and damage to the battery.
- 4: The hamburger lamp needs to be used frequently. If it is left unused for a long time, it needs to be charged every month of storage. Each charge should not be less than 4 hours, otherwise it will reduce the battery life.
- 5: When the hamburger lamp is fully charged, it is necessary to unplug the charging wire to avoid overcharging.
- 6: This hamburger lamp has a touch sensitive switch with three levels of brightness: low light, medium light, and high light. One touch for low gear; Two touches for mid range; Three touches for high-end; You can adjust the brightness of the lights by tapping according to your different environment and needs.
- 7: The lamp head and base of this desk lamp are connected by a wrapped rubber hose, which can be adjusted in height according to user needs or used as a night light when closed.
- 8: Continuously use the new product when fully charged, for about 30 hours at low levels; Mid range takes about 12 hours; High end takes about 8 hours.
- 9: During use, when the brightness of the light is dim, it indicates that the battery is in a low battery state. To protect the battery, it should be stopped and charged in a timely manner. Please try to avoid charging after completely losing power, otherwise the battery is prone to damage.
- 10: Charging indicator: The indicator light remains on during charging and goes off when fully charged.

