

LED Watch Instruction Manual

Display Mode

Press Button A once to show time, twice to show date, three times to show seconds.
To start over, don't press any button, screen will automatically turn off after 3 seconds.

Time Setting (Hour/Minute/Month/Date/Year)

1. Press Button A once then press Button B once to enter Setting Mode (Hour digit will start flashing)
2. Press Button A to set Hour, once it is set, press Button B to switch to Minute setting;
3. Press Button A to set Minute, once it is set, press Button B to switch to Month setting;
4. Press Button A to set Month, once it is set, press Button B to switch to Date setting;
5. Press Button A to set Date, once it is set, press Button B to switch to Year setting;
6. Press Button A to set Year, once it is set, press Button B to switch to 12/24hr setting;
7. Press Button A to select 12 or 24 hour display mode, press Button B to confirm setting.
8. To start over, do not press any button, screen will automatically turn off after 3 seconds.

Battery: 1X Maxell CR2016

DO NOT MIX OLD AND NEW BATTERIES
DO NOT MIX ALKALINE, STANDARD (CARBON-ZINC),
OR RECHARGEABLE (NICKEL-CADMIUM) BATTERIES.
DO NOT IMMERSE IN WATER
DO NOT WEAR IF CASEBACK IS MISSING OR DISASSEMBLED



Removing the Band from Your Watch:

Lay your watch with the face down (preferably on a cloth to prevent scratching your watch)



You will need a sharp point or "spring bar tool" to perform the following steps.



Changing Your Strap on your Watch:

1. Insert the sharp point between the strap and watch lug to release strap from case.



2. Once the spring bar is detached you can remove your strap. To reattach, depress spring bar and insert into hole on the inside of the watch case lug.

MADE IN CHINA