

LED Watch Instructions

Function

1. Under normal time display mode,
LED watch show: Hours, Minutes
Can set : Years, Months, Dates.



2. Operate push button

Setting the Time and Date

Push button one time, will show hour, minute.
Push button for 2 seconds, the watch will enter
setting mode.

1. Push button for 2 second, setting Hours, morning
means "A" , afternoon means "P"

2. Push button for 2 second, setting Minute

3. Push button for 2 second, setting Year

4. Push button for 2 second, setting Month

5. Push button for 2 second, setting Date

When finish the setting mode, no push button for 2
seconds, will become the time display mode will
become standby mode after 2 seconds

Battery: 1 X Maxell CR2016(3V)

DO NOT MIX OLD AND NEW BATTERIES


DO NOT MIX ALKAUNE, STANDARD(CARBON-ZINC)
OR RECHARGEABLE(NICKEL-CADMIUM) BATTERIES.

DO NOT IMMERSE IN WATER


DO NOT WEAR IF CASEBACK IS MISSING OR
DISASSEMBLED

Removing the Band from Your Watch:

Lay your watch with the face down (preferably on a cloth to prevent scratching
your watch)




You will need a sharp point or "spring bar tool" to perform the following steps.



Changing Your Strap on your Watch:

1. Insert the sharp point between the strap and watch lug to release strap from case.



2. Once the spring bar is detached you can remove your strap. To reattach, depress
spring bar and insert into hole on the inside of the watch case lug.

MADE IN CHINA