

Temperature Control

Celsius Parameter Programming

1. Press and hold the **SET** + **▼** keys until the “°C” or “°F” LED flashes, then release the keys.
2. Press and hold again the **SET** + **▼** keys until the **Pr2** label is displayed, then release the keys.
3. Press the up key **▲** to scroll to the parameter **CF** within 10 sec.
4. Press the “**SET**” key to display the current parameter value.
5. Use the down key **▼** to change the parameter value to **C** within 10 sec.
6. Press “**SET**” to save the new value. The display will flash 3 times.
7. Press up/down keys **▲/▼** to scroll to other parameters and change the values as follows.
8. **To exit:** Press **SET** + **▲** or wait 15sec without pressing a key.

PARAMETER	DESCRIPTION	VALUE
Hy	temperature regulation differential (°)	2
CF	temperature unit (°F/ °C)	C: Celsius
US	maximum set-point (°)	20
LS	minimum set-point (°)	5
ALU	high temperature alarm (°)	5
ALL	low temperature alarm (°)	5
AFH	alarm recovery differential (°)	2
SAA	heater set-point (°)	4
Shy	heater regulation differential (°)	2

8. Change the set-point
 - 1) Press and hold the **SET** key until the “°C” or “°F” LED starts flashing and the set-point is displayed.
 - 2) Press the up key **▲** to change the set-point value to 13 within 10 sec.
 - 3) Press the **SET** key again to store the new set-point value.

NOTE: Depending on the controller, not all parameters are used.