
IONMAX LEONE PRO QUICK INSTALLATION GUIDE



- 1. Place the unit in an upright position on a stable, level surface. Please ensure the unit is not sitting on its own cable.
- 2. Only use the unit in areas larger than 7m².
- 3. Please ensure the unit is a safe distance away from walls and furniture (as shown above).
- 4. Please keep clothes at a safe distance of 30cm from air outlet of the unit to prevent water dripping into the unit.
- 5. For best results, position the dehumidifier somewhere central like a landing or a hallway. As long as the internal doors are open, the excess moisture from all of the rooms in the house will migrate naturally towards the dehumidifier and be processed.



Do not install or operate the dehumidifier in the following conditions:


- areas smaller than 7m²
- small unventilated rooms or confined areas
- · areas where flammable gas may leak



- in close proximity to a heat source such as radiators, tumble driers and stoves
- under direct sunlight



- · areas where oil or water may be splashed
- · mechanical vibration or shock
- · excessive dust
- uneven surface





For more information or to troubleshoot, please refer to the user manual.

Scan the QR code or visit ionmax.com.au/leone-pro-manual

MOBILE APP SETUP



Download the lonmax app on your phone.

Scan the QR code or visit ionmax.com.au/app



1 Register a new account on your phone, or log in to your existing account for the lonmax app.

3 Ensure that the WiFi indicator on the dehumidifier is flashing during the connection process.

2 Place the dehumidifier at a distance of at least 5 meters from your router.

If the WiFi indicator is not lit, hold down the Timer button on the dehumidifier for 5 seconds until the WiFi indicator is flashing quickly. This indicates that the dehumidifier is ready for connection.

Plug the dehumidifier into an appropriate power outlet and switch it on.



Cancel

Select 2.4 GHz Wi-fi
Network and enter password
if your Wi-Fi is 5GHz, please set it to be 2.4GHz

Wi-Fi - 5Ghz

Wi-Fi - 2.4Ghz

Connect the dehumidifier to your phone via Bluetooth or Wi-Fi

Method 1: Connect via Bluetooth

- Enable the Bluetooth function on your mobile phone.
- · Open the lonmax app on your mobile phone.
- · The app will search for the dehumidifier and connect automatically.
- · Follow the prompts on the app to finish the Bluetooth connection.

Method 2: Connect via Wi-Fi

- On your lonmax app, select or create a new location for your dehumidifier.
- Select "Devices" and click on "+" to add a new device.
- Select product type "Dehumidifier" and "EZ mode" (default).
- · Enter your WiFi network SSID and password on the app.
- * Please use a 2.4GHz network only.
- The app will search for the dehumidifier and connect automatically.

Once the dehumidifier is successfully connected, the WiFi indicator will stop flashing and remain lit up. You can now monitor and operate the dehumidifier using the mobile app.

WARRANTY DETAILS

Congratulations on your purchase! It is our aim to provide you with quality products that you can trust. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The Guarantee

The product is guaranteed to be free from defects in workmanship and parts for a period of 24 months from date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Trade Practices Act and similar state laws.

Proof of Purchase

This warranty is valid for the original purchase and is not transferable. Please keep your purchase docket or receipt as proof of purchase and as proof of date on which the purchase was made. The purchase docket (or a copy) or receipt must be presented with the warranty when making a claim under this warranty.

Service during the Warranty Period

To claim for warranty, contact us on 1300 800 200 or support@andatech.com.au to get an RA# (Return Authorisation Number) or submit a support ticket on my.andatech.com.au. Ensure that the RA# is clearly stated on the outside of the packaging and that the product is properly packaged so that no damage occurs to the product during transit. Shipping of the product back to us for warranty will be at your cost. A product return without the RA# will not be accepted.

Extent of Warranty

This warranty is limited to defects in workmanship or parts. All defective products or parts will be repaired or replaced. This warranty does not cover manuals and packaging.

Normal Wear and Tear

This warranty does not cover normal wear and tear to the product or parts.

Exclusions

This warranty does not cover:

- Any defect caused by an accident, misuse, abuse, improper operation, lack of reasonable care, unauthorised modification, loss of parts, tampering or attempted repair by a person not authorised by the distributor.
- Any product that has been damaged by a lightning strike either directly or indirectly or a main power surge or liquid ingress.
- The product if it is located outside of Australia.
- Any damage caused by improper power input or improper cable connection.

Register your warranty online at my.andatech.com.au

Andatech Pty. Ltd.

PO Box 3038, Nunawading VIC 3131, Australia.

Phone: 1300 800 200 Fax: 1300 883 802 Email: support@andatech.com.au

