



BETTY &
BERTIE
MOBILITY

LUPIN

HOW TO CARE FOR YOUR TYRES

TYRE PRESSURE

We recommend the tyre pressure to be between 24 and 32 PSI, depending on your preference of riding. For example, if you require more support and a smoother ride then inflate to a higher PSI.

HOW TO MEASURE

Tyre pressure can be measured with a standard pressure gauge:

1. Put the pressure gauge onto the tyre valve stem.
2. Press down the gauge evenly on the valve stem to ensure you get an accurate reading.
3. Check the reading on the pressure gauge to determine if you'll need to deflate or inflate your tyres.

A standard bike pump can be used to inflate the tyres if they need it.

WHAT TO DO IF YOU GET A PUNCTURE

We do suggest that you use a tyre inflator and sealer before using the scooter to protect your tyres from puncture. If you are unsure on what this is, please contact us and we will recommend a suitable product.

We also sell inner tubes which can be kept as spares. If you do get a puncture, you can change the inner tube so that you are never caught out.