


1. Weak water pressure from the nozzle


When the water pressure from the nozzle is weak

When the water pressure from the nozzle is weak


1. Open the water valve and reset the unit




① Unplug the cord



② Fully open the water valve counterclockwise



③ Water valve fully opened



④ Plug the cord back

When the water pressure from the nozzle is weak

2. Check the remote setting




* Push the water pressure button to highest to adjust the water pressure.



Please test the function again at this stage. If the problem is not resolved, please move on to the next page and follow the instruction.

When the water pressure from the nozzle is weak

3. Clean the mesh



Close the water valve



Detach the hose



Check the debris in the mesh and use a tool to pull out the mesh



Remove all debris





Wash the mesh in the running water



Attach the mesh again

When the water pressure from the nozzle is weak

4. Check the hose



* Detach the hose and check the rubber packing from the hose



Please test the function again at this stage. If the problem is not resolved, please contact our customer support team so that we can provide replacement unit with prepaid return label.