





WI-LTE117-O

Outdoor LTE Router for IP cameras with two PoE ports
Quick Install Guide

Package content




X1



X1



X2




X1



X1

Hardware Overview




Action	Status Indication
WAN/LAN	It is a Ethernet port, which can serve as a WAN port or a LAN port. By default, it is a LAN port. 1) When the router is under 4G router mode, it serves as a LAN port. 2) When the router is under SOHO router, Eth-First Router and 4G-First Router, it serves as a WAN port.
LAN	It is a LAN port used to be connected to wired devices, such as a IP camera.
Card Slot	Insert 4G standard SIM card.
Reset	Press and hold for 8 seconds to restore the factory settings.

Mounting


Step 1:

Lead the end of the pole mounting




Step 2:

Fix the device position and wrap the pole installation strap around the pole. Pass one end through the screw block and tighten the screw block and tighten the belt until the device is secured.




Network application

Flexible Power Option



OR



Login method




Please connect devices according to the above topology.

Follow the steps for quick Router configuration, using initial setup wizard:
Step 1 Connect your PC to device via Ethernet or Wireless.

Note:

- Default WiFi name: **WI-TEK_XXXX**, Password: **88888888**


Step 2 Launch your web browser then enter <http://192.168.1.1> in the address bar and specify the default login key: **admin**.



Configuration steps

There are four working modes: SOHO Router, 4G Router, Eth-First Router, 4G-First Router

- The default mode is 4G Router, click Next to enter.




Note:

- Eth-First Router**: If and when the internet service becomes unavailable via the Eth connection, the router automatically switches to the LTE network.
- 4G-First Router**: If the LTE network service cannot be connected, the router will automatically switch to the Eth network.

- Select the country, fill in the wireless SSID, encryption method, and key information, and click Next to enter



- Click the complete button to complete the setting.




- Configuration complete.



Cloud management settings


- Launch your web browser then enter <http://cloud2.wireless-tek.com> in the address bar.
- Register an account password by user name or email.
- Log in to the cloud account with the account password after registration.




- Click ADD NETWORK



After the login is successful, the steps to bind the device on the cloud account are as follows:



- Fill in the group name and location, click save.




- And click next.




- Enter serial number, click ADD to create and click FINISH, the configuration is complete.

Note:

The 17-digit SN code of the 4G Router is shown on the sticker on the back of the device.




- In the relevant device options, you can see the bound device information.



- Click Tunnel, select 4G Router, click EWEB to log in to the device



- Click Tunnel, select 4G Router, click EWEB to log in to the device



Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within three months after purchase, we will provide you a new product of the same model.
- If the product defects within the three-year warranty period, we will provide the professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disaster, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card losing will disqualify the product from limited warranty.



Wireless-Tek Technology Limited
Address: Room 402 4F, BiaoFan Technology Building, Bao'An Avenue, FuYong Town, Bao'An district, ShenZhen
Website: www.wireless-tek.com
Tel: 86-0755-32811290
Email: sales@wireless-tek.com
Technical Support: tech@wireless-tek.com