

BORA

KAMBUKKA®


USAGE RECOMMENDATION

- Suitable for both hot and cold food.
- Hours it keeps food hot: graph 1
- Keeps food fresh for hours.
- All of our Kambukka food jars have been rigorously tested at full volume and under a constant temperature.
- Different types of food have different performances.
- 'Vent' function: push to release the internal steam and pressure before opening.
- Do not overfill. Fill liquid maximum up to the groove of the lid.
- If you fill the food jar with a boiling liquid, allow the liquid to cool down for at least 3 minutes before you close the lid. If not, internal pressure build-up can lead to leaks and severe burns.
- Make sure the lid is screwed down completely.
- Unscrew the lid before use.
- Do not keep food in the jar for longer than 24 hours.
- Do not microwave and do not freeze.
- For an optimal result, preheat or precool by filling with hot or cold water for 5-10 minutes.
- Keep out of reach of children when filled with hot liquids.
- Not suitable for children under the age of 3.
- Do not continue to use the product if damaged.

CLEANING INSTRUCTIONS


- Wash all parts with soapy water before first use.
- Lids are dishwasher safe. Use of dishwasher and detergents can have an impact on the color.
- Food jars with a painted or lacquered body are best washed by hand. Soak the product for 10 minutes in hot soapy water and wash with a mild detergent.
- Don't use cleaning substances containing bleach, chlorine, scouring agent and/or harsh chemicals.
- Always store with lid removed.

Thirsty for more? Combine your food jar with one of our trendy bottles or mugs. Visit www.kambukka.com for more details.



AIR VENT INSTRUCTIONS

Push the air vent to let out steam & reduce pressure



**BE HUNGRY,
EXPECT MORE**

GRAPH 1: HOURS HOT

