New Kestrel LINK Weather Application (iOS and Android)

The current Kestrel LiNK application is no longer supported as we have released a new version of the application on the Google Play and iTunes Stores. The older version of Kestrel LiNK was renamed Kestrel LiNK Legacy and can still be used, however once you update the firmware on your Kestrel through the new app, you may have issues going back to and using Kestrel LiNK Legacy.

What changes can you expect with the release of the new Kestrel LiNK application?



Kestrel LiNK App

- Maintains same functionality as previous app
- Much more user-friendly UI
- Ability to customize units for any measurement
- Numerous bug fixes from previous app
- Adds ability to update to latest firmware
- Customizable export management
- Additional features to be added



Kestrel LiNK Legacy App

- Will be eventually going obsolete
- Previously stored data will still be accessible

New Kestrel LINK Weather Application (iOS and Android)

Warning for First time users of the Kestrel LiNK App

Both a Firmware update and Bluetooth profile update will be needed to use the new Kestrel LiNK Weather app.



These updates WILL erase your device's data log. If you have data on the Kestrel that you absolutely need, you should first upload it to the Kestrel LiNK Legacy app BEFORE updating your firmware and Bluetooth profile using the new LiNK Weather app. Note: Update may take up to 20 minutes to complete and a fresh battery is recommended.


Data stored in the Kestrel LiNK Legacy app will not be able to be moved or imported into the new Kestrel LiNK Weather application. You can however export the data and keep in CSV form. See guidance for this in the Appendix.

Please review section entitled: *First Time Users – Saving Data and Updating Firmware* before proceeding.


Table of Contents

 First Time Users – Saving Data and Updating Firmware 	4-6
 Connecting and Device Settings 	7-12
Realtime Measurements	13-15
• History	16-19
• Options	20-21
 Appendix: Exporting from LiNK Legacy 	22

Step 1: Saving Current Data on Device



If you need to save data, first go to Kestrel LiNK Legacy







If you have data you want to save, please cancel the firmware update until you can save off the weather data.

Wait until spinning wheel reaches 100% to ensure data has been saved. You can then export the data on the Stats page.
(See Appendix for Exporting Data)

Step 2: Connect and Check for Firmware Update




Click on Device
Settings to check for new firmware and BLE profile.



Click to check if there
is a new firmware
update for your device

Step 3: Update BLE Profile and Firmware


(Note: Process may take more than 20 mins. Fresh battery is preferred)



Press Update to initiate BLE Profile Update



After BLE is completed you will see this screen.





You will need to reconnect and get prompted for a firmware update.



Run the firmware update this time and make sure it completes.

Using the Application – Connecting and Device Settings







Device Settings allows you to:

- Change name of device
- Manage Device Data
- Check for FW updates
- RH Calibration
- Device Info

Using the Application – Device Settings - Edit




Click on Edit to change the name or color of the Kestrel.




Enter a new name for the Kestrel and press Save when completed.

Swipe left or right to change the color of the Kestrel. Save when completed.

Using the Application – Device Settings – Manage Device Data



Click on Manage Device Data to manage Kestrel data.




- 1) Sync Data Press to get the latest data log from the Kestrel
- **2) Export Data** Export data to email or other platform
- 3) Device Sync Rate Time interval for how often Kestrel data is updated in the app
- 4) Data Logging Rate Time interval for how often the Kestrel device logs data
- 5) Wrap Log When ON, oldest data on the Kestrel will be overwritten with latest data. If OFF, logging will stop when logger full
- 6) Clear App Log Clears all stored memory in the app
- 7) Clear Device Log Clears all data in the Kestrel device
- 8) Power Saving When off, app will stay connected to Kestrel when app is in the background.


Using the Application – Device Settings – Manage Alerts



Click on Manage Alerts to setup alerts. Select Add Alert.




Select the measurement you would like to set an Alert.




- 1) Threshold Enter the alert value to monitor.
- 2) Direction Select Above if alert goes above threshold value, Below if alert goes below this value.
- 3) Clearing Events If set to ON, user will receive a notification when alert condition is resolved.
- 4) Notifications—Select between Quiet, Sound only or Sound and Vibration notifications.
- 5) Email Turn on to send an email alert as well as mobile alert.
- 6) Email Address Enter the email address in which to send the alert.


Using the Application – Device Settings – Check for Firmware Update and Device Info



Using the Application – Device Settings – RH Calibration



Click RH
Calibration to
view calibration
history of device.



- 1) RH Calibration Reminder Customer settable date used as a reminder for when RH needs to be recalibrated.
- 2) Reset Reminder Used to set the RH Calibration Reminder date shown at the top and will prompt user based on Reminder Settings.
- Reminder Settings Set
 Reminder interval, turn on/off
 email reminders, turn on/off
 App notifications for
 reminders.
- 4) RH Calibration History Log of the calibration history of the Kestrel device.


 \bigcirc

Ш

Using the Application – Realtime – Dashboard and List




Clicking on the Realtime tab will bring up realtime measurements




You can choose to view realtime measurements in List form as well.

To choose which values appear on dashboard or list view, click on the Edit icon




Click radio boxes on left to hide/show what appears. Drag and drop to change order.

Using the Application – Realtime – Capture




Clicking on Capture allows you to take a snapshot of the current conditions.




A snapshot will show and the data is saved to application. Press View to edit snapshot.

(Note: You can view all data in the History section)




Customize which measurements you want to include in snapshot.



Add notes and GPS information to the snapshot using Details tab.

Using the Application – Realtime – Start Recording





Click on Start Recording to record measurement data over a time period.



You will see the timer start, click Stop Recording to end data capture.


Please note that recording sampling will be based on Device Sync Rate (see Device Settings)







Session will be saved in History. You can view and edit in the same fashion as Snapshot. The one difference is the Stats page will show min/max/avg over the duration. 15

Using the Application – History – Viewing Data




The History tab is where you can view all your saved data.






Daily will show you a weekly or monthly calendar view for that specific device. Dots will appear under dates in which data was saved.




Click on the date and then session to view that data.


Using the Application – History – Viewing Data




There is also the Timeline view. Click on this to view all device data in the app.



Clicking on Select Devices brings up all the devices that have connected to app.





You can select which devices and specify a date range to show all the data.



By pressing the Select icon, you can choose multiple sessions to export.

Using the Application – History – Export Data






Whether you are exporting a single session or multiple sessions, pressing the Share button will bring up export options.

Note: to export the entire device log, go to Devices > Device settings > Manage device data and press the export data button (see pg 9)


1	Device Name	AGRICULT	R - 2445054	1								
2	Device Model	5500AGL										
	Serial Number	2445054										
	FORMATTED DATE_TIME	Temperat	Wet Bulb	Relative H	Barometri	Altitude	Station Pr	Wind Spe	Heat Inde	Dew Poin	Density A	Air Flow
5	YYYY-MM-DD HH:MM:SS	°F	°F	%	inHg	ft	inHg	mph	°F	°F	ft	cfm
6	12/18/2020 15:16	70.6	55.2	36.2	30.24	-298	30.24	0	68.5	42.6	513	(
7	12/18/2020 15:16	70.7	55.6	37.9	30.18	-243	30.18	0	68.7	43.7	588	(
8	12/18/2020 15:17	70.7	55.7	38	30.18	-243	30.18	0	68.7	43.9	590	(
9	12/18/2020 15:17	70.8	55.6	37.5	30.18	-243	30.18	0	69.1	43.6	597	
10	12/18/2020 15:17	70.8	55.9	38.4	30.18	-247	30.18	0	69.1	44.3	600	
11	12/18/2020 15:17	70.8	55.9	38.5	30.18	-243	30.18	0	69.1	44.3	600	
12	12/18/2020 15:18	70.9	55.9	38.3	30.18	-243	30.18	0	69.1	44.3	604	
13	12/18/2020 15:18	71	56.5	40.3	30.18	-243	30.18	0	69.3	45.7	621	
14	12/18/2020 15:18	71	57.5	43.6	30.18	-247	30.18	0	69.6	47.8	631	
15	12/18/2020 15:18	71	57.5	44.1	30.18	-243	30.18	0	69.6	48.1	631	
16	12/18/2020 15:18	71	57.5	43.8	30.18	-243	30.18	0	69.6	47.9	631	
17	12/18/2020 15:19	71.1	57.5	43.9	30.18	-247	30.18	0	69.8	48.1	638	
18	12/18/2020 15:19	71.1	58.1	45.6	30.18	-247	30.18	0	70	49	643	
19	12/18/2020 15:19	71.1	58.1	45.3	30.18	-247	30.18	0	70	48.9	643	
20	12/18/2020 15:19	71.5	58.3	45.2	30.18	-247	30.18	0	70.3	49.2	667	
21	12/18/2020 15:19	71.8	59.3	47.8	30.18	-247	30.18	0	70.9	51	703	
22	12/18/2020 15:19	71.7	59.3	48.1	30.18	-247	30.18	0	70.7	51	691	
22						2/17	2N 10	0	70.5	/10 0	670	
		2445054	_12_18_20_4	4	Ð							1

After exporting, the result is a CSV file that can be opened in Excel.


Using the Application – History – View Data Log



Click on the session log to view that day's data.




It'll appear in list form showing the min, avg and max




Click on a measurement to view in graphical form

Using the Application – Options – App Preferences



Click on Options to view app setting options.




Users can select Imperial, Metric or a Custom set of units for the measurements.

If using Custom, simply select the measurement and change the unit to the user-desired choice for each measurement.

App preferences allows you to Enable GPS auto-fill and change measurement units.

Using the Application – Options



On the Options page, users can also:

- Visit the Kestrel Store
- Review the FAQs
- View the App Information
- Contact Support or
- View the App Tutorial

Appendix – Exporting from Kestrel LINK Legacy

