

CHEFMAN®

RJ48 SERIES

# ERASE BOARD PERSONAL FRIDGE



**CUSTOMER SERVICE:** 888.315.6553 | [customerservice@chefman.com](mailto:customerservice@chefman.com)

## **Congratulations on your purchase!**

Every Chefman product is manufactured to the highest standards of performance and safety. We are confident that you will be so satisfied with your purchase that Chefman will be your go-to company for appliances in the future.

Customer satisfaction is a key element of our company's philosophy. The Chefman brand exists to fill a void on retail shelves and in consumer kitchens for a truly value-focused kitchen appliance. By questioning and adding value and innovation at every touch point in the manufacturer to end user journey, Chefman provides home chefs with the tools they need to achieve picture-perfect results with maximum efficiency. In addition to manufacturing appliances that are dependable, affordable and built with intuitive features to enhance your kitchen experience, we pride ourselves on providing top-of-the-line post purchase support, which includes complimentary access to ClubChefman.com for product tutorials, delicious recipes, how-to videos and access to our team of dedicated chefs.

Should a problem arise, each product is backed by a comprehensive manufacturer's 1-year warranty as well as outstanding after-sales service support through our dedicated customer service team. In the unlikely event that your product does not operate as described in the manual, please feel free to call or email our helpline for assistance. We understand that sometimes products can malfunction, so if you feel that your appliance is not operating as it should, warranty claims can be made within one year from the date of purchase when accompanied by a dated receipt.

This guarantee is in addition to your statutory rights; your statutory rights are not affected. This limited warranty does not apply in cases of damage caused by accident, improper use, abuse or force majeure.

This warranty gives you specific legal rights. Rights may vary depending on your state or province of residence. Some locations do not allow limitations on implied warranties or special incidental, or consequential damages, so the limitations may not apply to you. This limited warranty will be invalidated if the appliance is tampered with in any way whatsoever.

Our telephone helpline (888) 315-6553 is available for questions or technical assistance Monday through Friday, 9 am to 5 pm EST.

Customers can also receive support by emailing [customerservice@chefman.com](mailto:customerservice@chefman.com).



### **READ ALL INSTRUCTIONS BEFORE USE**

**For your safety and continued enjoyment of this product, always read the instruction manual before using.**

# CONTENTS

- 1** Introduction
- 2** Safety Instructions
- 4** Features
- 5** Operating Instructions
- 6** Cleaning and Maintenance
- 7** Terms and Conditions
- 8** Warranty Card

# INTRODUCTION

The Personal Fridge is an eco-friendly “green” product. It cools and warms using advanced semiconductors that are free of CFC’s and refrigerants. It’s insulated, ensuring that your food and beverages stay cold or warm.

The Personal Fridge is great to use on your desk, or in a car, boat, RV, or any other mode of transportation with a DC outlet. It’s lightweight and ergonomically designed with a convenient carrying handle. Use the included markers to write on the door\* and leave yourself little reminders. Simply wipe off with a damp cloth or paper towel to erase.

\*Chefman recommends only writing on the door to ensure proper cleanup.

# SAFETY INSTRUCTIONS

## IMPORTANT SAFEGUARDS

### READ ALL INSTRUCTIONS.

#### **THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.**

**WARNING:** When using electrical appliances, basic safety precautions should always be followed, including the following:

Read all instructions.

To prevent fire, electric shock and/or injury, do not immerse cord, plug, or Personal Fridge and Warmer in water or other liquids.

Close supervision is necessary when any appliance is used by or near children. Keep the Personal Fridge and Warmer and its supply cord out of the reach of children.

Unplug Personal Fridge from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning the appliance.

Do not operate any appliance that has been damaged in any way or has a defective cord or plug. In such cases, contact Chefman Customer Service for assistance.

The use of accessory attachments not recommended by Chefman may result in fire, electric shock or injury.

Do not let cord hang over the edge of the table or counter, or touch hot surfaces.

Do not place Personal Fridge on or near a hot gas or electric burner, or in a heated oven.

Do not use Personal Fridge for other than intended use.

To disconnect Personal Fridge, remove plug from wall outlet.

Allow 6 to 12 inches of clearance between the back fan of the Personal Fridge and any wall/obstruction for continued optimal operation.

When using for the first time, allow up to 12 hours for the Personal Fridge to reach its optimum temperature. After continued use, temperature wait times will decrease naturally.

When alternating between WARM and COOL, turn the switch to OFF. Wait 5 minutes, then switch to COOL or WARM.

When the Personal Fridge is in the WARM function, use care when handling to avoid burns.

When using the Personal Fridge in a car, pull the plug out of the power outlet when the car is stopped and turned off to save energy.

Switch Personal Fridge to OFF and unplug from power outlet when not in use.

Do not allow small children to play with markers; the pen cap poses a choking hazard.

Do not ingest marker ink.

# SAFETY INSTRUCTIONS

## SAVE THESE INSTRUCTIONS

**WARNING:** This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

### SHORT CORD INSTRUCTIONS

A short power supply cord is provided to reduce the hazards resulting from entanglement or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use. If a longer detachable power-supply extension cord is used:

1. The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance, and:
2. The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

### POWER CORD SAFETY TIPS

1. Never pull or yank on cord or the appliance.
2. To insert plug, grasp it firmly and guide it into outlet.
3. To disconnect appliance, grasp plug and remove it from outlet.
4. Before each use, inspect the line cord for cuts and/or abrasion marks. If any are found, this indicates that the appliance should be serviced and the line cord replaced. Please return it to an authorized service representative.
5. Never wrap the cord tightly around the appliance, as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.


### DO NOT OPERATE APPLIANCE IF THE LINE CORD SHOWS ANY DAMAGE OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

**CAUTION:** To ensure continued protection against risk of electric shock, connect to properly grounded outlets only.

**IMPORTANT:** During the first few minutes of initial use, you may notice smoke and/or a slight odor. This is normal and should quickly disappear. It will not recur after appliance has been used a few more times.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

# FEATURES



- 1. Stay-Cool Carrying Handle
- 2. Matte Finish Front for Writing
- 3. Door Handle
- 4. WARM/COOL/OFF Switch
- 5. DC/AC/OFF Switch
- 6. Green Indicator Light
- 7. Red Indicator Light
- 8. Removable Shelf
- 9. Markers (3)
- 10. AC Cord and Plug
- 11. DC Cord and Plug

# OPERATING INSTRUCTIONS

When the Personal Fridge is in the COOL function, the temperature will range between 27°F and 36°F. Use to store anything you would normally store in your home refrigerator: Beverage cans, yogurt, lunch, etc.

When the Personal Fridge is in the WARM function, the temperature will range between 131°F and 149°F—perfect for keeping already cooked foods at a food-safe temperature for serving.

## BEFORE FIRST USE

Remove all packing materials and stickers from the inside and outside of the Personal Fridge. Gently wipe down exterior and interior with a damp cloth or paper towel. Never immerse the Personal Fridge in water or any other liquids.

## HOW TO USE

1. Select your desired cord and plug. The DC cord and plug is for use with the power outlet in your car. The AC cord and plug is for use with a typical power outlet in your wall.
2. Plug the selected cord into the respective outlet (DC or AC.) The outlets are located on the back of the Personal Fridge. The DC outlet is rectangular while the AC outlet is oval-shaped. Both outlets are labeled.
3. Position the DC/AC/Off switch to the respective setting.
4. Position the Warm/Cool/Off switch to your desired setting.
5. Plug the Personal Fridge into the respective power outlet. Once the Personal Fridge is plugged in, the red indicator light will illuminate if WARM is selected or the green indicator light will illuminate if COOL is selected. Allow at least 30 minutes for the Personal Fridge to cool down or heat up. For best results, place already cold food or beverages into the fridge and already warm foods or beverages into the warmer.
6. To open the Personal Fridge, turn the door handle to the right and pull.
7. To close the Personal Fridge, push the door until it snaps shut.
8. To create more room for food or beverages, remove the shelf from inside the Personal Fridge.
9. Use the included markers to write on the door.\*
10. Unplug the Personal Fridge when not in use. Cool completely before storing by opening the door. Careful: If the WARM function was being used, Personal Fridge will be hot.

\*Chefman recommends only writing on the door to ensure proper cleanup.



# CLEANING AND MAINTENANCE

Wipe the Personal Fridge with a damp cloth or paper towel. The removable shelf may be washed with soap, water and a sponge.

To wipe off writing, use a damp cloth or paper towel. Dry completely.

Never immerse the Personal Fridge in water or other liquids.

Always allow the Personal Fridge to cool down completely, with the door open, before storing. Keeping the door open while it returns to room temperature will help prevent moisture and mold from potentially developing inside.

Always ensure that the Personal Fridge is completely dry before storing.

Always unplug the cord and plug when not in use and before storing.

Store in a cool, dry place.

# TERMS & CONDITIONS

## Limited Warranty

CHEFMAN® warrants, subject to the conditions stated below, that from the date of purchase, this product will be free from mechanical defects for a period of ONE (1) year. CHEFMAN®, at its option, will repair or replace this product found to be defective during the warranty period. Should this product become defective by reason of improper workmanship or material defect during the specified warranty period, CHEFMAN® will repair or replace the same effecting all necessary parts replacements for a period of one year from the date of purchase. If product is no longer available we will replace it with a product of equal value. Transportation charges on parts, or products in whole, submitted for repair or replacement, under this warranty, must be borne by the purchaser. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as specified on the rating label (e.g., 120V ~ 60 Hz).

This warranty is available to consumers only. You are a consumer if you own a CHEFMAN® product that was purchased at retail for personal, family or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners.

**CONDITIONS:** This warranty is valid for the original USA and Canada retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty service or replacement. Dealers, service centers, or retail stores do not have the right to alter, modify or in any way, change the terms and conditions of this warranty. Warranty registration is not necessary to obtain warranty on CHEFMAN® Products. Save your proof of purchase receipt.

**ABOUT YOUR PRODUCT WARRANTY:** Most warranty repairs are handled routinely, but sometimes requests for warranty service may not be appropriate. For example, warranty service would NOT apply if the product damage occurred because of misuse, lack of routine maintenance, shipping, handling, 3rd party warehousing or improper installation. Similarly, the warranty is void if the manufacturing date or the serial number on the product has been removed or the equipment has been altered or modified. During the warranty period, the authorized service dealer, at its option, will repair or replace any part that, upon examination, is found to be defective under normal use and service.

**NORMAL WEAR:** This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product; improper voltage or current; use contrary to the operation instructions; deviation from instructions regarding storage and transportation; repair or alteration by anyone other than CHEFMAN® or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes. CHEFMAN® shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

**HOW TO OBTAIN WARRANTY SERVICE:** If your CHEFMAN® product should prove to be defective within the warranty period, we will repair it, or if we think necessary, replace it. To obtain warranty service, simply email [customerservice@chefman.com](mailto:customerservice@chefman.com) or call our toll-free number 1-888-315-6553 for additional information from our Customer Service Representatives, or send the defective product to Customer Service at Chefman, 200 Performance Drive, Mahwah, NJ 07495.

This warranty is effective for the time periods listed above and subject to the conditions provided for within this policy.

### CALIFORNIA RESIDENTS ONLY:

California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product (A) to the store where it was purchased or (B) to another retail store which sells CHEFMAN® products of the same type. The retail store shall then, at its discretion, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product. If the above two options do not result in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility if service or repair can be economically accomplished. CHEFMAN® and not the consumer will be responsible for the reasonable cost of such service, repair, replacement, or refund for nonconforming products under warranty.

CHEFMAN® is a registered trademark of RJ BRANDS, LLC.

# WARRANTY



**ERASE BOARD**

**PERSONAL FRIDGE**

**CHEFMAN®**

**All data fields are required in order for us to process your request:**

Model Number: \_\_\_\_\_

Full Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Phone: \_\_\_\_\_ Email: (if applicable) \_\_\_\_\_

Date of Purchase\*: \_\_\_\_\_

\*We recommend you keep the receipt with this warranty card

Retail Store of Purchase: \_\_\_\_\_

**Description of Malfunction:**

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Return your completed warranty card to:

**RJ Brands  
200 Performance Drive  
Suite 207  
Mahwah, NJ  
07495**

**ERASE BOARD  
PERSONAL FRIDGE**

**MODEL:  
RJ48-BLACK-DE**

**888.315.6553**

**customerservice@chefman.com**

Phone lines available Monday to Friday, 9am-5pm EST  
**1-YEAR LIMITED WARRANTY**

**CHEFMAN**<sup>®</sup>



CLUBCHEFMAN.COM | CHEFMAN.COM | @MYCHEFMAN